



TECH BRIEFS

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING

**NASA's
Inventions
of the Year**

**Automation
Software Enables
Advanced Electronic
Design**

**NASA Failure-Reporting
Device Mimics "Black Box"
Data Recorders**

JOHN F. KENNEDY
SPACE CENTER LIBRARY
DOCUMENTS DEPARTMENT
CIRCULATION COPY

UPDATE SL ONLY
RETAIN PAST ISSUES

Photonics Tech Briefs

Motion Control Tech Briefs




Painless Programming



Prevent headaches with Measurement Ready DAQ.

Get results from your measurements – not headaches from acquiring them. Simplify your data acquisition (DAQ) development with:

- Straightforward documentation of DAQ functions
- Hundreds of ready-to-run DAQ examples for NI LabVIEW™ and Microsoft Visual Studio
- Thorough triggering and synchronization control with simple software commands
- Pre-configured measurements scaled to your choice of units



The NI PCI-6036E is a 16-bit E Series DAQ board with a 200 kS/s sampling rate, two analog output channels, and timing/triggering options for easy control from a familiar programming environment.

ni.com/info

Learn how to prevent programming headaches today. Visit ni.com/info and enter **namw01** to download an interactive white paper on Measurement Ready DAQ.

**NATIONAL
INSTRUMENTS™**

(800) 449-6347

Fax: (512) 683-9300 • info@ni.com

DO YOU HAVE YOUR OMEGA®



MADE IN THE USA HANDBOOK™ SET?


A supply chain's best friend!
5,000 pages of solutions



OMEGA offers the most impressive customer service in the industry. Fortified with manufacturing know-how and thousands of products on-hand for immediate delivery, OMEGA is your one-stop choice.

- Same day shipping
- Free loaner program
- Online quotes and sales
- Certified calibration lab
- Custom design department
- Degreed application engineers
- Knowledgeable sales associates
- Extensive worldwide warehousing

The OMEGA® Made In The USA Handbook™



- ✓ Free Software
- ✓ Easy to Use Navigation
- ✓ Thousands of Products
- ✓ No Installation Required

Request Your FREE Copy Today

1-888-82-66342®

Shop online at omega.com™

Temperature • Pressure •
 Electric Heaters • Data Acquisition
 The Green Book • PH & Conductivity
 Transactions

Get Your Dilbert Card Deck

Circle No. 500

www.omega.com/dilbert



Dilbert Decks No. 13 & 14 Available

omega.com®

Ω OMEGA®


Also available on CD

© COPYRIGHT 2002 OMEGA ENGINEERING, INC. ALL RIGHTS RESERVED.
 Handbook Covers: © SEPS: Licensed by Curtis Publishing, Indianapolis, IN www.curtispublishing.com

Online:
usaomega.com
 Circle Number:
 501



▲ Wire Stripping with Sealed CO₂ Lasers



Clean results were achieved with a 25-watt Synrad CO₂ laser.


Because many materials used to fabricate wires, such as copper and aluminum, are reflective to the CO₂ wavelength, lasers are an excellent source for wire stripping. The laser ablates the coating, typically consisting of PVC, Teflon, Mylar, etc., and the laser beam reflects off the copper, leaving the underlying wire undamaged. Unlike traditional contact cutting methods, which can lead to product damage, the laser produces clean results.

The wire stripping application in the photo to the left was accomplished by scanning a 0.6" x 0.15" area with a Synrad FH "Index" marking head and 25-watt laser. Two passes of the laser were used at a speed of 40" per second and a resolution of 350. The process was then repeated on the other side of the material, resulting in a cycle time of 2.3 seconds per side.

▲ Laser Marking Plastic Automotive Parts

Sealed CO₂ lasers are ideal for marking text, bar codes, and serial codes on a wide range of plastics. The type of plastic, absorption of the laser beam, and power used will determine the type of mark that can be created on the material.

Marking is achieved by either engraving the material or by creating a contrasting mark on the surface. Engraved marks are produced when the laser actually removes material, creating a depression. Contrasting



Engraved marks can be created on plastic parts using just 10-watts of laser power.

marks are produced by either surface melting or by surface discoloration via a chemical reaction of the material to the laser beam, usually requiring less power than engraving.

The engraved alphanumeric on the plastic automotive part in the photo to the left were created using a Synrad 10-watt laser, marking head, and 125mm lens. The marks were made at a speed of 5" per second and a cycle time of 0.75 seconds, using a spot size of 180 microns.

▲ Laser "Engraving" Polyester Fleece

The pile of this polyester fabric can be selectively removed to create a pattern or logo on the material with no discoloration. An alternative to interweaving the pattern into the fleece, the laser offers manufacturers excellent flexibility on logo positioning and design.



Polyester fleece, "engraved" with a Synrad 10-watt laser and FH-Series "Index" marking head.

Discover more CO₂ laser applications!
Sign up for our
online Applications Newsletter at
www.synrad.com/signup1

All applications on this page were processed at Synrad's Applications Laboratory. Synrad, the world's leading manufacturer of sealed CO₂ lasers, offers free process evaluations to companies with qualified applications. Call 1-800-SYNRAD1 for more information.

A DECADE OF DOMINANCE




**#1 OVERALL PERFORMANCE
10 YEARS IN A ROW!**


DISTRIBUTOR EVALUATION STUDY, 1992-2001

**www.
Digi-Key[®]
.com**

**1-800-DIGI-KEY
www.digikey.com**

Now the left hand knows what the right hands are doing.





Introducing Microsoft Project Server 2002, the newest way to manage your enterprise projects at every organizational level. Today's complex projects have grown to encompass multiple departments, organizations, and geographies, which means visibility and collaboration are more essential than ever. Part of the Microsoft® .NET family of servers, Microsoft Project Server 2002 works with Microsoft Project Professional 2002 to help you manage resources and model projects across your portfolio. Web-based access to project information keeps everyone in the loop, at any time and from anywhere. And the open architecture in Microsoft Project Server 2002 allows you to deploy a customized, secure, enterprise-scale project-management solution that integrates with your current business systems. So even when there are lots of hands on the job, they're still of one mind. Find out how Microsoft Project Server 2002 can help you manage projects across your organization. Go to goprojectserver.com **Software for the Agile Business.**

Microsoft®



FEATURES

- 27 Automation Software Enables Advanced Electronic Design**
- 30 NASA Awards Inventions of the Year**
- 32 Application Briefs**
- 68 Specifying Fiber Alignment System Performance: Coupling Loss Offers An Alternative to Motion Capability Solutions**

27



32

SOLUTIONS



34 Technology Focus: Data Acquisition

- 34 Remote Monitoring and Alarm System
- 34 Failure-Reporting Device Concept for Spacecraft and Remote Vehicles
- 36 Program Uses Terrain-Image Data To Locate Safe Landing Site
- 36 Measuring Sea Height and Roughness With GPS Reflections
- 40 Hybrid Electric-Field Sensor



41 Electronic Components and Systems

- 41 Communication Antenna in a Helicopter Rotor
- 42 GPS Attitude Determination Using Nonaligned Antennas
- 44 A Semiautomated Coordinate-Measuring System



48 Software

- 48 Software Provides Thermal Optimization of a Computer CPU
- 50 Software for Automated Planning of Spacecraft Missions
- 50 Generalized-Time-Line Program for Planning and Scheduling



52 Materials

- 52 Improvements in the Use of Water Washes in Testing for NVR
- 55 Using Polyimide Tape to Mask Against Reactive-Ion Etching



56 Mechanics

- 56 Hexfoil Rotary Flexures
- 58 Flight Research on Supersonic Laminar Flow
- 61 Improved Flange Design for Cryogenic Vacuum O-Ring Seals

DEPARTMENTS

- 14 Commercial Technology Team**
- 18 UpFront**
- 20 Reader Forum**
- 22 Who's Who at NASA**
- 24 Technologies of the Month**
- 78 Advertisers Index**

NEW FOR DESIGN ENGINEERS

- 73 Products/Software**
- 74 Literature**

SPECIAL SUPPLEMENT




1a – 14a Photonics Tech Briefs


Follows page 40 in selected editions only.



Hewlett-Packard Optimizes New Tape Drive with Simulation Software




A Hewlett-Packard LTO Ultrium Back-up Drive



Mechanical Event Simulation
of Magnetic Back-up Tape

Von Mises Stress
from the Mechanical
Event Simulation



"The software's early prediction of the stress levels enabled me to make adjustments and optimize the design."

*Paul Poorman
Mechanical Engineer
Hewlett-Packard Company*

Hewlett-Packard Chooses ALGOR FEA to Extend the Life of Back-up Tape

Linear Tape-Open (LTO) technology, developed jointly by Hewlett-Packard Company (HP), IBM and Seagate, replaces proprietary formats for corporate back-up solutions with an open tape format that makes it easier for customers to choose products. Hewlett-Packard used ALGOR's Mechanical Event Simulation (MES) software to analyze the behavior of the magnetic recording tape as it is wound through a Hewlett-Packard LTO Ultrium back-up drive.

The Challenge

Hewlett-Packard's challenge was to optimize the LTO drive to increase tape durability while maintaining tape path stability. To study the tape's behavior, the software had to simulate motion, contact between parts in an assembly, large displacement, elastic material behavior and stresses.

For this complete story and others, visit
hptapedrive.ALGOR.com

The Solution

A Hewlett-Packard engineer, Paul Poorman, modeled the magnetic tape with isotropic shell elements and the drive assembly using kinematic elements. In the MES, the tape wraps around two rollers and across a tape head and is then pulled into a take-up reel. The MES results showed the motion of the tape and resulting stresses. These results helped Hewlett-Packard find a proprietary solution that keeps the tape on track while reducing stresses on the edge of the tape, thus extending the life of the back-up tape. Paul Poorman reports, "The first generation of Hewlett-Packard Ultrium drives is currently in the market and performing well."



ALGOR, Inc.
150 Beta Drive
Pittsburgh, PA 15238-2932 USA
Phone 1.412.967.2700
Fax 1.412.967.2781

USA/Canada
1.800.48.ALGOR


France
0.800.918.917

Italy
800.783.132

Singapore
800.120.3775

United Kingdom
0.800.731.0399

hptapedrive@algor.com
hptapedrive.ALGOR.com



All trademarks may be trademarks or registered trademarks of their respective owners.



62 Physical Sciences

- 62 Making Hydrogen by Electrolysis of Methanol
- 63 Aircraft-Mounted Cloud-Water-Content Probe
- 64 Miniature NMR Spectrometers Without Magnets



66 Books and Reports

- 66 MEMS Design Optimization With FEA
- 66 Further Developments Regarding Noise-Reducing Slots in QWIPs
- 66 Time-Parallel Algorithms for Solving PDEs




70 Motion Control Tech Briefs

- 70 Algorithm Computes Kinematics of a Rover on Rocky Terrain
- 71 Software for Simultaneous Control of Three Magnetic Bearings
- 72 Crowned Races for Crossed Roller Bearings

PRODUCT OF THE MONTH

ATEasy 4.0 test development software from Geotest-Marvin Test Systems (Irvine, CA) lets users create re-usable components modeled after real-world test systems.



18

ON THE COVER



The DeBaKey Ventricular Assist Device (VAD) rotary blood pump, developed at Johnson Space Center, was named NASA Commercial Invention of the Year for 2001. The use of computational fluid dynamics (CFD) modeling, coupled with computing technology from NASA's Advanced Supercomputing (NAS) division at Ames Research Center, led to design modifications that improved the VAD's performance. This image shows a visual comparison of the original VAD (right), and the unit following the addition of an inducer. Read more about the pump, as well as NASA's Government Invention of the Year, beginning on page 30.

(Image courtesy of NASA/Cetin Kiris)

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+ .00

Industrial Portable Workstations

ruggedized
multi-slot
multi-drive bay
sunlight readable LCD




For more than a decade, BSI has provided custom solutions for field service and mobile computer applications with our multi-slot portables. BSI's portables pack the full power of a desktop workstation into a ruggedized, compact chassis. They are optimized for single or dual-processor and support industry standard add-on cards and components.

Visit our web site or call us to see why major defence contractors and the National Guard choose BSI portables for their field applications.



Broadax Systems, Inc.

17539 E. Rowland Street . City of Industry, CA 91748 . tel: 626-964-2600 . fax: 626-964-2665



1-800-872-4547
GSA# GS-35F-0496K
www.bsicomputer.com

©2002 EDS. EDS and Unigraphics are registered marks and EDS is Design and EDS Solved & Design are trademarks of Electronic Data Systems Corporation or its subsidiaries.



EDS PLM SOLUTIONS Unigraphics®

- ❖ **Total Product Engineering: "The Ultimate Megaworks Supercombo."** EDS Unigraphics® delivers Total Product Engineering from concept to reality. For superior products at lower cost in less time. Now you can automate collaboration by capturing, re-using and sharing knowledge across complex products, easily and transparently. With Unigraphics, the total engineering process is digital, so you can design, simulate, optimize, document, build and test your products in record time. You'll eat it up. To learn more, call 877-342-5847 or visit eds.com/plm.



Published by **Associated Business Publications**
Publisher **Joseph T. Pramberger**
Editor/Associate Publisher **Linda L. Bell**
Editor, Market Focus Editions **Ashli K. Riggs**
Associate Editor/Internet Editor **Laura Raduta**
Production Manager **Joanne Gaccione**
Assistant Production Manager **John Iwanciv**
Art Director **Lois Erlacher**
Senior Designer **Christopher Coleman**
Circulation Manager **Hugh J. Dowling**

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor **Ted Selinsky**
Sr. Technical Analyst **Dr. Larry Grunberger**
Art Manager **Eric Starstrom**
Staff Writers/Editors **Dr. Theron Cole, George Watson**
Graphics **Robert Simons**
Editorial & Production **Joan Schmiemann, Becky D. Bentley**

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:
Administrator **Sean O'Keefe**
Director, Commercial Technology **Dr. Robert Norwood**
Publications Director **Carl Ray**

*For a complete list of staff e-mail addresses,
visit www.abpi.net*

ASSOCIATED BUSINESS PUBLICATIONS INTERNATIONAL
317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864


Chairman/Chief Executive Officer **Bill Schnirring (bill@abpi.net)**
Vice Chairman/Chief Operating Officer **Domenic A. Mucchetti**
MIS Manager **Ted Morawski**
Webmaster **Albert Sunseri**
Director of Electronic Products **Luke Schnirring**
eBusiness Director **Andrew Runk**
Credit/Collection **Felecia Lahey**
Accounting/Human Resources Manager **Sylvia Ruiz**
Office Manager **Alfredo Vasquez**

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES

Headquarters (212) 490-3999
CT, MA, NH, ME, VT, RI, Eastern Canada **Ed Marecki**
at (401) 351-0274
NJ, NY, PA, DE **Jim Oot**
at (973) 983-2757
VA, MD, DC, NC, SC, GA, FL, AL, TN, MS, LA, AR, OK, TX **Bill Manning**
at (770) 971-0677
MN, ND, SD, WI, IL **Bob Casey**
at (847) 223-5225
IN, KY, MI, OH, MO, KS, IA, NE, Western PA & NY, Central Canada **Chris Casey**
at (847) 223-5225
N. Calif., CO **Bill Hague**
at (800) 830-4351
WA, OR, ID, MT, WY, UT, NV, Western Canada **David Chew**
at (650) 726-2128
S. Calif., AZ, NM **Tom Boris**
at (949) 642-2785
Internet Advertising **Luke Schnirring**
at (212) 490-3999
Postcard/Literature Advertising **John Waddell**
at (212) 490-3999
Cathi Campbell
at (603) 627-4981
Reprints **Jeannie Martin**
at (866) 879-9144

Driving with confidence

Instron's no-compromise technology is deep and flexible, with a product range designed to meet the needs of every budget at every level of manufacturing sophistication. Our instruments test all of the earth's man-made and natural materials. Instron offers tensile, tension, torsion compression, fatigue and impact testing machines as well as structural testing systems. Our software is developed for simple or advanced design standards. Take the high road and standardize on Instron quality, reliability and service. We are the choice for critical applications throughout all industries. You can now own the Instron difference . . . The difference is measurable



▲ **8800 Servohydraulic Testing Systems®**



▲ **SF 1288 Spring Tester®**



▲ **Universal Testers®**



▲ **Rockwell 2000 Tester®**



▲ **In-Spec 2200 Handheld Tester®**



▲ **Dynatup 9200 Series®**

Instron Corporation • 100 Royall Street • Canton, MA 02021 • Tel: 800-564-8378 • Fax: 781-575-5751 • Email: info_query@instron.com

TEAM POWER



Designed for high performance and reliability. Tested and proven by leading CAD-ISV partners, a Compaq Evo™ Workstation with the latest Intel® Xeon® Processor simply makes things happen. These powerful Windows® platform machines will give your engineers some concurrent quality time. Now fully functional prototypes, more efficient 3D design, and Web-based project management and collaboration stand at-the-ready. For CAD solutions, put a Compaq Evo Workstation on your team. It will be high fives all around.

Compaq CarePak Services provides a variety of upgrades to enhance the base warranty on your Compaq products.

[to equip your team for victory visit
compaq.com/workstations
or call 1-800-888-0414



The Power of
MACROPROCESSING

COMPAQ
Inspiration Technology

Compaq PCs use genuine Microsoft® Windows®
www.microsoft.com/piracy/howtotell

Compaq, the Compaq logo, Evo and Inspiration Technology are trademarks of Compaq Information Technologies, L.P. in the U.S. and other countries. Intel, the Intel Inside logo, and Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries. Other products mentioned herein may be trademarks of their respective companies. Compaq is not liable for editorial, pictorial, or typographical errors in this advertisement. © 2002 Compaq Information Technologies, L.P.


For Free Info Circle No. 518 or Enter No. 518 at www.nasatech.com/rs


They believe you'll automatically install their 3D software because you already have their 2D software.

We believe you're smarter than that.

We understand that you need the best design tools available. Why? Because SolidWorks was founded by people like you. People who know what it takes to design a product and see it through production. Our 3D software gets the job done. And gets it done easily. We're **100% Focused** on product design. We're **Proven** in production. Our **Innovative** capabilities lead the CAD

industry. When it comes to performance and compatibility, SolidWorks sets **The Standard**. Maybe that's why more than 188,000 designers and engineers worldwide will spend more than 50 million hours this year using SolidWorks® software. Don't be fooled by imitators. There's only one standard in 3D. SolidWorks. **For a free demo CD, visit us at www.solidworks.com/thestandard or call 1-800-693-9000.**





The Standard in 3D



For Free Info Circle No. 515 or Enter No. 515 at www.nasatech.com/rs

NASA Commercial Technology Team

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (609) 667-7737 for the FLC coordinator in your area.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths: Information Technology; Biotechnology; Nanotechnology; Aerospace Operations Systems; Rotorcraft; Thermal Protection Systems.
Carolina Blake
(650) 604-1754
cblake@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.
Jenny Baer-Riedhart
(661) 276-3689
jenny.baer-riedhart@dfrc.nasa.gov

Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Remote Sensing; Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@jpl.nasa.gov

Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Charlene E. Gilbert
(281) 483-3809
commercialization@jsc.nasa.gov

Kennedy Space Center

Selected technological strengths: Fluids and Fluid Systems; Materials Evaluation; Process Engineering; Command, Control and Monitor Systems; Range Systems; Environmental Engineering and Management.
Jim Aliberti
(321) 867-6224
Jim.Aliberti-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Sam Morello
(757) 864-6005
s.a.morello@larc.nasa.gov

John H. Glenn Research Center at Lewis Field

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Larry Viterna
(216) 433-3484
cto@grc.nasa.gov

Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Vernotto McMillan
(256) 544-2615
vernotto.mcmillan@msfc.nasa.gov

Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(228) 688-1929
kirk.sharp@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Carl Ray
Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)
(202) 358-4652
cray@mail.hq.nasa.gov

Dr. Robert Norwood
Office of Commercial Technology (Code RW)
(202) 358-2320
rnorwood@mail.hq.nasa.gov

John Mankins
Office of Space Flight (Code MP)
(202) 358-4659
jmankins@mail.hq.nasa.gov

Terry Hertz
Office of Aero-Space Technology (Code RS)
(202) 358-4636
thertz@mail.hq.nasa.gov

Glen Mucklow
Office of Space Sciences (Code SM)
(202) 358-2235
gmucklow@mail.hq.nasa.gov

Roger Crouch
Office of Microgravity Science Applications (Code U)
(202) 358-0689
rcrouch@hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Wayne P. Zeman
Lewis Incubator for Technology
Cleveland, OH
(216) 586-3888

Thomas G. Rainey
NASA KSC Business Incubation Center
Titusville, FL
(407) 383-5200

B. Greg Hinkebein
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

Joanne W. Randolph
BizTech
Huntsville, AL
(256) 704-6000

Julie Holland
NASA Commercialization Center
Pomona, CA
(909) 869-4477

Joe Becker
Ames Technology Commercialization Center
San Jose, CA
(408) 557-6700

Bridgette Smalley
UH-NASA Technology Commercialization Incubator
Houston, TX
(713) 743-9155

Marty Kaszubowski
Hampton Roads Technology Incubator (Langley Research Center)
Hampton, VA
(757) 865-2140

John Fini
Goddard Space Flight Center Incubator
Baltimore, MD
(410) 327-9150 x1034

Paul Myrda
NASA Illinois Commercialization Center
West Chicago, IL
(630) 845-6510

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

Joseph Allen
National Technology Transfer Center
(800) 678-6882

James P. Dunn
Center for Technology Commercialization
Westborough, MA
(508) 870-0042

Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(409) 845-8762

Pierrette Woodford
Great Lakes Industrial Technology Transfer Center
Battelle Memorial Institute
(216) 898-6400


Ken Dozier
Far-West Technology Transfer Center
University of Southern California
(213) 743-2353

B. David Bridges
Southeast Technology Transfer Center
Georgia Institute of Technology
(404) 894-6786

Charles Blankenship
Technology Commercialization Center
Newport News, VA
(757) 269-0025

NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.



© David Corio

"The key to innovation is the fearless pursuit of experiment, application, and proof of the theory. IEEE allows engineers to see what is possible, and pursue it with science."

Dr. Evangelia Micheli-Tzanakou
IEEE Fellow

Director of Computational Intelligence
Laboratories, Department of Biomedical
Engineering, Rutgers University



What will you discover next? Join IEEE.
www.ieee.org/apply



too few
software seats

insufficient
compute time

simulation
uncertainties

incorrect
analysis

market window
closing

need larger
team

not enough
experts



Feeling pressured?
We can help.

Announcing MSC.Professional Services—
from the experts in engineering analysis.

Let us take the weight off. We realize how important it is for you to get results. So we work hard to help you streamline your product development process. Call now, we'll show you what we know. We'll listen. We'll ask. And we'll propose the right solution.

Put MSC.Professional Services on your team today and we'll start taking the pressure off, fast.

FOR MORE INFORMATION:

www.engineering-e.com
1.888.817.ECOM

SOFTWARE

World's leading
simulation software.

SYSTEMS

High performance computing
for complex analysis.

SERVICES

Expert solutions for the
most challenging problems.

engineering-e.com



For Free Info Circle No. 511 or
Enter No. 511 at www.nasatech.com/rs

PRODUCT OF THE MONTH

Geotest-Marvin Test Systems, Irvine, CA, has released ATEasy 4.0 test development

software for most test and measurement applications.


It lets users create reusable components modeled after real-world test systems.

Components include systems, drivers, programs, tests, and commands. The graphical user interface is compatible with Microsoft Visual Basic™ and Visual C++™. The software's modular structure

allows users to partition and organize test code. A just-in-time compiler gathers only the necessary code to be executed independently without running the entire application. ATEasy features an open system architecture that provides ActiveX controls, spreadsheets, databases, word processors, and Web browsers. A Test

Executive module selects and runs a test program, and debugs, views, and prints test logs.

For Free Info Circle No. 720 or Visit www.nasatech.com/geotest



What's New On-Line

The NASA Tech Briefs Software Center is now open on the NTB Web site at www.nasatech.com/software. The Software Center is a new FREE download service that lets you access NASA software programs and source code available for commercial applications and development, ranging from aerodynamic analysis to viscosity measurement. NASA Tech Briefs readers also will be able to purchase commercial engineering software directly from the site.

Currently, the Software Center features software code from NASA's Glenn Research Center. But check back often as we continue to add more programs from NASA's other field centers around the country, as well as demos of new commercial software packages.

The Software Center also highlights software-related tech briefs, archived software reviews from NASA Tech Briefs, and feature articles on software topics that have appeared recently in NTB.

Check it out at www.nasatech.com/software.

NASA's New Atomic Clock Will Aid Farmers and Physicists

Modern navigators continue to rely on atomic clocks that use the natural resonance of atoms to provide the steady tick of a clock. The best atomic clocks on Earth lose no more than one second in millions of years. Scientists at NASA's Fundamental Physics Program would like to do better.

Sailors, truck drivers, soldiers, pilots, and hikers all rely on atomic clocks by using Global Positioning System (GPS) devices. Each of the 24 GPS satellites carries four atomic clocks. Tiny instabilities in those orbiting clocks can contribute a few meters of error to

single-receiver GPS measurements. Making the clocks smaller and increasing their stability could reduce such errors.

A laser-cooled clock called PARCS is expected to be installed on the International Space Station by 2005. It should be the most stable clock ever, keeping time within one second every 300 million years. PARCS will test technologies to be used in a next-generation clock named




RACE slated for installation on the ISS in 2006. RACE will keep time so well that if it ran for three billion years, it would lose less than one second.

Clocks like PARCS and RACE will improve telecommunications on Earth, including navigation. Pilots landing on narrow airstrips at night would benefit, as would surveyors, farmers, and search and rescue teams.

For more information, visit <http://link.abpi.net/1.php?20020416A2>.

Next Month in NTB

The focus will be on Automotive Technology in the July issue of NASA Tech Briefs, with a feature article on auto design and manufacturing, including the newest players in automobile design, simulation, and analysis. Also look for new NASA innovations in sensors and actuators.



**Sooner or later, every design becomes 3D.
This is an argument for sooner.**



Introducing **Autodesk Inventor™ Series**. We've paired the groundbreaking Autodesk Inventor 3D technology with the AutoCAD®-based Autodesk® Mechanical Desktop®, creating a flexible design solution that helps you move from 2D to 3D without giving up your current system. For Dr. Markus Bohrer, General Manager of Incision Lasertec, the breakthrough adaptive technology and industry-leading DWG compatibility has helped increase productivity: "With Inventor we finished our latest, highly complex machine in only 8 months. Without Inventor it would have taken us twice the time." Are you ready for 3D made easy? Experience the freedom to design without limits. Visit www.autodesk.com/inventorseries to find out more.

autodesk®

©2002 Autodesk, Inc. Autodesk, the Autodesk logo, AutoCAD, Autodesk Inventor, and Mechanical Desktop are either registered trademarks or trademarks of Autodesk, Inc., in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders.

For Free Info Circle No. 509 or Enter No. 509 at www.nasatech.com/rs

**Fast.
Reliable.
Safe.
Everything
automated
riveting
should be.**



**Introducing POPmatic
Point & Set™, the first
reliable auto-feed rivet
system.**

POPmatic Point & Set, our new auto-feed rivet system, delivers what no riveting tool has before. Consistent riveting at a rate faster than any current hand tool. Designed with a safe, self loading hopper that holds up to 2500 rivets, Point & Set accelerates the riveting process to previously impossible speeds, meeting the requirements of any production line. It's reliability in an otherwise unreliable world. For more information, call us at 203-925-4424 or visit us on the web at www.emhart.com

Emhart®
POPMATIC

A BLACK & DECKER COMPANY

CERTIFIED
ISO 9001 • QS 9000

Reader Forum

Reader Forum is dedicated to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a technical problem, or an answer to a previously published question, post your letter to Reader Forum on-line at www.nasatech.com, or send to: Editor, *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and e-mail address or phone number.

I am writing in response to a letter in the March Reader Forum from Michael Jones, who was looking for suggestions on developing a wireless video system. I believe the poor results he's experienced so far are due to multi-path fade and echoes. I suggest a reflector behind the receiving antenna, with about .2 wave separation, and diversity in the form of two antennas some distance apart with the feed lines exactly the same length to the "T". The power/bandwidth allocations in that frequency range are rather stringent.

dave@diamondtouch.com

I'm looking for a device that when placed onto a cargo container, transmits an active signal if the container is tampered with or breached. It would need to be tracked throughout the world. Thank you.

Dave Fulbright
j.fulbrig@jcpenny.com

(Editor's Note: Dave, NASA's Jet Propulsion Laboratory in Pasadena, CA, has developed such a device. The credit-card-sized transponder is placed on a cargo container and can be tracked anywhere on Earth. You can access the complete tech brief on this technology by visiting the NASA Tech Briefs library at: www.nasatech.com/Briefs/Sept98/NPO19769.html.)

Technologies Wanted

Periodically in Reader Forum, we feature abstracts of Demand-Pull Technology Transfer projects. These projects identify technology needs within an industry segment — such as Augmentative Communication — and find solutions to meet those needs. The Rehabilitation Engineering Research Center on Technology Transfer, in partnership with the

Rehabilitation Engineering Research Center on Communication Enhancement and the Federal Laboratory Consortium, has developed the Project on Communication Enhancement to identify technologies like those listed below to help persons with communication disabilities who use Augmentative Communication devices. For more details on the project, or to submit technology proposals, visit <http://cosmos.buffalo.edu/aac>.

Speech Production & Output Technology

Output technologies (speech synthesis, sound projection, and adaptive volume control), are needed that are intelligible, personalized, and natural-sounding to enhance communication privacy. Display technologies are needed that perform well in all lighting conditions and support private communication at short range or remotely.

Speech synthesis technology should produce a natural-sounding voice that can express emotion. It should be customizable and modifiable in real time. Automatic volume control should recognize ambient sound levels; the user should be able to adjust loudness and turn on/off.

Displays should reduce or eliminate daylight glare and improve contrast for night viewing. Displays that automatically adapt to changes in lighting conditions also are desired. Third-party intervention should not be required to set-up, adjust, or take down the display.

Wearable, remote, and dual displays are sought to enhance opportunities for education, rehabilitation, safety, and personal independence. Wireless wearable displays should be unobtrusive and provide a high-quality image. It should not obstruct face-to-face interaction.


Directed sound output (speakers) should automatically track the communication partner to increase intelligibility and communication privacy.

A black and white photograph of three men in a human pyramid formation. The man at the base is crouching, the middle man is leaning over him, and the top man is perched on the middle man's shoulders. They are all in a pensive pose, with their hands on their chins. The background is a textured, dark surface.

IF YOU CAN THINK IT, WE CAN DO IT.

Emhart is a world leader in the design and supply of innovative fastening and assembly technology. From concept through installation, whether you're manufacturing around the corner or around the globe, Emhart provides cost-effective solutions for assembly applications. Visit us at www.emhart.com

Emhart[®]



A  BLACK & DECKER COMPANY

Extreme sensors

High
Accuracy,
Reliability,
Structural
Integrity



NONCONTACT EDDY CURRENT DISPLACEMENT SENSORS



800-552-6267

www.kamansensors.com

KAMAN

Who's Who at NASA

Dr. Paul Schenker, Director, Planetary Robotics Laboratory, Jet Propulsion Laboratory

Dr. Paul Schenker is the director of the Planetary Robotics Laboratory (PRL) at NASA's Jet Propulsion Laboratory in Pasadena, CA. The organization is responsible for research and development in mobility and robotics, and is developing a series of rover prototypes for planetary surface exploration.



NASA Tech Briefs: What is the purpose of the rovers?

Dr. Paul Schenker: The purpose is to develop new rovers and supporting technology that could go into more difficult terrain that is rough and sloped. Current rovers have a hard time traveling through rocky, dense areas, or up slopes that are more than 15-20 degrees. It's now thought that some of the most exciting planetary science will be near water outflows at craters' edges. We want to drive rovers up or down to such an area to get to the interesting science.

NTB: How have these rovers performed in demonstrations?

Schenker: They've done well. We first developed the technology in the laboratory. That technology includes not only re-configurable rovers — meaning ones that could change their shape and the positioning of their mechanical parts, their legs, structure, and wheels — but new algorithms that can take what the rovers see, literally, and adapt their control and traction as they go into steeper areas. It's similar to how a human or a dog changes footing, squats down, and gets prepared to go up or down a steep hill.

We give the rover behaviors or skills whereby it can adapt when it sees a region with its computer vision or 3D terrain mapping. So it's kind of an animal-like paradigm, but a rather intelligent one.

NTB: What's the newest prototype?

Schenker: The more exciting aspect of this project is the development of the Cliff-bot. It's not one robot, but three. This is a true robot team with distributed intelligence and sensing. Two of the ro-

bots are at the top of the cliff and they are referred to as the Anchor or Tether-bot, which assist the Cliff-bot. There are tethers attached to the Cliff-bot, forming a triangle — two at the top and then the two tethers going down. The robot that is going up and down the cliff is actively driving; it's not just being lowered. A good analogy would be a human climber with two expert assistants.

What is very exciting about that in terms of applications is the promise of a robot being able to go to these very steep cliff edges where there might be mineral water outflows. Using these rovers, we can look where we've never been able to go before.

NTB: Do you foresee any terrestrial applications?

Schenker: Absolutely. The onboard intelligence, or the autonomy, is the research basis for making robots smarter. I think we'll see the robot team idea have importance in things like military applications and for search and rescue. If someone is in trouble, you can deploy a robot into a difficult region. We haven't done anything like that for terrestrial applications. Our work has been NASA-based, but these technologies are potentially important for terrestrial and military applications.

NTB: What is the goal of the Planetary Robotics Laboratory?

Schenker: The PRL is an organization of about 85 people whose interests include the broad range of technology for both NASA and non-NASA robotics. The expertise here spans machine vision, robotic navigation, onboard robotic autonomy, operation interfaces, and mechanical design. Another project is robot-assisted microsurgery (RAMS), which is a system for dexterity-enhanced microsurgery. The surgeon makes a tele-operated input, so when the surgeon's hand moves, it scales the surgery down by a factor of ten and filters out the tremors, allowing doctors to do remarkable surgery. That technology is now on its way to market.

A full transcript of this interview appears online at www.nasatech.com/whoswho. Dr. Schenker can be reached at schenker@helios.jpl.nasa.gov.

Expand your capabilities...



...faster, better, more affordably.

Anywhere you need to go, our rugged portables are ready. FlexPAC™ is available with six full-size expansion slots, an Intel Pentium® 4 processor running at 2 GHz, system memory up to 2 GB, and video memory of 16 MB. That means you won't find a more robust industrial portable computer anywhere. And with its new rugged design and lifetime guaranteed configuration control, FlexPAC is also remarkably affordable. No wonder companies like Agilent and National Instruments have made Dolch their choice.

Check it out along with other Dolch products at www.DolchNTB.com
or call 877.347.4924.

©2002 Dolch Computer Systems, Inc. FlexPAC is a trademark of Dolch Computer Systems, Inc. All other brand or products named are trademarks or registered trademarks of their respective companies.

For Free Info Circle No. 517 or Enter No. 517 at www.nasatech.com/rs

Technologies of the Month

Sponsored by **yet2.com**

For more information on these and other new, licensable inventions,
visit www.nasatech.com/techsearch

Water-Repellent Technology Can Be Controlled By Light

Hitachi, Ltd.

Waxes, oils, and other coatings have been used to create water-repellent products; however, these coatings evaporate over time, leaving a surface unprotected. A new compound provides an increase in water repellency for a range of materials and products by creating a surface coating offering a contact angle with water of approximately 80-120°. This enables round water droplets to hit the slanted surface and roll off before being absorbed.

A novel feature of this technology is the ability to control its degree of water repellency by applying a photochromatic compound to the coating material. By applying light to certain areas, the chemical structure of the compound can be altered, affecting its ability to interact with water by creating an acid or a base. Applications include anti-corrosion coatings, electronics packaging, anti-icing treatments, and fabric coatings.

Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/hitachi.html

Email: nasatech@yet2.com
Phone: 617-557-3837

High-Speed Replicator Synchronizes Data Updating Between Relational Databases

The Dutch Royal PTT Post

All the information produced since the dawn of recorded history equals approximately 18 terabytes — the number 18 followed by 18 zeroes. Twelve percent of that data was created in 1999 alone. Databases have become the core of most operations, and the upkeep and feeding of them accounts for increasingly large amounts of time, money, and manpower.

A commercial middleware called High Volume Replicator (HVR) replicates data between databases at extremely high speeds, enabling changes made to one set of data to affect and update those changes to relational databases. HVR offers mission-critical fault tolerance, collision resolution, and database/transaction consistency with 24-hour availability. It also guarantees zero downtime and complex synchronization across diverse platforms and operating systems. The middleware features a Java-based graphical user interface and supports HP-UX, Solaris, AIX, Open VMS, and Windows 2000.

Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/royalPTT.html

Email: nasatech@yet2.com
Phone: 617-557-3837

New Electrode Layering Technology Substantially Reduces Noise

Toyota

The static a driver hears on a car radio or occasional glitch in the automotive electrical system is often the result of ignition noise — unnecessary electrical signals generated by the distributor and spark plugs in a car's ignition system. As the rotor electrode in the distributor rotates, the discharge between it and the electrodes that send current to the spark plugs creates a high-frequency signal, causing ignition noise.

To combat this problem, Toyota has developed a multiple-layer electrode that reduces ignition noise and resists deterioration that can lead to noise creeping back in. The electrode is comprised of two layers, each composed of a metal oxide resistor and dielectric. The second layer features greater resistivity than the first, enabling a lower discharge voltage, which in turn reduces ignition noise. No additional materials or circuitry are required to reduce ignition noise levels, and less expensive materials can be used to replace conventional ceramic electrodes, cutting material and labor costs.

Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/toyota.html

Email: nasatech@yet2.com
Phone: 617-557-3837

New Stabilizers Improve Appearance and Lengthen Life of Plastics



Honeywell

Though plastic is relatively strong, lightweight, and versatile, its lifespan is shortened when exposed to sunlight, temperature fluctuations, and staining. A group of stabilizers from Honeywell utilizes a class of water-soluble sulfonated aromatic compounds that promise improved stain resistance and reduced fading.

When used to treat nylon fibers, the compounds are applied to the dyed fiber in a diluted or concentrated aqueous solution. The water is then removed and the fibers are oven-dried at 120°C. To improve the fiber's soil resistance, a fluorinated dry soil release agent can also be applied, either before or after the sulfonated aromatic compound application. To reduce fading, the fibers can be treated with cinnamamide compounds, which have the ability to absorb both UV-A and UV-B radiation, enabling polymer fiber to better withstand haziness, brittleness, and general loss of elasticity.


Get the complete report on this technology at:
www.nasatech.com/techsearch/tow/honeywell-stabilizers.html

Email: nasatech@yet2.com
Phone: 617-557-3837



FEMLAB[®]

— multiphysics in MATLAB[®]




FEMLAB[®] supplies highly sought-after new technology for the modeling and simulation of physics in all science and engineering fields. Its main attribute is the ease with which modeling can be performed and its unlimited multiphysics capabilities, in 1D, 2D and 3D — the perfect way to apply state-of-the-art numerical analysis to your expertise in modeling.

Order your free literature kit!



Visit www.comsol.com/ient or
call +1-781-273-3322





FEMLAB is a registered trademark of COMSOL AB.

- ▶ The most common reactor for environmental protection, which we encounter or use everyday, is the catalytic converter in automobiles. In these monolithic catalysts, carbon monoxide and nitrous oxides are converted into relatively harmless species like carbon dioxide and nitrogen. To optimize the utilization of the expensive catalyst, it is important to be able to model the reactor at different operational conditions. In this FEMLAB model, mass and heat balances are coupled to compute temperature distribution and flowlines in the reactor.
- ▶ This square-shaped spiral inductor is used for bandpass filters in micro electro-mechanical systems (MEMS). The FEMLAB simulation takes the nonuniform current density in the coils into account to compute an accurate magnetic flux around the coils. The inductance of this inductor is 2.1 nH, which is obtained by integrating the magnetic energy. Using the programming language of FEMLAB for parametric analysis, you can find the correlation between the induction and the input parameters of the model.
- ▶ In the design of electrodes for water electrolysis, it is important to minimize the voltage losses at a given total current. FEMLAB modeling helps the engineer in the design of the electrode geometry and the current collector. The model gives the current density distribution and the potential distribution in the system. These results make it possible to avoid excessive degradation of the active electrode surface and overheating of the welds at the position of the current collector.
- ▶ When designing an electric motor it is important to design the rotor shaft so that no eigenfrequencies exist in the working range of the rotational speed. It is also important to study the shape of the eigenmode and not just the eigenfrequencies. In the eigenfrequency analysis, one end of the shaft is fixed and the other end is free to rotate and axially deform. The image shows deformation and rotation angle in the second eigenmode, using different visualization options like colormaps and scaling.

FEMLAB KEY FEATURES

- Flexible and powerful graphical user interface
- Built-in user-friendly CAD tool for solid modeling in 1D, 2D and 3D
- Automatic mesh generation, adaptive mesh and multigrid
- Powerful solvers for linear, nonlinear and time-dependent systems of partial differential equations (PDEs)
- Extensive postprocessing capabilities
- Model Libraries with over fifty models fully documented from various engineering fields
- Ready-to-use application modes for different engineering fields
- Equation-based modeling for arbitrary systems of PDEs

FEMLAB PUTS YOU IN THE FRONTLINE

FEMLAB employs sophisticated numerical techniques developed by our staff of leading scientists in collaboration with industry experts from around the world. These professionals had a goal of making modeling available to every engineer and scientist. FEMLAB is the result of our commitment to putting engineering mathematics in a box.

Order your free literature kit!



Visit www.comsol.com/ient or call +1-781-273-3322




www.comsol.com

VISIT WWW.COMSOL.COM FOR INTERACTIVE DEMOS AND TUTORIALS

Automation Software Enables Advanced Electronic Design

A thriving industry supports innovation across markets and product types.

Electronic design challenges affect companies in almost every industry including consumer products, automotive, communications, and biomedicine. Perhaps that is why electronic design automation (EDA) blossomed into a \$4 billion dollar industry last year despite the troubled economy, according to the EDA Consortium's Market Statistics Service (MSS). That's a 6% increase over 2000 revenues. In fact, since the EDA Consortium started tracking revenue in 1994, the EDA market hasn't experienced a single year of negative growth.



Ansoft HFSS screen sample. 3D electromagnetic field radiation through a high-speed package.

Ray Bingham, EDA Consortium chairman and president, explained, "Even though the electronics industry experienced the worst economic downturn in its history last year, our customers around the world continued to increase their investments in the design of electronic products. That's because product design technologies and services play a crucial role in helping companies create value, differentiate their product offerings, and bring innovation to reality while accelerating time to market."

Industry of Specialties

The EDA Consortium — an international, non-profit association for companies developing design software and services that enable engineers to create the world's electronic products — divides the 16-year-old industry into five main application segments: Computer-Aided Engineering (CAE), Integrated Circuit (IC) Layout, Printed Circuit Board (PCB) & Multi-Chip Module (MCM)

Layout, Services, and Semiconductor Intellectual Property (SIP) Products & Tools. Working together, EDA providers structure packages to target a combination of specific market and design sub-segments. These companies often provide highly specialized software tools and/or systems that enable complex designs to be realized.

Electronic products are becoming more feature-rich and the number of transistors on an IC is growing exponentially. This necessitates the highly specialized, team-based environments that characterize the design process. As Pamela Parrish, executive director of the EDA Consortium, pointed out, "The bottom line is that consumer demand for more 'gee wiz' features has increased the complexity of designs. We no longer have one engineer designing an entire IC, for example. A team consisting of engineers with differing expertise is needed to create the design using specialized EDA tools."

Just as a single engineer cannot provide all the necessary expertise for most design projects, one software company cannot provide all the solutions necessary for every segment of design. Thus, a majority of EDA software companies create some level of interoperability between their solutions and those of other companies. Some alliances are even branded through formalized partnership programs.


Align to Design

"Connection programs like Cadence's Connections® Program and Mentor's OpenDoor are inherent to the EDA industry. After all, EDA stands for electronic design automation and to do that requires data flow and transfer to and from various tools, whether it is hardware or software," added Sherry Hess, vice president of marketing for Ansoft Corporation, a provider of simulation software and member of Cadence Design Systems' Connections program. Hess also noted that a major advantage of these programs is that they remove duplicity from the design cycle, thereby creating significant time-savings and re-

ducing errors associated with manually handling data.

A supplier of electronic hardware and software design solutions, Mentor Graphics' previously mentioned OpenDoor program consists of more than 95 companies that develop and maintain commercial integrations with Mentor for design processes including PCB layout and IC design. Mentor maintains relationships with Ansoft and Cadence through this program.

Cadence, a supplier of EDA products and methodology/design services for semiconductors, computer systems, networking/telecommunications equipment, consumer electronics, and other electronics-based products, provides over 120 members of the Connections Program with access to software and application notes that enable tool interoperability with third-party software. Through the program, Cadence developed interoperability with several Ansoft products. Traces from Cadence software such as APD, a constraint-driven layout environment for the physical design of complex, high-density IC packages, and



A sample screen from AWR's Microwave Office 2002 during a MMIC design project.

Allegro™, a physical and electrical constraint-driven system for the physical design of multi-layer PCBs, can be exported into Ansoft computational analysis tools such as HFSS™ and Maxwell® Spicelink. Originally introduced in 1990, Ansoft HFSS™ provides 3D electromagnetic (EM) simulation for radio frequency (RF), wireless, packaging, and optoelectronic design. Maxwell® Spicelink per-

STRATEGY TO SERVICE

we know

they know

CONCEPT TO MARKET

Product Lifecycle Management (PLM) solutions. IBM's unpr technologies. Dassault Systemes' leading 3D applications p product development an integrated, collaborative, and in cut production costs and get to market faster. Whatever yo

IBM

@business

COLLABORATE TO INNOVATE— PLM SOLUTIONS

Product Lifecycle Management (PLM) solutions reduce the complexities and restrictions linked to product manufacturing. How? By providing the framework and tools that foster a collaborative, integrated, end-to-end, process-centric environment. In short, PLM brings together the entire network of companies that conceptualize, design, manufacture and support a product to work together as one single entity.

Improved collaboration leads to better end products. Promoting real-time data exchange between all parties in the product manufacturing process helps define best practices and methodologies. So, rather than reinventing the wheel each time, your whole team gets to concentrate on manufacturing higher-quality, more innovative products. End result: reduced development costs, faster speed to market, maximized profitability and increased customer loyalty.

IBM AND DASSAULT SYSTEMES

Together, IBM and Dassault Systemes offer you leading PLM solutions. IBM is the largest e-business solutions provider, with industry proven technologies and implementation skills. It provides the foundation and support for an unrivalled 3D PLM applications portfolio from Dassault Systemes, including CATIA, ENOVIA and SmarTeam. Companies worldwide have already integrated and streamlined their product management processes with the help of a PLM solution from IBM and Dassault Systemes.

SEE FOR YOURSELF

Discover how PLM solutions have helped other businesses like yours.

GO TO IBM.COM/SOLUTIONS/PLM/WHY

PLM

we know

they know

3D

Product Lifecycle Management (PLM) solutions. IBM's unprecedented e-business experience and proven industry technologies. Dassault Systemes' leading 3D applications portfolio. Together, we provide PLM solutions that make product development an integrated, collaborative, and innovative process. Streamline product development, cut production costs and get to market faster. Whatever you make, make it better at ibm.com/solutions/plm/why

IBM

@ business solutions

D
S
DASSAULT
SYSTEMES

IBM and the e-business logo are trademarks of International Business Machines Corporation. CATIA is a registered trademark of Dassault Systemes. ENOVIA is a registered trademark of Dassault Systemes. SmarTeam is a registered trademark of Dassault Systemes. Other company, product or service names may be the service marks or trademarks of others. © 2002 IBM Corporation. All rights reserved.

forms electromagnetic field simulation of 2D and arbitrary 3D structures.

In April, Applied Wave Research (AWR), developer of EDA software for wireless, high-speed wireline, and electro-optical applications, also joined the Cadence Connections Program. AWR plans to integrate their Microwave Office 2002 design suite, which consists of an IC layout editor as well as harmonic balance and EM simulators, with Cadence's Analog Design Environment™, an analog design automation solution for analog and RF-IC design, and SpectreRF, a full-chip RF-IC simulator for wireless communication designs. According to AWR, this will give system-on-a-chip (SoC) designers integrated IC design and verification capabilities by combining their RF and microwave technology with Cadence's layout, simulation, and verification products.

Ted Miracco, executive vice president of AWR, noted, "The trends in the electronics industry continue to be higher levels of integration and reducing power consumption. EDA companies are trying to address these trends by providing better tools for simulating complete systems

ucts offer varying degrees of interoperability and valuable design capabilities for end users.


ALGOR's Multiphysics technology, for example, operates seamlessly with most CAD solid modelers so that engineers can continue to use tools they already understand. Easy set-up enables engineers to focus on the physics of a part or assembly instead of learning the process and terminology of a specific software package. For instance, the graphical user interface allows engineers to link the results of one analysis to another by clicking on just a few options.

Bob Williams, product manager at ALGOR, commented, "Several of ALGOR's recent multiphysics enhancements are especially well-suited for the design, analysis, and optimization of electronic devices, although our FEA and Mechanical Event Simulation software are used by engineers in a wide variety of industries." Enhancements to multiphysics include the new Joule heating capability and the forced convection option. Williams noted that the Joule heating capability enables engineers to link results from electrostatic analysis and heat transfer analysis in order to calculate the heat generated by a current. Especially suitable for analyzing systems requiring fans or water for cooling, the forced convection option includes fluid convection effects in heat transfer analysis.

Jointly developed by Fluent, a provider of commercial computational fluid dynamics (CFD) software and services, and ICEM CFD Engineering, a developer of software for pre- and post-processing of engineering applications, Icepak is an object-based, thermal management and computer-aided analysis tool for electronics. Icepak can be integrated with other CAD and EDA tools thanks to enhanced CAD geometry import in IGES and DXF formats.

Companies often focus on integrating their own products rather than, or in addition to, developing interoperability


with external software offerings. For instance, Electronics Workbench, a developer of Windows®-based EDA tools, recently announced the integration of three of their own products. This integration creates a seamless design environment for the schematic capture, simulation, layout/routing, and computer-aided manufacture of PCBs. The Professional and PowerPro Suites combine Electronic Workbench's Multisim (schematic capture and SPICE/VHDL/Verilog HDL/RF simulation), Ultiboard (PCB layout), and Ultiroute (autoplacement, autorouting, and manufacturing optimization) products. The PowerPro Suite differs from the Professional Suite by offering increased functionality in terms of support for programmable logic (VHDL), co-simulation, RF design, and PCBs with up to 64 layers.



The latest version of Flomerics' FLOPACK, v3.1, generates instant, ready-to-run thermal models for a range of IC packages.

Similarly, modeling software developer, Flomerics, enables parts created within their FLOPACK software, a Web-based product for thermal modeling of IC packages, to be imported directly into Flotherm, a thermal analysis software that analyzes the cooling requirements of electronic components and systems.

Electronics design is an increasingly complex discipline requiring not only engineering expertise but also specialized software. Hence, the continued success of the EDA market, which supplies these highly specialized design environments with critical tools. Since one company can rarely provide all of the tools needed for complex electronics projects, interoperability characterizes the majority of offerings in the EDA and related software markets.



ANSYS/Multiphysics screen. A MEMS Optical grating shows structural deformation from residual stress in materials.

that will be either integrated into mixed signal ICs or multichip modules."

Simulation software provider ANSYS also establishes strategic alliances through their Enhanced Solution Partner (ESP) program, which encourages software developers to use ANSYS as a development platform for their applications. MEMSCAP, provider of MEMS-based solutions for the design and manufacture of telecommunications products, partnered with ANSYS to develop an interface between MEMSCAP products and ANSYS/Multiphysics™, which simulates complex thermal/mechanical, fluid/structural and electrostatic/structural, and a number of coupled-physics interactions.


Software Round-Up

Even outside the framework of formal partner programs, innovative prod-

Get Connected to the Companies Featured in this Article:

ALGOR, Inc.	www.algor.com
Ansoft Corp.	www.ansoft.com
ANSYS Inc.	www.ansys.com
Applied Wave Research	www.mwoffice.com
Cadence Design Systems	www.cadence.com
EDA Consortium	www.edac.org
Electronics Workbench	www.electronicworkbench.com
Flomerics Ltd.	www.flomerics.com
Fluent, Inc.	www.fluent.com
ICEM CFD Engineering	www.icemcfd.com
MEMSCAP, S.A.	www.memscap.com
Mentor Graphics Corp.	www.mentor.com

NASA Awards Inventions of the Year



NASA has chosen a Hollow Cathode Assembly and a Rotary Blood Pump as the top inventions of 2001. Researchers at Johnson Space Center in Houston, TX, received the NASA Commercial Invention of the Year for the Rotary Blood Pump Ventricular Assist Device (VAD). NASA's Government Invention of the Year Award went to a team from Glenn Research Center in Cleveland, OH, for developing both a Hollow Cathode Assembly for the International Space Station Plasma Contactor and Hollow Cathode Technology for commercial purposes. Although these innovations originated from NASA research centers, each has the ability to benefit a much wider range of industries.

Rotary Blood Pump — Ventricular Assist Device (VAD)

NASA's entry into blood pump technology began on a personal level. A NASA engineer suffering from congestive heart failure met with famed pioneer heart surgeon Dr. Michael DeBakey while receiving a heart transplant. As a result of their discussion, a team of NASA engineers and contractors was formed to apply the expertise gained in solving space exploration problems to benefit people with congestive heart failure. The partnership led to the development of the DeBakey Ventricular Assist Device (VAD), a small, lightweight, high-speed turbine pump that moves blood without damaging the delicate individual blood cells or allowing clotting of the blood — the two principle obstacles in blood pump technology.

The VAD includes a tubular housing that has an externally mounted motor


stator, an internally fixed flow straightener within its upstream section, and a diffuser fixed within its downstream section. The only moving part — a one-piece rotor that includes an inducer portion and an impeller portion — is mounted on bearings between the flow straightener and the diffuser. Magnets embedded in the vanes of the impeller form the motor rotor of the pump.

The blades of the flow straightener, inducer, impeller, and diffuser are all optimized to function together to minimize blood hemolysis. Precisely shaped entrance and outlet angles, and the transitions between them, contribute to the overall pumping efficiency, and enhance the blood-protecting character of the design. To prevent clotting of the blood in the low-flow-rate areas around the bearings, the bearing areas are configured to allow cross-linked blood to fill and seal those areas. A back electromotive force (EMF) integrated circuit regulates rotor operation and a micro-computer may be used to control one or more back EMF integrated circuits.

The implanted device is applied externally of the heart and connected to it by cannula. It assists in the pumping of blood from the lower left ventricle of the ascending aorta rather than replacing the heart's natural pumping ability. In

operation, the turbine pump is powered by batteries and has an external patient-operated controller.

The VAD is utilized in three distinct ways. Initially, it functions as a "bridge to transplant" temporary device to help the patient survive while waiting for a suitable transplant organ to become available. A second application is as a "bridge to recovery." Surgeons have discovered that with some hearts, the assistance sup-



The use of NASA computational fluid dynamics (CFD) modeling capabilities led to major design improvements in the original Ventricular Assist Device (VAD), which is pictured at the top. The improved version is shown at the bottom. Adding an inducer to the DeBakey device eliminated the dangerous back-flow of blood by increasing pressure and making flow more continuous. The device is subjected to the highest pressure around the blade tips, shown in pink. (Image courtesy of NASA/Cetin Kirlis)

plied by the VAD is sufficient to allow the natural heart to repair itself, in which case the VAD can later be removed. The third anticipated application of the VAD would be as a permanent implant.

The battery-operated pump — approximately 3 inches long, 1 inch in di-

ameter, and weighing less than four ounces — seems to be an answer to the decades-long quest to develop an implantable VAD. NASA, in keeping with its mission of transferring space-based technology to the private sector, granted exclusive rights to MicroMed Technology of Houston, TX. After extensive testing and clinical trials, the VAD became commercially available last year. This contribution will continue to be an asset to health care as more VADs are made available to more recipients, and as applications broaden to include additional uses.

The blood pump was developed in a joint effort by Bernard J. Rosenbaum, Gregory S. Aber, Richard J. Bozeman Jr., and James W. Akkerman of Johnson Space Center; Dochan Kwak and Cetin Kiris of Ames Research Center in Moffett Field, CA; Dr. Michael DeBakey and George VanDamm of the Baylor College of Medicine; James Bacak of Lockheed-Martin; Robert Benkowski of MicroMed Technology; and Paul A. Svejksky of Boeing.

For more information, see the tech brief available at: www.nasatech.com/Briefs/Oct99/MS22822.html

Hollow Cathode Assembly for the ISS Plasma Contactor

Researchers at Glenn Research Center were awarded NASA's Government Invention of the Year for developing a mission-critical, self-regulating Hollow Cathode Assembly (HCA) that controls charging on the International Space Station (ISS). The inventors also were recognized for advancing hollow cathode technology. Michael J. Patterson, Timothy R. Verhey, and George C. Soulas

were able to increase hollow cathode lifetimes from about 500 hours to 28,000 hours, enabling the use of Hall and ion propulsion current for use on NASA missions, including Deep Space 1, the ISS, and STS-92.

The HCA is the primary component of the ISS Plasma Contactor System. It also mitigates spacecraft charging by emitting electron current from low-density plasma to the electrically "ground"


between the hollow cathode and anode of the HCA. The resulting plasma is coupled to the spacecraft potential. When this plasma "sees" the ambient space plasma at a different potential, electrons stream between the two plasmas to equilibrate their potentials, controlling spacecraft charging in a self-regulating manner.

The innovators developed this technology from a laboratory device to spaceflight-qualified hardware, and also manufactured the spaceflight hardware for the ISS. The hollow cathode technology developed during this program is also used for electric space propulsion — such as ion and Hall thrusters used on commercial satellites and scientific spacecraft — and plasma sources for materials processing. The hollow cathodes utilized by these devices are used either to create ions for acceleration and/or neutralize an ion beam.

Besides the successful operation on the ISS, the hollow cathode assemblies were launched aboard STS-92 and Deep Space 1. On Deep Space 1, the hollow cathodes on the ion thruster operated flawlessly for over 16,000 hours.

NASA has entered into a joint effort with Advanced Refractory Technologies of Buffalo, NY, to develop a hollow cathode for use as an electron source in the production of diamond-like coatings to replace thermionic filament cathodes. Multiple units have been manufactured and tested at NASA's Glenn Research Center and are under integration at the industrial partners' manufacturing facilities.

For more information, see the tech brief available at www.nasatech.com/Briefs/Feb00/LEW16658.html.



The original NASA version and the commercial version of the plasma-contact hollow cathode assembly (HCA) are shown here. The commercial version preserves the technological heritage of the original NASA version, but can be mass-produced at lower cost.

ISS to near-space plasma potential. Early testing and prior flight experience indicated that the high voltages and exposed conducting surfaces across the ISS's solar arrays could cause the station structure to charge to a significant negative potential relative to the ambient space plasma. Since the ISS structure is electrically tied to the solar arrays, this charging could lead to arcing, damaging critical spacecraft surfaces.

The HCA alleviates spacecraft charge build-up by emitting electrons collected by the solar arrays. A discharge is ignited

Seven other inventions were nominated in the 2001 competition:

- Ames Research Center developed a method and system for an automated tool for en route traffic controllers. The innovation is an optimization algorithm that predicts flight path, minimizing time between points without possible collision.
- A parallel-integrated frame synchronizer chip was manufactured at Goddard Space Flight Center in Greenbelt, MD, reducing the cost of workstations and the backlog of unprocessed science data from the Terra spacecraft. A computer-implemented empirical mode decomposition method, apparatus, and article for manufacture also were developed at Goddard, providing more efficient filtering of a signal from noise for non-linear, non-stationary data.
- Langley Research Center in Hampton, VA, developed a high-temperature polyimide resin system — an environmentally friendly alternative to a common temperature matrix resin, offering use in applications requiring a high-temperature, lightweight, high-strength material. Also developed

at Langley was a method and apparatus for the portable identification of material thickness of layers using a scanning heat source and infrared detector.

- From Glenn Research Center came silicon/mullite/BSAS environmental barrier coatings, providing long-term protection from attack by water vapor and molten salts in combustion environments.
- An infector for liquid-fueled rocket engines was developed at Marshall Space Flight Center in Huntsville, AL. The invention produces low static pressure variations in the flow passages, providing uniform propellant injection.

NASA's Government and Commercial Inventions of the Year are selected by NASA's General Counsel and the Inventions and Contributions Board (ICB). For detailed information on all the winners and nominees for 2001, visit the ICB Web site at: <http://icb.nasa.gov/IOY2001>.

Application Briefs

E-business Platform Helps NASA Streamline Financial Management

mySAP.com e-business management platform
SAP Public Services
Washington, DC
888-727-1993
www.sap.com/usa/publicservices

To streamline NASA's business processes, the agency's Integrated Financial Management (IFM) Program utilized mySAP.com®, an e-business platform designed to increase operational effectiveness. IFM is the organization aimed at improving NASA's financial, physical, and human resources management processes. The IFM Program team has conducted demonstration testing on relevant mySAP.com solutions, such as those designed for human resources,

budget planning formulation, and product lifecycle management.

Recently, NASA purchased an additional 12,600 licenses for the mySAP.com suite, doubling the number of users. SAP solutions will help meet the agency's user requirements for the remaining NASA IFM Program modules — specifically, budget planning and formulation; integrated asset management including logistics, facilities, environmental and aircraft; and human resources and payroll.

"With the tightly integrated solutions of SAP, NASA will have consistent cross-agency processes, informed by best practices, that will allow us to access and assemble vital information quickly and effectively," said Mike Mann, program manager of NASA's IFM Program. A combined team of NASA and SAP employees are implementing the platform at Marshall Space Flight Center in Alabama and will extend the system to the remaining centers upon completion.

For Free Info Circle No. 711 or Visit www.nasatech.com/sap

Tensioners Hold Shuttle Arm in Place During ISS Launch

Superbolt® Multi-Jackbolt tensioners
Superbolt
Carnegie, PA
800-345-BOLT
www.superbolt.com


Part of Canada's investment in the International Space Station (ISS) program is the Canadarm2, an advanced version of the shuttle's robotic arm. Unlike the original Canadarm, which is mounted just outside a shuttle's payload bay, each end of Canadarm2 has a hand that can grasp an anchor on the ISS. By flipping end-over-end between anchor points, Canadarm2 can move around the ISS like an inchworm. To install the robotic arm for use on the ISS, Superbolt Multi-Jackbolt tensioners were used on eight bolts to hold Canadarm2 in place during launch.

The tensioners are designed to replace conventional hex nuts, covered nuts, and bolts. They were chosen because they are simple to remove with hand tools and were able to achieve the bolt preloads required for the launch. This is an important consideration in keeping space-walking astronauts safe and reducing the launch weight since no heavy tooling is required.

Canadarm2 was carried to the ISS via the Space Shuttle Endeavour. Once in orbit, astronauts left the shuttle and


removed the eight tensioners, allowing Canadarm2 to be unfolded and positioned for installation.

For Free Info Circle No. 712 or Visit www.nasatech.com/superbolt





No Matter What You Test, Do It With Dewetron!



Our customers are testing everything from train cars to the Space Shuttle, from automobile airbags to oilwells...and the list keeps growing. Why? Maybe it's our plug-in signal conditioners that allow connection of *any signal, any sensor*. Or perhaps it's the fact that Dewetron systems are built on an open-architecture, COTS* computer platform, allowing easy upgrades and compatibility with all Windows® software and hardware.

Or it could be our software—so easy to use and yet so powerful—with brilliant on-line displays, full-color printing and one-click export to Excel®, MatLab®, ASCII, and several other popular formats. Of course, Dewetron machines are perfect platforms for LabVIEW® development, and they already include a National Instruments® A/D card connected to our high-isolation plug-in signal conditioners!

Above left to right – the DEWE-4000, DEWE-2010, and DEWE-3010 portable PC Instruments

Our basic models are also highly popular as portable industrial computers built to MIL-STD-810C for shock and vibration.

It could be any of these things - or maybe it's all of them. The bottom line is, if you're doing data acquisition any other way, you're missing a lot. Please take a look at Dewetron today. Start with our website, or give us a call and arrange a no-obligation demonstration at your facility.

Contact us today toll-free at **877-431-5166** (+1 401-364-9464 outside the USA), or visit us on-line at **www.dewamerica.com/ntb**



Plug-in signal conditioners for every signal, every sensor



Just need a front-end? Check out our DEWE-RACK and DEWE-BOOK solutions for your notebook computer!



*COTS = Commercial, off-the-shelf.

For Free Info Circle No. 520 or Enter No. 520 at www.nasatech.com/rs



Remote Monitoring and Alarm System

John F. Kennedy Space Center, Florida

The Remote Monitoring and Alarm System (RMAS) is a system of electronic hardware and software for monitoring of fiber-optic video transmission equipment at Kennedy Space Center (KSC). The RMAS could also monitor other equipment that generates discrete contact closures and/or analog voltages. The hardware includes multiple remote terminal units (RTUs) that are collocated with, and gather both discrete and analog information from, the monitored equipment, and convert this information to RS-232 data streams. The RTUs are connected via point-to-point long-haul modem circuits to a 96-port code-

activated switch (CAS), that, in turn, connects specific RTUs to a monitoring computer workstation. Polling software running on the workstation periodically gathers data from each RTU and stores the data for processing by network-management software, which also runs on the workstation. The network-management software analyzes the data to generate a graphical representation of the fiber-optic video transmission equipment, with indications of any alarm conditions. Each RTU contains custom firmware that governs communication with the polling software and that, upon command by a user, implements diag-

nostic routines. A Simple Network Management Protocol agent links the polling software to the network-manager software via a custom management information base.

This work was done by Philip Gvozdz, Matthew Smisor, and William Toler of Kennedy Space Center and Chris Keros, Robert Chiodini, Pamela K. Schmidt, and Robert Swindle of Dynacs, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. KSC-12314

Failure-Reporting Device Concept for Spacecraft and Remote Vehicles

Unlike aircraft "black boxes," these devices would transmit information to remote receivers.

NASA's Jet Propulsion Laboratory, Pasadena, California

Failure-reporting devices somewhat similar to the "black box" data recorders on aircraft have been proposed. These devices were conceived for use on spacecraft, but might also be useful on terrestrial autonomous underwater vessels or terrestrial remote exploratory robots. The concept was motivated by the need to learn from mission failures in order to make future missions more failure resistant.

Even more than aircraft "black boxes," the proposed devices would be extremely rugged to survive re-entry into the atmosphere of the Earth as well as impacts substantially harder than those of airplane crashes. Unlike aircraft "black boxes," the proposed devices would not be designed to be retrieved; instead, they would be designed to transmit as much pertinent information as possible to enable analysis to identify specific causes of mission failures.

The design of the proposed devices would follow a "spacecraft within a spacecraft" approach. The device would contain data-handling, telecommunication, power-supply, and structural subsystems. The primary interfaces between

this system and the spacecraft would be power connections and points of access to the spacecraft data bus and/or the spacecraft telemetry-management system. The links between the failure-reporting device and the spacecraft would be subject to severance at any time. However, even while the spacecraft remained intact and functional with the device connected, the device would transmit subcarrier beacon tones that would convey information on the status of the spacecraft during high-risk maneuvers like entry, descent, and landing.

Upon separation from the spacecraft, the device would stop drawing power from the spacecraft power supply and start drawing power from an internal battery. Once separated from the spacecraft, the device would automatically begin transmitting relevant data back to Earth ground stations and/or nearby orbiting spacecraft. A flight-qualified data processor would run the software necessary to record channelized data, set the beacon state, and execute other functions like those of an aircraft "black box." The level of data processing would

depend on the degree to which the data received by the device were summarized and otherwise preprocessed by the spacecraft data-processing system. The most important data would be stored (most likely in a solid-state memory) aboard the device for transmission.

The telecommunications and software subsystem of the device would generate low-rate telemetry signals to transmit stored engineering data. If possible within the processing constraints, summarization software would transmit the most relevant sensor data recorded around the time of the failure. The subcarrier signals could be programmed to correspond to spacecraft failure modes and would provide some indication of status in the event that acquisition of telemetry was not possible.

This work was done by E. Jay Wyatt and John Szijarto of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. NPO-20942

Digital

Solid State Recorder



Compact • Ruggedized 50 GB Airborne Data Recorder

80% less weight*
90% less power*
75% less space*
30% less cost*

*Compared to AMPEX DCRsi™ 240

Low power, 50 watts: 28VDC
Compact - 8 lbs; 8.7" x 6" x 3.75"
High Speed: 480Mbits/sec total transfer rate
Modular storage, easy upgrade - 32 PCMCIA cards

For airborne flight test digital data recording
Digital imagery recording for tactical weapons pods such as LANTIRN and TARPS
Integration into high resolution sensor packages for direct digital recording

If it's worth a mission, it's worth a

TEAC®

www.teac-recorders.com

Tel. 323-727-4866 • Fax: 323-727-4877
e-mail: airborne@teac.com

© 2002 TEAC America, Inc. All trademarks are property of their respective companies.

For Free Info Circle No. 505 or Enter No. 505 at www.nasatech.com/rs

Program Uses Terrain-Image Data To Locate Safe Landing Site

NASA's Jet Propulsion Laboratory, Pasadena, California

A computer program under continuing development strives to locate a safe landing site for a spacecraft through real-time processing of image data acquired by a video camera aimed at the terrain below while the spacecraft descends. The program might also be useful for aiding the selection of a landing site for an unpiloted helicopter or other unpiloted aircraft capable of slow vertical or nearly vertical descent. The program implements

two main algorithms: a texture-based landing-site-selection algorithm and a landing-site slope-estimation algorithm. The texture-based algorithm analyzes spatial variations in image brightness to identify candidate sites that are acceptably smooth and free of large rocks. The slope-estimation algorithm computes the slope on the basis of the perspective relationships between two images of the same terrain area acquired from successive po-

sitions along the descent trajectory. Because the slope is a very important factor for safe landing and for mobility of a robotic exploratory ground vehicle to be deployed from the spacecraft after landing, the slope-estimation algorithm includes an error-analysis subalgorithm.

This program was written by Yang Cheng, Andrew Johnson, Larry Matthies, and Aron Wolf of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.


This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-30268.

Data Is Cheap. Answers Are Priceless.

Experience IDL

Visit our Web site and receive an "Image Processing With IDL" technical paper free.

www.rsinc.com/exp
or call 303.786.9900



Radar-mapped data of Venus shown using IDL's Show3 technique.

From Data To Answers Get There Faster With IDL

- Create custom applications with far fewer lines of code than traditional languages.
- Get more from your data faster with IDL's powerful interactive visualizations.
- Develop cross platform applications in a single environment.

IDL

www.rsinc.com/exp 303.786.9900
United States • United Kingdom • France • Italy
IDL is a registered trademark of Research Systems, Inc.

**RESEARCH
SYSTEMS**
A Kodak Company

Measuring Sea Height and Roughness With GPS Reflections

Dense and rapid coverage would enable new oceanographic applications.

NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed technique of bistatic radar altimetry would utilize information available in Global Positioning System (GPS) signals reflected from the ocean surface. The signals would be monitored by an airborne or spaceborne receiver and would be processed to determine the height, roughness, and possibly other properties of the surface. An important advantage of the proposed technique would be density and rapidity of coverage: Whereas a traditional nadir-looking radar altimeter gives the surface height at only one location below the altimeter, a receiver implementing the proposed technique could track about 10 GPS reflections simultaneously. Such dense coverage could translate to spatial and temporal resolutions greater than those previously achievable, and hence the ability to study ocean-topography features or processes beyond the reach of prior techniques. Potential applications could include monitoring of

**From concept
to design
to mold
to mountain.**



**VX gives designers
the competitive edge.**

**Design
through manufacturing**

with no stops. The biggest challenge

faced by leading-edge ski binding manufacturer Fritschi is translating its sophisticated designs and high-tech materials into a manufacturable, performance-tested product. That's why

they rely on VX CAD/CAM to

design their entire product line. VX

gives Fritschi a single, powerful, fully-inte-

grated design through manufacturing solution, including superior freeform surfacing, mold design, and manufacturing planning. If Fritschi can imagine it, they can take it right to the mountain with VX.

Premium performance without the

premium price. Because it comes loaded with high performance

features at a sensible price,



VX delivers the most bang for the buck of any system.

Alias®-style modeling, photo realistic rendering, limitless

undo/redo, you name it. Plus, the ability to import legacy data and the highest level of interoperability on the market (STEP, IGES, Parasolid®, CATIA®, Pro/E®, AutoCAD®).

Learn to fly. See for yourself how VX's flexibility and ease of use can help your teams fly through projects all the way to manufacturing without losing design integrity.

Contact us for a FREE demo today.



VX® Shaping the future of CAD/CAM™

V → concept → aesthetic design → mechanical design → manufacturing engineering → X

VX.COM 321-676-3222 sales@VX.COM

©2002, VX Corporation. VX and the VX logo are registered trademarks of VX Corporation. All others are the property of their respective owners.

For Free Info Circle No. 526 or Enter No. 526 at www.nasatech.com/rs

eddies and tides and tracking of fast barotropic waves.

The proposed technique is an extended version of the cross-correlation

process used to extract time and position information from direct GPS signals. The extension to the reflected-signal case involves consideration of


numerous factors, including the field of view and pointing direction of the receiving antenna, the angle of scattering of each affected GPS signal, the direction of the plane of incidence of the GPS signal relative to the velocity of the spacecraft or aircraft carrying the receiver, and the integration time of the receiver.

One function of particular importance for the mathematical foundation of the technique is the derivative of the correlation function (DCF) with respect to the model time delay. This function exhibits a sharp peak (see figure), the shape of which is affected in known ways by the wind speed and by surface-roughness statistics. Hence, in principle, one should be able to extract important sea-state parameters from the DCF. These parameters are, specifically, (1) the mean sea height (derived from knowledge of the location of the DCF peak relative to the model

delay), (2) the ocean-surface wind (derived from the height of the DCF peak), and (3) the significant wave height (derived from the width of the DCF).

The effects of the ionosphere, troposphere, and clock errors on the accuracy of the technique have been estimated, and an overall root-mean-square value of range accuracy has been predicted as a function of sea state and antenna gain. It has been found that when one averages many measurements collected from a possible constellation of receivers, the range error would be progressively reduced as a function of space and time, yielding predicted accuracies in estimated sea height with associated spatial and temporal resolutions. Preliminary calculations indicate that sea-height accuracies of a few cm on spatial scales of 100 km from measurements averaged over four days could be achievable.

The effect of wind speed and significant wave height on the received signal has been examined by computational simulation for realistic ranges of wind speeds and wave heights. The bistatic geometry has been found to make the sea-height measurements less sensitive to wave heights than are the sea-height measurements of conventional nadir-



The Derivative of the Correlation Function with respect to delay time yields information on three sea-state parameters, as described in the text. The unit of delay time is one repetition period ("chip") of the GPS pseudonoise code — a period = 0.1 second.

Tackle tough DSP & Data Acquisition jobs with Conejo!

Conejo DSP board with C6711 DSP and 4 independent channels of 10MHZ analog I/O.

Features

- ▶ Ultra-Flexible Triggering Modes
- ▶ Blazingly Fast 64-bit PCI Bus
- ▶ 150 MHz TMS320C6711 DSP
- ▶ 4 Independent I/O channels DC-10MHz
- ▶ Multiboard Synchronization

Applications

- ▶ Wireless IP Development & Hardware Testing
- ▶ Ultra-Fast Flexible Data Acquisition
- ▶ Stimulus/Response Measurements
- ▶ Semiconductor Testing
- ▶ RADAR
- ▶ Electronic Warfare

Conejo




805.520.3300 phone • www.innovative-dsp.com

Innovative Integration
... real time solutions!

Demand more from your Ion Gauge Controller

- 1000 Torr to UHV range
- 0.3% controller accuracy
- Bayard-Alpert gauge compatible
- Pressure vs. time curves
- 4 analog input/output ports
- RS-232 interface
- 8 process control channels (opt)
- GPIB and Web interfaces (opt)



\$1495 (U.S. list)


The IGC100 is much more than a conventional ion gauge controller. Not only does it monitor pressure from up to two ionization gauges, two convection enhanced Pirani gauges and four capacitance manometers, but it also has many useful features that have never been available before in a controller.

We've added a touchscreen display that can show pressure vs. time curves so you can closely monitor the behavior of your chamber. Also included are eight process control channels and four analog I/O ports for automated system control.

The IGC100 is accurate to 0.3% and we offer NIST traceable gauge calibration at a very reasonable price.



Best of all, the IGC100 is fully web-ready! All you need is a computer, your favorite browser and a network connection, and you can access your controller from anywhere in the world.



Stanford Research Systems

Phone: (408) 744-9040 • Fax: (408) 744-9049 • email: info@thinkSRS.com • www.thinkSRS.com

For Free Info Circle No. 528 or Enter No. 528 at www.nasatech.com/rs

viewing geometry. The electromagnetic bias of the scattered waveform has also been found to be reduced. The range accuracy versus receiving-antenna gain and scattering direction were also examined; it was found that at low elevation angles, both the scattering cross section and the coherence time are greater than

those at nadir, resulting in a potential decrease of the range error for a fixed antenna gain. Finally, the possibility of tracking the phase of the GPS signal at small elevation angles and the resulting improvement in the range-measurement accuracy has also been examined theoretically.

This work was done by Cinzia Zuffada, George Hajj, and J. Brooks Thomas of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Information Sciences category. NPO-20943

Hybrid Electric-Field Sensor

John F. Kennedy Space Center, Florida

The hybrid electric-field sensor (HEFS) has been proposed for measuring quasi-static electric fields — especially those associated with thunderstorms. The HEFS would combine the relative compactness, low cost, and low power consumption of prior induction-probe-type electric-field sensors with the higher sensitivity of the prior field-mill-type electric-field sensors. The HEFS design would utilize a chopping-electrostatic-shield feature of a field mill over two insulated antennas to overcome the finite time constant and the poor upper frequency response of

the induction probe and the electric field mill, respectively. The HEFS would be modular in order to accommodate "smart" data-acquisition and communication ports for operation as a battery-powered, stand-alone unit. Optionally, the HEFS could incorporate a barometer, thermometer, and hygrometer, so that it could serve as a portable meteorological station. A network of such stations could transmit digitized measurement data to a central monitoring station. The estimated cost of an HEFS, including communication circuitry, is \$1,000 (based on

prices as of year 2001). In contrast, a field mill costs about \$10,000. Moreover, unlike a field mill, an HEFS would consume little enough power that it could be powered by a solar power system backed by rechargeable batteries.

This work was done by Carlos T. Mata of Dynacs, Inc., for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category. KSC-12317




Data acquisition for both sides of your brain.

FLUKE®

Get unyielding lab precision and rugged industrial flexibility in a single solution with the Fluke 2680 Series.

The new Fluke 2680 Series data acquisition system offers steady, unyielding three sigma measurement accuracy for meticulous lab work, and the rugged flexibility to apply "out of the box" problem-solving to changing industrial applications. It's the right choice anywhere you need precision temperature and other measurements, with these unique capabilities:

- **Standalone or networked models.** Run one standalone chassis with 20 to 120 universal inputs or connect several chassis to serve up to 2,000+ channels on your network.
- **Versatility.** Choose from multiple speed and scan selections, high isolation versions, intersystem math channels, and removable Universal Input Modules.
- **Powerful, easy-to-use software** for configuration and basic trending, with optional OPC and a powerful HMI development system.



Whichever side of your brain you use most, the Fluke 2680 Series helps you come out ahead. Call 1-800-44-FLUKE today for more information or visit our web site at www.fluke.com.

Fluke. Keeping your world up and running.

©2002 Fluke Corporation. All rights reserved. www.fluke.com Ad No. 01512


PCI & CompactPCI Plug-In Data Acquisition

From
\$295

Now with
Linux & ActiveX
Support!

The New DaqBoard/2000™ series of PCI & CompactPCI data acquisition boards is packed with features that other boards can't match, at any price!

- 16-bit/200-kHz sampling
- Synchronous scanning of analog, digital, & frequency I/O
- Analog input expansion up to 256 channels, 40 DBK™ signal conditioning options for direct measurement of thermocouples, RTDs, strain gages, accelerometers, & more
- Digital I/O expandable up to 208 channels, including isolation & relay options
- New ActiveX/COM-based rapid application development tools, including network support
- 100% digital calibration on all ranges
- 16-bit/100-kHz analog waveform & digital pattern generation with infinite waveform/buffer depth
- Drivers for Windows® 95/98/2000/NT/XP plus support for LabVIEW®, TestPoint®, DASyLab®, & Linux.



www.iotech.com/plug-in



Iotech Inc
25971 Cannon Rd
Cleveland OH 44146
1 440 439 4091
Fax 1 440 439 4093
sales@iotech.com

1 888 942 6678



Ethernet-Based Distributed I/O

Iotech's new PointScan™ series of 30+ Ethernet-based distributed I/O includes built-in Ethernet and RS-485. Unlike other suppliers, there's no need to purchase expensive communication modules.

PointScan modules work with any OPC-based software application. There's also a seamless, high-performance link to Citect® HMI/SCADA software.

Ethernet



- Over 40 analog and digital I/O modules
- 8-channel "universal" input module measures V, mV, TC, or mA per channel
- 16-bit analog I/O with $\pm 0.02\%$ accuracy
- 500 VDC isolation for industrial digital I/O modules
- -30°C to +70°C operating temperature
- Hot swap for easy maintenance and zero down-time
- FREE and easy-to-use I/O module configuration and test software
- Modbus RTU/ASCII and Modbus/TCP "open" protocols

www.iotech.com/pointscan

1 888 942 6678



Data

P O R T A B L E

Acquisition

IOtech offers the widest variety of portable data acquisition and signal conditioning solutions. Our portable products support battery or AC line operation, and include **Out-of-the-Box™** software so that you are

up-and-running within minutes of attaching your signals. We also provide comprehensive support for all popular programming environments, including LabVIEW®, DASyLab®, C++, Visual Basic®, and more.

Add our vehicle network interface (DBK70™) to any of the products below to measure vehicle network parameters concurrent with analog transducer measurements.

USB

Directly attach up to 80 channels of TC's, voltage, frequency, and digital I/O to the USB-based **Personal Daq™**.



High-Speed

Measure up to 72 channels of vibration, sound, strain, and much more with the 16-bit/1-MHz **WaveBook/516™**.




Stand-Alone

PC-Card memory stores your program and acquired data with the stand-alone, 16-bit/100-kHz **LogBook/300™**.



Multifunction

Over 30 signal conditioning options make the 16-bit/100-kHz **DaqBook/260™** the most versatile PC-based data acquisition device available.




Vehicle Network

Acquire vehicle network parameters for CAN, J1850, ISO-9141, J1939, and more, using the **DBK70™** along with any of IOtech's portable products in this ad.



Sound & Vibration Analysis

Real-time frequency- and time-domain waveform analysis is easy with the 4- to 16-channel **ZonicBook™**.



www.iotech.com/portable

1 888 942 6678



©Copyright 2002, IOtech, Inc. DaqBook, DBK70, LogBook, Out-of-the-Box, Personal Daq, Wavebook, & ZonicBook are trademarks of IOtech, Inc. All others are trademarks or registered trademarks of their respective holders. For a complete listing of IOtech worldwide sales offices, see www.iotech.com/sales.html. 020303.




IOtech Inc.
25971 Cannon Rd
Cleveland OH 44146
1 440 439 4091
Fax 1 440 439 4093
sales@iotech.com



PHOTONICS

Tech Briefs

PHOTONICS SOLUTIONS FOR THE DESIGN ENGINEER



Digital Genomics	11a
Product Guide: Raman Spectrometers.....	4a
Technologies of the Month	8a
Microcavity Device for Measuring Direction of a Laser Beacon	10a
Fabricating Sapphire Optical Fibers for High-Temperature Use.....	11a
Etching Mirror Facets on SOI Optical Waveguides.....	12a
Improved Array of Switches for Fiber-Optic Communications	13a
New Products	14a

Cover photo courtesy of Spectra-Physics, see page 14a

www.ptbmagazine.com

Digital Genomics

An imaging-based approach challenges a traditional scanning method for simultaneous analysis of multiple genes.

Traditional biology has centered on the study of a single gene, that is, the attempt to identify all the factors that regulate the activity level of a particular gene. This approach has been painstakingly slow, but very rewarding in terms of obtaining specific information about the gene being studied. With the announcement that the entire sequence of the human genome has been identified, the rush is on to utilize the vast amount of information now available.

There are an estimated 80,000 to 100,000 unique genes encoded within the human genome and in order to determine the various functions of all of these genes, scientists are actively developing methods to analyze many of them in parallel. This task makes numerous new and interesting experiments possible, like identifying all the genes that are changed in response to a biologically active molecule such as a hormone or a drug.

While much of the early work in this area has relied on data-collection methods that employ serial scanning, new protocols based on digital imaging are now proving highly successful. Recent advances in electronics technology and new methods of high-volume manufacturing are making it possible for

builders of microarray scanners to affordably integrate advanced CCD imagers as components in their systems. On a smaller scale, it is even possible for individual researchers to use currently available camera systems for microarray imaging experiments in their own laboratories.

Measurement of Gene Activity

In order to measure a gene's activity, scientists collect the messenger RNA (mRNA), which carries information from the gene in the nucleus to the cytoplasm, where it is usually translated into a protein product. When the RNA from a cell population or tissue is collected, this preparation is typically converted into copy DNA (cDNA) and then amplified with the polymerase chain reaction (PCR). A sample of the amplified cDNA product can be labeled with fluorescent tags to allow that population to be identified.

Typically, the researcher uses two populations of cells: one representing the control and one representing the experimental treatment. As an example, a cultured cell line's response to insulin can be measured by preparing two cell populations: one treated with


insulin and one mock treated. The RNA from the insulin-treated cells can be labeled with Fluor 1 (green color) and the RNA from the control cells can be labeled with Fluor 2 (red color). These probes can then be used to interrogate a microarray of immobilized DNA targets on a glass surface, where each (x,y) coordinate represents a known DNA sequence.

When the green and red probes are hybridized to the array, the composite color is a measure of the gene activity ratio. A green color would indicate a gene that is on with insulin treatment and off when insulin is absent. A red color would indicate a gene that is on when insulin is absent and off with insulin treatment. A yellow color would indicate a gene that does not change significantly with insulin treatment.

Basic Analytical Approaches

Once the arrays have been hybridized and washed under the appropriate stringency conditions, the user needs to read the arrays at two different wavelengths of interest. The wavelengths used are usually in the red region of the spectrum to reduce auto-fluorescence from the system. The most commonly used labels for

The Company with Vision is in Motion



Integrate your machine vision with motion and measurements

Increase production cycles and lower test costs using an integrated National Instruments platform with vision, motion control, and measurement solutions. Perform precision alignment, automated inspection, precision assembly, and more.

Easy integration

Integration is easier with a high-speed, synchronized bus; platform choices that include PCI, PXI™/CompactPCI™, and IEEE 1394; and development tools such as LabVIEW™, Measurement Studio™, and TestStand™.

ni.com/info

For more information on leading manufacturers who increased production cycles, visit ni.com/info and enter nakn08.



(800) 811-0742

Fax: (512) 683-9300 • info@ni.com

microarray experiments are Cy3 and Cy5, depicted as green and red, respectively. Two basic approaches can be utilized to measure these signals: serial scanning or imaging.

In the serial scanning approach, a confocal fluorescent scanning device collects data serially using a common optical pathway for delivering the excitation beam and for collecting the emission beam. The fluorescent signal is measured by a photomultiplier tube and digitized to generate the output intensity at each spot on the microarray. After the first fluorescent channel has been measured, the optics are switched and the second channel is then measured.

In the imaging approach, a wide-field illumination scheme is utilized to achieve parallel excitation on most or all of the microarray. Similarly, the imaging of the whole array then occurs in parallel with an exposure time chosen to obtain the best signal-to-noise in the data. A camera digitizes the data and all of the digital data is delivered to the computer in an image format. For the second wavelength, the optics will need to be changed and another exposure taken.


Scanning Vs. Imaging

So which is the better method for analyzing this kind of data? Right now, the majority of the microarray scanners on the market employ the serial scanning approach. This is due to the simplicity of design of a system that uses a laser for illumination coupled with a PMT for a detector. In terms of performance, however, there are distinct advantages to moving to an imaging-based approach.

For example, in selecting laser lines for illumination in serial scanners, the fluorescent probes become confined to those whose excitation spectrum is sufficiently overlapped with the laser line to be useful. In the imaging approach, broadband emitters like xenon (Xe) or mercury (Hg) can be used to generate an almost continuous usable spectrum of illumination light.

Furthermore, by using a CCD-type detector to measure the fluorescence signals, an imaging device can achieve quantum efficiencies on the order of 90% — versus the 15-20% QE obtainable with a PMT-type device. This difference translates into a sensitivity advantage of up to sixfold! The CCDs can also be run with very low-noise analog electronics to achieve a readout noise lower than 4 e⁻ rms, whereas the PMTs can have noise terms that are significantly higher.

Another key advantage of the imaging-based approach is the highly paral-



Microarray image showing typical differences in gene expression levels. Image courtesy of Roper Scientific, Inc.

lel nature of the data collection. If the user needs to collect 5,000 data points in one experiment and 20,000 in another, the scanning approach will require four times longer for the second experiment than the first. In an optimized imaging experiment, both measurements will be under identical exposure conditions and so the time will be equal. As the number of elements in an array increases, the advantage of imaging over serial scanning becomes more pronounced.


Conversely, one of the arguments in favor of serial scanners over imaging devices is the former's ability to achieve a larger number of effective pixels. This ability is useful for the currently accepted standard of measuring each 100-micron DNA spot with a 10 × 10-pixel array, a practice that yields 70-80 (on average) individual valid measurements within the circular spot. The rationale for obtaining this highly oversampled data is that it enables the interpreting software to derive detailed statistics on the variation from spot to spot as well as to use this information to qualify the quality of the data in the spot. While this method does indeed give the software a good idea of the uniformity of

the distribution of the signal across the spot, it really does not address the core issue of whether or not the data is useful or quantitative.

In all biology, the standard manner to ensure the usefulness or validity of the data is the replicate method. Every biochemical assay is done in at least triplicate. Every plate-based assay is done in at least duplicate. The variation across replicates or triplicates is defined by the coefficient of variation; this number places a boundary on the usefulness of the data. The same principle should be applied in the microarray field, that is, all spots should be represented at least twice on each microarray and these spots should not be in the same region of the array. This approach eliminates the need for the high level of oversampling employed with serial scanning. Under these conditions, the finite number of pixels on the CCD is no longer a limiting factor.

This article was written by Mark Christenson, Ph.D., Senior Scientist, and Jeff Grant, Senior Technical Writer, at Roper Scientific, Inc. The authors can be reached at mchristenson@roperscientific.com and jgrant@roperscientific.com. Learn more about Roper Scientific at www.roperscientific.com.

What Color Laser Light do You Want?



That's right ... pick the color of laser light you need. We make it easy for you by providing low cost laser light from UV through IR for OEM and research applications.

COLORS. Select a nitrogen laser for 337 nm in the UV or a CO₂ laser for 9.3, 9.6, 10.3, or 10.6 μ m in the IR. For tunable laser light from 360 nm in the blue out to 950 nm in the near-IR, pick one of our dye lasers pumped with one of our nitrogen lasers.

EASE. To use our lasers, just plug them in and turn them on. The nitrogen and CO₂ lasers have sealed plasma cartridges so there is no flowing gas or circulating coolant, and the dyes are contained in sealed cuvettes so you don't have to pump messy dye solutions through your system.

YOUR NEEDS. Talk to us about the color of laser light you need and what you want to do with it. We would love to help. **Call Thermo Laser Science at 508-553-2353 or visit www.laserscience.com.**

Product Guide: Raman Spectrometers

Utilized in a variety of industries and applications, Raman spectroscopy is a technique that continues to gain in popularity. The evolution of enabling technologies such as laser diodes and detectors combined with minimal need for sample preparation has contributed to this acceptance.

By shining a laser on a sample and detecting the scattered light, Raman spectrometers allow for qualitative and quantitative analysis of materials. Applications exist in semiconductor, pharmaceutical, quality control, and research industries, for example.

Raman spectroscopy is complementary to infrared absorption spectroscopy — some instruments even combine

the two functions into one device. It also offers advantages. Raman analysis allows measurements to be made through transparent structures such as glass vials or by using fiber-optic probes. Raman also simplifies the analysis of aqueous samples by eliminating the need for special preparation and accessories.

Arranged alphabetically by company, the featured products are representative of available offerings and may not include all of the Raman technologies manufactured by each company. Additional information should be obtained directly from the manufacturer.

ABB BOMEM INC. Québec, Canada www.bomem.com

MB157S: Combined FT-IR/ FT-Raman



Spectral Range: 12,000 - 450 cm^{-1}
Raman Range: 150 cm^{-1} - 3,500 cm^{-1}
Laser: 1,064 nm YAG laser
Detector: MIR-NIR DTGS/FT-Raman
Dimensions: 20" x 22.25" x 12"
Features: Used for combined FT-IR/FT-Raman applications, especially to minimize fluorescence problems, the MB157S includes Windows™-based data processing and analysis software and the Arid-Zone™ sample compartment for rapid purge and easy sample loading.

ACTION RESEARCH Acton, MA www.action-research.com

SpectraPro® 300i: Imaging Monochromator/Spectrograph



Focal Length: 300 mm
Resolution: 0.1 nm @ 435.8 nm, 10 μm slits
Detector: CCD
Dimensions: 13.25" x 10" x 8", 35 lbs.
Features: Suitable for Raman, fluorescence, emission, and absorption/trans-

mission applications, the SpectraPro 300i is an f/4-aperture, triple-grating monochromator and spectrograph featuring dual exit ports, a 14 x 27 mm focal plane, and an imaging optical system designed for multi-channel CCD spectroscopy. Also available is the SpectraPro 500i with a focal length of 500 mm, an f/6.5-aperture, and resolution of 0.05 nm @ 435.8 nm.

InSpectrum™: Integrated CCD Spectrometer

Nominal Resolution: better than 3 pixels over 6mm height @ 435 nm (1200 g/mm grating)
Detector: CCD
Dimensions: 297 x 492 x 211 mm
Features: This spectroscopy system incorporates a research-grade, thermoelectrically cooled CCD detector inside a 300-mm f/4 imaging spectrograph in a compact and rugged package. A single USB cable interfaces any desktop or portable computer running Windows® 98/2000. Acton Research SpectraSense™ software provides full control of automated features, real-time spectral processing, and on-the-fly chemometrics. OEM & 150 mm versions are available.

BRUKER OPTICS Billerica, MA www.brukeroptics.com

RFS 100/S: Stand-Alone FT-Raman

Spectral Range: 3,600 - 70 cm^{-1}
Laser: diode-pumped Nd:YAG
Detector: InGaAs or Ge
Features: The RFS 100/s laser source is controlled completely through software. Solid, liquid, and gaseous samples are measured in the large sample compartment using a variety of included sample holders. Equipped with a broad-range quartz beamsplitter, the patented frictionless interferometer with ROCK-SOLID™ alignment provides high sensi-

tivity and stability. Options include a second excitation laser port and two fiber-optic coupling ports for the RAMANSOPE™ and Ramprobe.

FRA 106/S: Dual IR-Raman

The components used in the FRA106/S are identical to those in the RFS 100/S (see previous listing). This FT-Raman module is suitable for users requiring both IR and Raman capabilities. The FRA 106/S can be attached to several of Bruker's FT-IR spectrometers providing a FT-IR/FT-Raman solution.

INPHOTONICS Norwood, MA www.inphotonics.com

RS2000: High Resolution Raman

Spectral Resolution/Range: 1 cm^{-1} from 200 - 3,500 cm^{-1}
Laser: 50mW, 532 nm Nd:YAG or 300mW, 785 nm diode laser
Detector: 3-stage TE-cooled CCD array
Dimensions: 26" x 16" x 8", 55 lbs.
Features: The RS2000's lens-based optics are matched to a fiber-optic input, providing 1:1 imaging at the focal plane and eliminating the need for entrance slits. The RS2000 includes InPhotonics' data acquisition package and GRAMS/32® manipulation software operating on a standard PC data station.

InPhotote™ : Portable Raman



Spectral Resolution/Range: 4-6 cm^{-1} from 200 - 1,800 cm^{-1}

A little small talk about micro displays.



Micro Display Coatings for every industry.

Optical Coatings. From head mounted displays, to projectors and HDTVs, ZC&R coatings are nothing short of brilliant. We understand the need for precision quality and the importance it can play in the performance of your display products. From AR to ITO, our quality will have a big impact on your micro displays. Call us at 800-426-2864 or visit our web site to see all we can offer. Quality coatings for micro displays. It's not a small matter to us.

zcrcoatings.com



ISO 9002 • AS 9000
Registered

1401 Abalone Ave. / Torrance, CA 90501 / 310-381-3060 / 800-426-2864 / FAX: 310-782-9951
e-mail: info@zcrcoatings.com / www.zcrcoatings.com

For Free Info Circle No. 469 or Visit www.nasatech.com/469

Custom, Uniform, Super Compact LED Lighting

StockerYale excels at customizing compact, lightweight, LED illumination modules. Ideal for OEM applications with space or weight limitations, our chip-on-board technology allows for much denser packing of LEDs. **This creates a more uniform image for your CCD setup when illuminating a highly reflective surface.** We will design and manufacture a complete LED illumination solution for you. Applications include wafer, ball grid array, and metallized contact inspection. Many configurations available.

AREA LIGHT



- Many custom configurations: area lights, line lights, spotlights, and ringlights
- Highest density of LEDs
- Good uniformity
- White through infrared
- Variety of working distances



Visit us at MD & M, booth #2659

StockerYale Canada Inc.

275 Kesmark
Montreal, Quebec
H9B 3J1 Canada

T: (514) 685-1005 F: (514) 685-3307
1-800-814-9552

www.stockeryale.com/LED
lasers@stockeryale.com

Copyright © 2002 StockerYale Inc.
All rights reserved.

For Free Info Circle No. 401 or
Enter No. 401 at www.nasatech.com/rs

Photonics Tech Briefs

Laser: 300mW, 785 nm diode laser

Detector: 2-stage TE-cooled CCD

Dimensions: 16" x 10" x 9", 20 lbs.


Features: Optical components can withstand elevated ambient temperatures and are shock-mounted in a rugged, water-resistant case. Most samples can be measured through packaging materials (i.e. glass and plastic) with the RamanProbe. The system runs InPhotote acquisition software and GRAMS/32[®] manipulation software operating under Windows XP on an ultra-light notebook computer.

MCPHERSON, INC.

Chelmsford, MA

www.mcphersoninc.com

207/275DS: Raman System



Laser Source: selected to suit

Spectral Range: 185 nm to MWIR

Resolution: 0.007 nm to several nm

Detector: CCD

Features: Fast aperture ratio (f/4.7) provides excellent solid angle of collection and throughput. Triple monochromator filtering provides rejection of Raleigh scatter. Triple-stage instruments include the f/4.7 Model 207 Spectrometer in combination with the f/4.5 Model 275 Double-Subtractive filter stage. Specify the 2 m focal length Model 2062 for spectral resolution to 0.01 nm in the Visible and NIR. Instruments may be combined for double or triple stages as required by rejection requirements.

OCEAN OPTICS, INC.

Dunedin, FL

www.oceanoptics.com

R-2001: Integrated Raman



Spectral Range: ~200-2,700 cm⁻¹

Laser: 500 mW, solid state 785 nm diode laser

Detector: CCD

Features: This all-in-one system delivers detailed spectral analysis of aqueous

solutions, gels, powders, coatings, and surface media. The R-2001 series of spectrometers include a CCD-array spectrometer, an analog-to-digital converter, and 32-bit Windows operating software. The R-2001-G25 has a spectral range of ~200-4,000 cm⁻¹ and a 25mW, solid state 532 nm diode laser source. The R-2001-G50 has a spectral range of ~200-4,000 cm⁻¹ and a 50mW, solid state 532 nm diode laser source.

RSL-1: Portable Raman

Weight: 15 lbs.

The RSL-1 includes the standard Raman System components, as well as a probe or sample chamber, embedded computer, power supply, and optional customized, factory-installed calibration library. The unit provides users with a complete at-site Raman analyzer for chemical and pharmaceutical analysis.

THERMO NICOLET

Waltham, MA

www.thermonicolet.com

FT-Raman 960



Spectral Range: 3,600-100 cm⁻¹ Stokes, 300-2,000 anti-Stokes

Spectral Resolution: better than 0.8 cm⁻¹

Laser Source: Nd:YVO₄ 1.064 μm

Detector: Ge or InGaAs

Features: This dedicated system for optimized FT-Raman spectroscopy features gold-coated optics, an external laser option, and a dynamically aligned, frictionless flex-bearing interferometer with CaF₂ beam splitter. OMNIC[®] software and Raman spectral libraries included.

Almega™ Dispersive Raman


Spectral Range: 400 - 1,050 nm

Spectral Resolution: 2 cm⁻¹

Laser Source: 785, 633, or 532 nm

Dimensions: 58 x 72 x 58 cm, 295 lbs.

Features: This Raman spectrometer integrates microscopy and a full-size sample compartment into a single, enclosed automated system. OMNIC[®] software and Raman spectral libraries provide an integrated, Windows[®] compatible interface for system control and data analysis. Sampling applications include semiconductor, pharmaceuticals and polymers.



Hurricane *i*. The Ultrafast Industrial Machine.

The Spectra-Physics Hurricane is still the only one-box source of amplified ultrafast laser pulses based entirely on field-proven solid state technology. But now you have a choice. That's because we've just introduced the new Hurricane *i*, an industrial laser designed to meet the rugged requirements of tough applications such as materials processing. Based on a completely modular design, the Hurricane *i* combines state-of-the-art performance with new levels of reliability, output stability and ease-of-service. And like other Hurricane lasers, this new industrial version offers both high repetition rates (up to 5 kHz) and short pulse duration (<130 fsec).

From scientific research to precision materials processing, most applications for amplified ultrafast pulses are extremely demanding. That's why Spectra-Physics developed hands-free Hurricane one-box amplifiers. We've focused inside the box, so you can think outside the box—on your application. Call 1-800-SPL-LASER (775-5273) today to find out how Hurricane lasers can work for you.



The Solid State Laser Company™

Call: 1-800-SPL-LASER (775-5273) Web: <http://www.spectra-physics.com> E-mail: sales@splasers.com

© 2002 Spectra-Physics Lasers

For Free Info Circle No. 404 or Enter No. 404 at www.nasatech.com/rs

Miniature Spectros

reliable & low cost
Instrumentation

UV-VIS ... VIS-NIR

Portable SpectroRadiometers

Measure power and color of light and a lot more ...

Display absolute spectral power curves
 λ watts, lumens, footcandles, moles, cd,
xy chromaticity, dominant wavelength,
and color purity. UV abc level monitor.
NIST traceable calibration 200-1100nm

Also performs as a fiber optic SpectroPhotometer
Measure CIELAB color reflectance &
transmittance curves, concentration of
chemicals using absorbance methods.

SpectraWiz® Software
Free Win9x/NT/00 Program & Drivers

EPP2000 Portable

2048 Wavelengths



also powered by LabVIEW

Parallel printer interface
Plug & play via IEEE-1284

High Res. Models



www.stellarnet-inc.com



13801 McCormick Drive
Tampa, FL 33626 USA
813-855-8687 / 813-855-2279 fax

For Free Info Circle No. 498 or
Visit www.nasatech.com/498

Technologies of the Month

Sponsored by yet2.com

For more information on these and other new,
licensable inventions, visit www.nasatech.com/techsearch

Reactive Pulse Shaper for Inductive Transmitters

Robert Bosch GmbH

Schmitt-triggers provide a means of processing an alternating voltage into rectangular current pulses, which can then be counted; however, the stable hysteresis of the Schmitt-trigger (i.e. it is either "on" or "off") reduces sensitiv-



ity to interferences that extend beyond its hysteresis threshold. This causes the generation of erroneous pulses and consequently errors in measurement.

Robert Bosch GmbH's reactive pulse shaper — a Schmitt-trigger and a peak value detector connected to the output of an inductive transmitter — overcomes this limitation by defining the threshold of the Schmitt-trigger with respect to the peak value thereby reducing sensitivity to spurious interference, which enhances the accuracy of the inductive transmitter.

This device has been fully developed and has been incorporated in automotive engine management systems. Other applications may require further development. Applications and potential advantages exist for shaft angle measurement in gas turbines, valve control in rotary and reciprocating pumps, and precise control of drives in rolling mills.

For more information go to:
www.nasatech.com/techsearch/tow/pulse.html
email: nasatech@yet2.com;
phone: 617-557-3837

Fiber-Optic Security System Technology

Based on Optical Fiber Speckle Pattern recognition, this security system technology employs optical fibers, which are thin, light, flexible and immune to electromagnetic interference, as sensors. The system is based on the transmission of a laser beam in a fiber-optic cable. Any movement of the cable can be adjusted to set-off the alarm. The signal-to-noise ratio can be adjusted to remove undesired types of alarm triggers (i.e. external vibration caused by wind, rain, and small animals).

This security monitoring system technology is especially suitable for controlling large and long components such as country borders. When applied under road cable, it can be used to monitor traffic count.

For more information go to:
www.nasatech.com/techsearch/tow/security.html
email: nasatech@yet2.com;
phone: 617-557-3837

Iron-Base, Wear-Resistant Alloys

NOREM is an alloy that protects critical components from wear and corrosion damage in challenging environments. NOREM products and deposition procedures — using various conventional joining techniques — have been developed to facilitate coating operations. For example, NOREM can be welded onto a number of carbon and stainless steel substrates with little or no preheating.

Specifications for various NOREM products (powder, rod, wire, and strip) have been developed. Procedures for applying the alloy using conventional welding techniques (plasma transferred arc welding, gas tungsten arc welding, gas metal arc welding, and shielded metal arc welding) are also available. NOREM has already been used as a hardfacing alloy in new or replacement valves for nuclear power plants in the field to perform in situ repair of valves.

For more information go to:
www.nasatech.com/techsearch/tow/alloys.html
email: nasatech@yet2.com;
phone: 617-557-3837

See the Possibilities.

Imagine. Some of the most brilliant ideas in photonics, assembled for your review. R&D by the world's leading companies in fiberoptics, imaging, transmission, and optical devices, to name a few.

Now imagine the ability to search out and obtain licensable technologies that could help your photonics project see the light of day. Save

your searches and have new technologies pushed out to you as they become available.

Got some brilliant ideas of your own? Then post the results of your own R&D labor for a chance to shine and catch the eye of someone looking to license. **Who knows the possibilities?**

$(R+D)^{\infty}$



yet2.com

You can also view yet2.com's Tech of the Week by logging onto nasatechbriefs.com

Microcavity Device for Measuring Direction of a Laser Beacon


Angular resolution could be as fine as tens of nanoradians.

NASA's Jet Propulsion Laboratory, Pasadena, California

An optoelectronic device based on interferometry in a resonant microcavity has been proposed for use in measuring the direction of arrival of a circularly polarized beam of light from a beacon laser. In comparison with prior optoelectronic direction sensors, the proposed device would be simple, compact, and lightweight, in that it would contain no moving parts and no imaging optics and could be fabricated from semiconductor crystals. Moreover, it should be possible to integrate readout electronic circuits directly onto the device; these circuits would perform all needed intermediate signal processing to generate electrical output indicative of the angle of incidence of the laser beam on the device. In one potential application, the beacon would be located at one end of a free-space optical-communication link and would be used as a target for aiming a transmitting telescope located at the other end of the link. In another potential application, the beacon could be used similarly as a target for measuring angles precisely in land surveying.

The device, denoted an optical pointer on a chip (OPOC), would be divided into four quadrants, each of which would contain a wave plate in series with a blazed transmission-type diffraction grating, a Fabry-Perot etalon serving as a resonator, and a photodetector (see figure). Each wave plate would transform the circular polarization of the laser beam into the linear polarization optimum for the blaze of the grating in its quadrant. A complete explanation of the principle of operation would entail a great deal of mathematical derivation and, as such, would greatly exceed the space available for this article. In summary:

- The device would exploit the sharp dependence of the transmissivity of a Fabry-Perot resonator on the internal angle (β) of refraction or diffraction.
- The spatial period of the diffraction grating would be chosen so that normally incident light would be diffracted to a desired order inside the resonator at a desired angle β .
- The blazes in the opposite quadrants of the grating would oppose each other in such a manner as to select opposite diffraction orders (e.g., the $+j$ th and the $-j$ th) in opposite quadrants.
- The net result of the aforementioned features is that the currents generated in the photodetectors in opposite quadrants would respond antisymmetrically to a deviation of the laser beam



This **Optical Pointer on a Chip** would contain several well-known optical components in a unique combination such that the currents generated in the photodetectors in opposite quadrants would respond antisymmetrically to a deviation of the laser beam from normal incidence.

from normal incidence. To a first-order approximation for an angle that is a small fraction of a radian, the angle of incidence in a plane containing the outer corners of quadrants A and D would be proportional to

$$(I_A - I_D) / (I_A + I_D),$$

where I_A and I_D are the photodetector currents for quadrants A and D, respectively. Similarly, the angle of incidence in the plane containing the corners of quad-

rants B and C would be proportional to

$$(I_B - I_C) / (I_B + I_C).$$

Several design parameters [e.g., the thickness of the Fabry-Perot etalon, β , the reflectivity (preferably close to 1) of the mirror layers on the etalon, the laser wavelength, the indices of refraction of the device materials] affect the factor of proportionality and other aspects of the angular response of the device. It has been estimated that resolution of the order of tens

of nanoradians could be obtained by suitable choice of design parameters and execution of design by mass-production techniques now in use in the semiconductor industry.

This work was done by John Sandusky of Caltech for NASA's Jet Propulsion Laboratory.

tory. For further information, access the Technical Support Package (TSP) **free on-line at www.nasatech.com/tsp** under the Electronic Components and Systems category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its com-

mercial use should be addressed to Intellectual Property group, JPL, Mail Stop 202-233, 4800 Oak Grove Drive, Pasadena, CA 91109, (818) 354-2240. Refer to NPO-21117, volume and number of this NASA Tech Briefs issue, and the page number.

Fabricating Sapphire Optical Fibers for High-Temperature Use

Polycrystalline cladding layers are formed on sapphire cores.

John H. Glenn Research Center, Cleveland, Ohio

A process for the fabrication of coated sapphire multimode optical fibers has been developed. Sapphire multimode optical fibers are suitable for use as embedded sensors for measuring mechanical and thermal stresses and strains in material specimens at temperatures up to about 1,500 °C.

The core of each optical fiber of this type is made of optical-grade single-crystal sapphire (which is basically an allotrope of alumina). The sapphire core is clad with a layer that has an index of refraction smaller than that of sapphire, in order to confine propagating optical signals predominantly in the core and limit attenuation at the surface of the core. The cladding material preferred for thermal durability and for chemical compatibility with the core is polycrystalline alumina; however, one or more other optical materials (e.g., SiO₂, MgO, Al_xSi_{3-x}O₈) could be used for cladding. The cladding should be at least a few tens of microns thick, the exact required thickness depending on the optical properties needed for a specific application. The cladding is coated with an outer protective layer of SiC, ZrO₂, Ta₂O₅, HfO₂, or other strong, high-temperature-resistant material.

The techniques used to apply the cladding and protective layers are critical to the success of the fabrication process. The techniques and the fabrication sequence are chosen to ensure adhesion between adjacent layers. Although the process admits of a number of variations, the following steps are typical:

1. The surface of a sapphire optical fiber is prepared by cleaning in hydrochloric acid followed by rinsing in distilled water.
2. Alumina particles no larger than about 20 nm are suspended in a suitable monomer (e.g., acrylic acid) and a suitable accelerator and initiator are added to the suspension.
3. The fiber is immersed in the suspension for about half an hour to allow a thin sublayer of polymer and alumina particles to begin to form on its surface,

and the fiber is allowed to stand out of the suspension for another 24 hours, during which time the monomer polymerizes. All of the foregoing steps take place at room temperature.

4. The coated fiber is heated to a temperature of 600 °C to remove the polymeric binder, leaving the alumina particles in place.
5. The coated fiber is heated further to a temperature between 1,300 and 1,500 °C for a time between 10 and 60 minutes, in order to sinter the alumina particles around the sapphire core. The precise temperature-vs.-time sintering schedule is chosen to suit the intended application.
6. Steps 2 through 5 are repeated, as needed, in order to accumulate

cladding sublayers to the required cladding-layer thickness.

7. A suspension of particles of the protective material is prepared as in step 2, then applied to the fiber and consolidated as in steps 3 through 5.

*This work was done by Don J. Roth of Glenn Research Center and Mahmoud A. El-Sherif, Ihab L. Kamel, and Frank K. Ko of Drexel University. For further information, access the Technical Support Package (TSP) **free on-line at www.nasatech.com/tsp** under the Materials category.*

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17054.

FAST ANALOG POSITIONING



Main Applications:

- Measure laser displacements in real time
- Up to 60KHz bandwidth
- Perfect for closed loop applications
- Extremely accurate



DUMA OPTRONICS LTD.

Tel: 972-4-8200577 Fax: 972-4-8204190

P.O.B. 3370 Nesher 20306 Israel

E-Mail: sales@duma.co.il

Website: www.duma.co.il

Etching Mirror Facets on SOI Optical Waveguides

Surfaces of high optical quality could be mass-produced.


NASA's Jet Propulsion Laboratory, Pasadena, California

A process that would include a combination of dry and wet chemical etching has been proposed for making facets for low-loss mirrors on silicon-on-insulator (SOI) optical waveguides. Heretofore, such facets have been made by a process that includes dicing and polishing. This process is time-consuming and thus not suitable for mass production; moreover, the optical quality of the facets is limited by the size of the powder grains used in polishing. (Although it is possible to make nearly optically perfect facets by cleaving, the yield achieved in practice is too low for mass production.)

The etching techniques in the proposed process are already used for mass production in the semiconductor and integrated-circuit industries, and are expected to yield facets with optical quality superior to that achievable by polishing. There are two versions of the proposed process. The main steps of the first version (see figure) are the following:

1. Deposit an etching mask on top of the silicon active layer.
2. Do a reactive-ion etch through the thickness of the silicon active layer.
3. Do either a dry etch or a wet chemical etch through the thickness of the SiO_2 layer.
4. Optionally, etch a shallow groove into the silicon substrate.
5. Cleave the silicon substrate. A high yield can be obtained if one cleaves via an etched groove.
6. Remove the etching mask.

The main steps of the second version of the proposed



Facets of High Optical Quality would be formed on the etched surfaces of the silicon active layer.

process are nearly identical, except that one would turn the wafer upside-down and etch through the substrate first. The advantage of the second approach is that one would generate the facets by cleaving the silicon active layer; the quality of the facets would therefore be better than that achievable (by etching) in the first version.

This work was done by Chi Wu of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Manufacturing category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Assets Office

JPL

Mail Stop 202-233

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

E-mail: ipgroup@jpl.nasa.gov

Refer to NPO-20757, volume and number of this NASA Tech Briefs issue, and the page number.


SOLUTIONS FOR OPTICAL TEST AND INSPECTION

PRIOR
SCIENTIFIC

Prior Scientific manufactures a complete line of microscope automation equipment, fiber optic inspection instruments, microscopes and accessories for all your optical and test inspection needs.

Everything from the highest precision motorized stages and focus systems to the most advanced fiber optic endface inspection systems, Prior Scientific has it! For more

information on any of our products please contact Prior Scientific or visit prior.com.



Visit us on the web at www.prior.com

Prior Scientific, Inc. 80 Reservoir Park Drive Rockland, MA 02370
Tel: 800-877-2234 • 781-878-8442 Fax: 781-878-8736

Improved Array of Switches for Fiber-Optic Communications

Optical losses would be reduced, relative to prior switches.

NASA's Jet Propulsion Laboratory, Pasadena, California

A rectangular array of Y-junction electro-optical switches has been proposed as a prototype of reliable, high-speed cross-point switches for fiber-optic-based photonic communication systems. The proposed array would feature a hybrid digital/interference design. The proposed array would be an integrated-optics device, fabricated in the silicon-on-insulator material system; it would be compatible with silicon-based electronic integrated circuits and with up-to-date V-groove packaging.

Some previously developed electro-optical switches are said to be of the interference (more precisely, two-mode interference/single-mode propagation) type, for which the switching characteristic is sinusoidal. The performances of interference-type switches are sensitive to (and can thus be degraded by) imperfections of fabrication and variations of polarization, wavelength, operating voltage, and temperature. Hence, it is difficult to make a high-performance large interference-type switching array.

Some other previously developed electro-optical switches are said to be of the digital type. One subtype includes InP- and GaAs-based symmetric-Y-junction waveguide switches. In the case of an InP switch of this subtype, there are two electrodes on each of the two arms of the Y. When no current is made to flow through the electrodes, the switch behaves as a 3-dB power splitter. When sufficient electrical current is injected via the electrodes on one waveguide arm, the index of refraction of that arm decreases by enough that light no longer enters that arm and instead goes entirely into the other arm. Because each waveguide arm is designed to support propagation in only one mode, the light transmission versus the applied current exhibits a step-function characteristic; that is why a switch of this type is de-

noted a digital optical switch. When the current is turned on, there is an optical loss because (1) the reflection wall is tilted because of spreading of the injected current and (2) imperfections of the tips of the Y give rise to radiation and scattering.

The proposed array would contain ridge-waveguide structures. The waveguide ridges would be made of silicon, and the upper and lower cladding (opti-

hibit two states — denoted “through” and “switching.” These states are defined in the figure. The through state would involve multimode interference (instead of single-mode propagation). The principle of operation and the design to implement it would significantly reduce (in comparison with an InP switch as described above) the optical loss in through state, while retaining the step-function switching characteristic essential for effectively digital switching.


The throughput-waveguide portion of each switch would be curved; the precise shape would be chosen to minimize the throughput loss. The electrodes for each switch would be formed in a lateral acceptor-doped/intrinsic/donor-doped [positive/intrinsic/negative (PIN)] configuration that would suppress spreading of the injected current into the branch waveguide; as a result, the optical loss that would otherwise be associated with current spreading in the switching state could be minimized.

This work was done by Chi Wu and Simiak Forouhar of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasa.gov/tsp under the Electronic Components and Systems category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Assets Office
JPL
Mail Stop 202-233
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

E-mail: ipgroup@jpl.nasa.gov
Refer to NPO-20755, volume and number of this NASA Tech Briefs issue, and the page number.



This **Electro-Optical Switch** (one of many in a rectangular array) would divert light to the branch waveguide when a sufficient current was injected via the electrodes.

cal-confinement) layers would be made of air and silicon dioxide, respectively. Very low optical-propagation loss has been achieved in such a structure; this is attributable to low optical loss in the air and SiO₂ layers. The silicon wave-guiding layer in the proposed array could be designed with low doping concentration for low optical absorption.

The principle of operation of the switches in the proposed array would differ from the principles of operation of previously developed electro-optical switches. A switch in this array would ex-

new! Plug & Play Camera Kit



\$1495
complete system

SILICON VIDEO® 2112 1.3 megapixel, 10 bit, progressive scan, monochrome or color, with a programmable resolution to 1288 x 1032 pixels.

PIXCI® D2X PCI Interface supplies power and programmable pixel clock for the camera. Trigger input for async reset.

XCAP-Lite Software provides camera control including sub-windowing/sampling, mirror & flip modes, RGB balance, and user-selectable pixel clock.

2 Meter Cable supplies power, pixel clock, and control.

SILICON VIDEO® 2112

PIXCI® D2X
XCAP-Lite

EPIX®

Buffalo Grove, IL USA
Tel - 847 465 1818
Fax - 847 465 1919
epixinc.com/nt

©2002 EPIX, Inc.

For Free Info Circle No. 445 or
Visit www.nasatech.com/445




Automation Doesn't Get Any Easier!




Precision Linear Positioners

From \$399



Motorized Mirror Mounts

From \$999



I/O and A/D Products

From \$199



Chain Multiple Units to Single Port

Controller Built Into Each Unit

toll free: 1-866-409-2237 fax: 604-648-8033

www.zaber.com

For Free Info Circle No. 403 or
Enter No. 403 at www.nasatech.com/rs

New Products

Product of the Month



Multi-Sensor Metrology System

Optical Gaging Products Inc.'s (Rochester, NY) SmartScope® Quest 250 is a benchtop, multi-sensor dimensional measurement system with TeleStar® optics. As a multi-sensor system, SmartScope Quest integrates data from video, touch probe, and laser sensors to completely characterize a part. Parts that previously needed to be measured in separate set-ups on different machines can be measured entirely with SmartScope Quest. Software options dovetail smoothly into the company's MeasureMind® 3D Multi-Sensor metrology software, offering CAD import, contour analysis and fitting, and customized report generation and data export. Applications exist in virtually any industry that manufactures parts needing accurate dimensional inspection and measurement.

For Free Info Circle No. 730 or Visit www.nasatech.com/OpticalG



Excimer Laser Series for FBGs

Lambda Physik (Fort Lauderdale, FL) introduces a new series of excimer lasers designed for writing

fiber Bragg gratings. The FBG laser series is equipped with dedicated resonators and deliver very high coherence. The series offers four UV sources, differentiated by their throughput capabilities. The series — consisting of the LIFBG®, FIBEX™, COM-Pex FBG™, and OPTex FBG™ — can manage applications requiring high throughput production or single gratings for R&D.

For Free Info Circle No. 731 or
Visit www.nasatech.com/Lambda



LCR Meter for Impedance Measurements

The 1730 LCR Digibridge meter by QuadTech, Inc. (Maynard, MA) was designed for fast throughput of component evaluation in a high volume production environment. The 1730 features measurement of 12 impedance parameters, 0.1% accuracy, test frequencies to 100 kHz, high resolution LCD graphical display, plus monitoring of AC voltage and current to the device under test. The 1730 will measure, display, and output the results of any two parameters.

For Free Info Circle No. 733 or
Visit www.nasatech.com/QuadT



Telecentric Lenses

Edmund Industrial Optics (Barrington, NJ) is providing Machine Vision

Optics (MVO) Telecentric Lenses designed specifically for industrial applications. Available in four magnifications, the lenses provide both high resolution and low distortion. They can be used with CCD sizes as large as 2/3" and provide less than 0.1° telecentricity. All lenses have a front filter thread for the addition of color filters, polarizers, or other mounted components.

For Free Info Circle No. 735 or
Visit www.nasatech.com/Edmund



Space Saving Pressure Transducer

Setra Systems' (Borborough, MA) Model 227 pressure transducer weighs 6.5 oz., stands 3.6"

high, and features a space saving 1.125" Down-Mount "C" Seal interfacing base. The transducer is designed for installation on modular gas delivery systems or panels for monitoring of specialty gas processes in high purity gas delivery systems and semiconductor process tools. The Model 227 is available with 5 VDC, 10 VDC or 4 to 20mA output with 0.25% of full-scale or 1.0% of reading accuracy.


For Free Info Circle No. 732 or
Visit www.nasatech.com/Setra



Diode-Pumped Solid-State Laser

The HIPPO (High Intensity Peak Power Oscillator) from Spectra-Physics (Mountain View, CA) is an industrial, diode-pumped solid-state laser optimized for micromachining of metals, semiconductors, and polymer materials. Available with output at 1064 nm, frequency doubled to 532 nm (>11 W), and frequency tripled to 355 nm (>4.5 W), HIPPO lasers deliver short pulse length (<15 nsec at 40 kHz), high output power (>17 W at 1064 nm) and exceptional beam quality (M2<1.2).

For Free Info Circle No. 734 or
Visit www.nasatech.com/Spectra



Nano-Sized Connectors

Tyco Electronics (Harrisburg, PA) has augmented its small centerline connector product

line with a complete offering of nano-sized connectors. These nano-sized connectors have single-row contacts spaced on 0.025", or, for dual row connectors a 0.0125" centerline spacing is used. Nano connectors are suitable for industrial/commercial applications as well as military, space, and COTS applications.

For Free Info Circle No. 736 or
Visit www.nasatech.com/TycoE



Communication Antenna in a Helicopter Rotor

The radiation pattern would not turn with the rotor.

NASA's Jet Propulsion Laboratory, Pasadena, California

A proposed communication antenna for a helicopter would feature radiating elements in or on the blades of the main rotor, with a novel rotary radio-frequency coupling between the antenna and the radio equipment in the fuselage. The antenna would be suitable for communication along both predominantly horizontal paths (e.g., with distant ground stations) and predominantly vertical paths (e.g., with satellites).

The radiating elements would typically be constructed in one of three forms: (1) The elements could be vertical electric dipoles on the rotor blades; these would transmit and receive in vertical electric polarization. (2) The elements could be horizontal electric dipoles along the blades, in which case they would transmit and receive in horizontal electric polarization. (3) The elements could be horizontal slots on the blades; these would transmit and receive in vertical polarization along horizontal paths, horizontal polarization along vertical paths, and intermediate polarizations along intermediate paths. Horizontal dipoles or slots would ordinarily be preferable to vertical dipoles because they would cause less perturbation of the rotor-blade aerodynamics.


The rotary coupling could be any of several noncontact rotary waveguide joints (see figure). The stator in the rotary coupling would contain a number (n) of input/output probes equal to the number of rotor blades (typically, $n = 5$), positioned at equal angular intervals. The input/output probes in the stator would be connected to a beam-forming network connected via a coaxial cable to the radio equipment in the fuselage. The beam-forming network would be configured so that within the waveguide joint, the radiation would be coupled from the probes (in transmitting) or to the probes (in receiving) in the desired waveguide mode with n -fold azimuthal symmetry. Because the probes would be stationary, this mode would remain stationary.

The rotor part of the rotary coupling would also contain n probes at equal angular intervals. A coaxial cable would couple radiation between each of these

probes and the radiating element in or on one of the rotor blades. As the rotor turned, the rotor probes would pass through the stationary n -fold symmetric waveguide mode. This would cause the radio-frequency power coupled between each rotor-blade radiating element and the stationary radio equipment to vary with the instantaneous angle of rotation, so that the radiation pattern traced out by each radiating element alone during one complete rotation would exhibit n -fold symmetry. However, because there would be n blades, this pattern would be

spatially modulated with another n -fold symmetry characteristic of the spatial relationships among the n radiating elements. A basic theoretical analysis shows that the net effect of the rotating and stationary n -fold symmetries would be to produce a predominantly azimuthally symmetric (nonrotating) far-field radiation pattern.

The vertical polarization along horizontal paths in the case of horizontal-slot radiating elements would be desirable for communications with ground-based terminals from low altitudes. If either hori-



The **Rotary Radio-Frequency Coupling** could be a simple radial waveguide joint with overlapping parallel disks, or perhaps a more-complex radial waveguide joint that could include choke rings.

zontal electric dipoles or horizontal slots were used, the radiation skyward would be circularly polarized, as would be desirable for communication with satellites.

Because the radiation pattern would not rotate with respect to the airframe, and the rotor blades would not block the radiation, it appears that the proposed antenna would result in much less rotor-blade modulation than is observed when using helicopter antennas of other types. The rotor-blade modulation for this antenna would be limited to that as-

sociated with variation in the antenna-element/airframe coupling, with extremes when the center line of the fuselage is aligned with a blade and when it is aligned halfway between two blades. It has been conjectured that this modulation would be small in comparison with the modulation associated with the usual blockage effects.

Yet another advantage would lie in the variation of the phase of the modal radiation pattern with azimuthal angle. Depending on which mode is excited, the

relative phase of a received signal could provide a direct measure of the azimuthal angle of arrival of the signal. Thus, while providing omnidirectional coverage in azimuth, this antenna could also be used for azimuthal direction finding.

This work was done by Ronald J. Pogorzelski of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com/tsp under the Electronic Components and Systems category. NPO-19803

GPS Attitude Determination Using Nonaligned Antennas

Phases of circularly polarized signals are corrected for effects of antenna geometry.

Goddard Space Flight Center, Greenbelt, Maryland

A method of determining the attitude of a vehicle equipped with a Global Positioning System (GPS) receiver with multiple nonaligned antennas has been invented. As used here, "nonaligned antennas" does not signify antennas that lack alignment; rather, it signifies antennas that generally point in different directions (in contradistinction to antennas oriented identically as in prior methods). The method is applicable to a land vehicle, aircraft, spacecraft, ship, or almost any other vehicle.


For the purpose of this or any other method of determining attitude from GPS measurements, the positions and orientations of the antennas with respect to the vehicle and to each other must be known. In general, the attitude of the vehicle, referenced to lines of sight between the vehicle and a set of GPS satellites, is determined from differences among the phases of the GPS carrier signals received by the various antennas.

Prior methods of determining attitude from GPS measurements are based partly on the assumption that the antennas are oriented identically. This assumption simplifies attitude determination in the following way: GPS signals are right-hand circularly polarized (RHCP). In the case of identically oriented antennas, the effects of the circular polarization on the phases of the signals received by all the antennas are equal; therefore, the phase-difference measurements and the attitude determination are unaffected by the circular polarization.

When the antennas are nonaligned, the phase effects of the circular polarization differ among antennas, so that the

prior methods cannot be used. In the present method, these effects are taken into account, making it possible to use nonaligned antennas for attitude determination. The major advantage gained

through this method is that by using a sufficient number of antennas pointed in different directions, one can maximize the probability that a sufficient number of GPS satellites will be in view



The **Attitude Module** of a GPS Receiver runs software that makes differential-phase corrections for RHCP GPS signals received by nonaligned antennas.



Freedom to create

No limit on sensitivity • On expandability • On versatility

Just imagine what you could discover if you weren't limited by your instruments. Keithley's specialized and general purpose measurement solutions help scientists and engineers meet tomorrow's measurement challenges as well as today's. All our advanced research products are engineered with the accuracy, flexibility, and reliability you need. Each one is backed by our industry-leading applications support team to help you get the most from your equipment investment.


Take the first step toward greater measurement sensitivity—contact us at 1-888-KEITHLEY or visit www.keithley.com/research and download our **FREE Materials Research Kit**



Faster, easier
device characterization



Flexible DC/RF switch and measure
systems in one easy-to-use instrument



Cost-effective
PCI plug-in boards




Sub-femtoamp Remote
SourceMeter®

KEITHLEY

A GREATER MEASURE OF CONFIDENCE

For Free Info Circle No. 523 or Enter No. 523 at www.nasatech.com/rs

Evaluate Sound and Vibration



With LabVIEW™ and PXI™

Perform FFT, octave, THD, SINAD, level analysis, and more with LabVIEW and the new NI 4472 dynamic signal acquisition module. The NI 4472 features:

- 120 dB dynamic range (24 bit)
- 8 analog inputs
- 45 kHz bandwidth
- Multiple module expansion and synchronization

ni.com/info

For more information visit ni.com/info and enter na4226.

NATIONAL INSTRUMENTS™

(888) 279-9426

Fax: (512) 683-9300 • info@ni.com

© Copyright 2001 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

at any given time, making it possible to determine the current attitude of the vehicle, regardless of its position, attitude, or state of motion (the vehicle could even be tumbling).

The figure schematically depicts selected aspects of a typical GPS receiver system that implements the present method. Preferably, there are eight antennas and the radio-frequency (RF) section of the receiver can accommodate as many as six GPS channels per antenna. The signals in the various channels are digitized, then sent to a processor that includes a navigation module and an attitude module. The navigation computations and most of the attitude computations are performed according to conventional GPS methods. The distinct aspect of the present method lies in the software of the attitude module. This software provides phase-difference corrections based on the calculable effects of (1) the known relative positions and orientations of the antennas and (2) the phases of the RHCP GPS signals that they receive.

The primary obstacle to incorporating the RHCP phase-difference corrections into the attitude computations is the fact that the attitude of the vehicle is embedded in expressions of the ref-

erence frames of the various antennas. A circular-reasoning condition arises in that to calculate the attitude, it is necessary to know the RHCP corrections, but to calculate the RHCP corrections, the attitude must be known. If the attitude of the vehicle is already approximately known, perhaps from a prior estimate, the RHCP phase corrections can be estimated and then iterated, along with a new attitude solution, to convergence toward a final attitude solution. If no prior estimate of attitude is available, then an initial estimate can be constructed, for example, by use of the line of sight from each antenna to the source of the strongest GPS signal received on that antenna.

This work was done by Edgar Glenn Lightsey of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category.

This invention has been patented by NASA (U.S. Patent No. 6,005,514). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-13907.

A Semiautomated Coordinate-Measuring System

John F. Kennedy Space Center, Florida

The Advanced Payload Transfer Measurement System (APTMS) comprises electromechanical sensors and sensor-output-processing circuits. Designed specifically for measuring offsets between spacecraft payload trunnions and trunnion supports during ground-based payload-transfer operations, the APTMS could be adapted to general measurement of offsets for guiding movement of large objects during assembly of heavy machinery or structures. An electromechanical sensor of the type used in the APTMS was described in "Spherical-Coordinates Encoder Module" (KSC-11973), NASA Tech Briefs, Vol. 24, No. 2 (February 2000), page 52. Initially, the sensor outputs were fed via cables to a portable computer for analysis and display. More recently, the sensors and computer were equipped with wireless transceivers capable of communicating in either a time-division- or a spread-spectrum multiplex mode to eliminate

the need for cables, thereby contributing to maneuverability and safety in the workspace. An important element of the design and operation of the system is taking calibration measurements and processing of these measurements by curve-fitting software to piecewise-linear offsets to correct for systematic errors in raw sensor outputs in order to obtain accuracy within 0.05 in. (≈ 1.3 mm) at distances ≤ 40 in. (≈ 1 m).

This work was done by Felix A. Soto Toro of Kennedy Space Center and Wasfy Mikhael of the University of Central Florida. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Commercialization Office, Kennedy Space Center, (321) 867-8130. Refer to KSC-12204/3/195.



ANSOFT

C O R P O R A T I O N

Electromagnetically Charged EDA Software Solutions

With electronic designs evolving at lightning speed, accurate EDA tools are a must. From electromagnetics to circuits to systems, we solve design problems from the inside out. No fudge factors or approximations—just pure field equations to get the physics right from the start. So why compromise the accuracy of your designs? Call Ansoft now to learn more about how we can help turn your ideas into products. Through our electrifying innovations, we'll lead the industry into the next generation of simulation technology.



www.ansoft.com

Engineering and Design had labored in isolation.
Now they wanted nothing less than a
complete connection to the world.



Product First™

The Adventure Begins

From the producers of *ProENGINEER* comes an action-packed story of
product development unleashed. With engineering in the driver's seat.

WARNING: CONTAINS
STRONG PRODUCT
DEVELOPMENT CONTENT



COMING JUNE 18 TO ENGINEERS EVERYWHERE

SEE TICKET AT www.ptc.com/go/engineering

HURRY...

Make sure you're part of the adventure.

www.ptc.com **GO/ENGINEERING**
TODAY!

HURRY
HURRY
Make sure you're part of the adventure.
www.ptc.com **GO/ENGINEERING**
TODAY!



P

From the
producers of

RESE

...of the adventure.
ENGINEERING
AY!

...is more important to you than music.

Design had labored in isolation.
...wanted nothing less than
...ete connection to the enterprise.

...e us a call at




Product First™

The Adventure Begins

...ENGINEER... comes an action-packed drama of
...altered. With engineering in the driver's seat.

WARNING: CONTAINS
STRONG PRODUCT
DEVELOPMENT CONTENT



COMING JUNE 18 TO ENGINEERS EVERYWHERE

OUR FREE TICKET AT www.ptc.com/go/engineer

HURRY...
Make sure you're part of the adventure.
www.ptc.com
GO/ENGINEERING
TODAY!

For Free Info Circle No. 531 or Enter No. 531 at www.nasatech.com/rs

Pro
TH

from the producers of Pro
product development software

COM

ERVE YO

Product First is a service to provide a free sample of the world of product development. ©2001 PTC. PTC is a registered trademark of PTC and is used here under license. All other trademarks and service marks are the property of their respective owners. PTC is not responsible for any damage or loss of data or information that may occur as a result of using this service. PTC is not responsible for any damage or loss of data or information that may occur as a result of using this service.

Software Provides Thermal Optimization of a Computer CPU

A FEA-based, multiphysics analysis tool analyzes the water cooling system of a computer CPU to improve product durability.

ALGOR, Inc., Pittsburgh, Pennsylvania

Heat is the primary enemy of any electronic component. In order for an electronic device to have a long, problem-free life, cooling must be an important design consideration. The problem of cooling CPUs, in particular, has grown as processors have become more powerful. Water cooling systems are one option for keeping blazing-fast CPUs cool. As an example, engineers used finite element analysis (FEA)-based, multiphysics analysis software to consider whether a proposed water cooling system design would regulate CPU temperature in order to meet the manufacturer's recommendations.

Simple heat dissipation methods, such as adding heat fins and relying on natural convection, have often been sufficient for electronics. However, as devices become more powerful, it becomes increasingly important to produce the flow of a fluid to create forced convection for greater cooling capacity. The fluid may be air-moved by a fan or water within a water cooling system. The key is to produce a sufficient amount of forced convection to keep a device within its recommended operating temperature range during sustained use.

FEA-based, multiphysics analysis software provides engineers designing electronic components with a tool to determine the required flow velocities. As an electronics OEM and provider of wireless communications equipment, Wytec of Santa Clara, CA, needed to know what fluid flow velocity was necessary to cool the electronics. ALGOR's forced convection capability determined what level of fluid flow would produce the desired temperatures and prevent the electronics from overheating and failing.

The water cooling system was modeled in ALGOR. A fluid flow analysis was then performed based on an inlet velocity of 20 in./sec. to obtain a velocity profile throughout the water tube. The inlet velocity of 20 in./sec. was used because it




Figure 1: This ALGOR Fluid Flow Analysis shows the fluid velocity profile through the water tube inside a computer CPU cooling system.

is a common flow rate for an off-the-shelf small pump. This velocity profile was then used as input to the heat transfer analysis to simulate forced convection. In addition to the forced convection input, an internal heat generation load considered 29.5 watts of energy from the CPU, a specified temperature

of 70°F was applied at the inlet, and another convection load accounted for heat loss through natural convection to ambient air. The steady-state heat transfer analysis produced a temperature profile throughout both the water and cooling block with the maximum temperature reaching 82°F.

The multiphysics analysis was then repeated with a water inlet velocity of 0 in./sec. In this case, the maximum temperature reached 220°F. The analysis verified that the system would successfully cool the CPU with a water flow rate of 20 in./sec. and thereby support reliable performance over the life of the computer.

For more information on using ALGOR's multiphysics analysis products, including the forced convection capability, contact ALGOR, Inc., 150 Beta Drive, Pittsburgh, PA 15238; Tel: 1-800-48-ALGOR; or visit the Web site at: www.ALGOR.com.




Figure 2: The ALGOR Multiphysics Analysis of the Complete CPU Cooling System utilized a steady-state heat transfer analysis that considered the fluid flow velocity results from the water tube when determining the final temperature distribution in both the water and cooling block.

NEW
TEST AND
MEASUREMENT
TOOLS

Get to analysis faster. Take live measurements in MATLAB.

New test and measurement tools for MATLAB combine data acquisition, instrument



New test and measurement tools allow you to communicate with data acquisition devices and instruments directly from MATLAB.

control, and data analysis in a single, interactive environment. Now you can acquire live data from popular data acquisition devices and control your test

equipment directly from MATLAB. Use proven tools for signal processing, statistical analysis, graphics, and reporting to analyze your data as it streams into MATLAB.

Get your free 30-day trial today.



Call 508-647-7040 to request your trial. Or get a free technical information kit at www.mathworks.com/nttm.

**MATLAB®
& SIMULINK®**

Data Acquisition
Instrument Control
Signal Processing
Statistics
Training
Consulting

MATLAB
training
offered in
15 locations.

These new MATLAB tools provide a complete solution for test, measurement, analysis, graphics, and reporting.



Visit www.mathworks.com/nttm
or call 508-647-7040

© 2001 The MathWorks, Inc.

Software for Automated Planning of Spacecraft Missions

NASA's Jet Propulsion Laboratory, Pasadena, California

An artificial-intelligence computer program generates and evaluates plans for spacecraft missions subject to constraints associated with spacecraft designs. The input to the program includes spacecraft design parameters (e.g., slew rates and battery capacities) and mission parameters (e.g., requested scientific observations, frequency of communication passes, and trajectory). The program generates a mission-activity plan for attaining mission goals without violating constraints (e.g., for making all desired observations within the available time). The program makes it possible to perform rapid evaluations of

multiple candidate designs against a given mission scenario by generating plans for each design and automatically evaluating them against objective criteria. Alternatively, the program can also be used to perform "what-if" evaluations. This program can be used early in the spacecraft-design and spacecraft-mission-planning process, thereby helping to ensure that a spacecraft design and mission plan are consistent with each other; more specifically, the program can show how a given design can be expected to perform in a given mission scenario, and on the basis of the program output, one can modify the design

and/or the mission to improve performance.

This program was written by Steve Chien, Barbara Engelhardt, Darren Mutz, Russell Knight, Gregg Rabideau, Robert Sherwood, Ben Smith, Colette Wilklow, and Jason Willis of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-21000.

Generalized-Time-Line Program for Planning and Scheduling

NASA's Jet Propulsion Laboratory, Pasadena, California

Generalized Timelines API is a computer program that provides (1) a means of representing arbitrary real-world state and resource information for use in planning, scheduling, and

plan- and schedule-executing software and (2) an application-programming interface (API) that accelerates the development and validation of the software. In prior time-line programs, con-

straints had not been regarded as parts of time lines, and it was difficult to represent constraints. For the present program, a time line is defined as a representation of the actual and/or predicted value(s) of a variable and a set of constraints on the variable, both at successive intervals of time. The program (1) enables assignment of values to variables and modeling of the constraints on the variables, all as functions of time; (2) makes it possible to determine whether the values are consistent with the constraints; and (3) provides "hooks" to the search space represented by the variables for the purpose of optimizing plans. This program enables computer-programming specialists to engage in research on, and development of, scheduling application programs separately from the efforts of other specialists to implement time lines specific to their domains of expertise. In comparison with prior software of the same type, this program is representationally sufficient for more domains.

This program was written by Steve Chien, Russell Knight, Kim Gostelow, Tom Starbird, Gregg Rabideau, and Robert Sherwood of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-21022.

MORE PRODUCTS... MORE STYLES...



IGBT SNUBBERS



RC NETWORKS



BALLASTS



FILM CAPACITORS



FOIL TRANSFORMERS



CUSTOM EMI FILTERS

Quality and Performance for 40 Years!



"The Cube" delivers!
electrocube

- on-line catalog
- custom design capabilities
- local sales representation
- stocking distribution
- factory customer service and engineering support

www.electrocube.com
1307 S. Myrtle Ave • Monrovia, CA 91016
TEL: (626) 301-0122 • FAX: (626) 357-8099

ISO9001/AS9000 Certified

ACCURIDE. THE PIONEER IN PRECISION SLIDES & SOLUTIONS.

Accuride is the largest company in the world dedicated to the design and manufacture of precision ball bearing slides. For more than 35 years, we've worked side-by-side with our customers to pioneer new applications and solve tough design challenges through sound engineering, expert tooling and innovative solutions.

MORE SLIDES

- ▶ 8" to 60" long;
35 to 500 lb. load capacity
- ▶ Standard and customized designs
- ▶ Network of stocking distributors

MORE SOLUTIONS

- ▶ Expert technical assistance
- ▶ Worldwide sales and
global manufacturing
- ▶ ISO 9001 certified facilities

INNOVATIVE



INNOVATION

THE 2907. THE NARROWEST BALL BEARING SLIDE FOR 1U TO 4U CHASSIS.

Introducing the industry's narrowest, 100% ball bearing slide for 1U to 4U chassis. This versatile server slide offers superior movement and unparalleled mounting flexibility to work with an array of rail configurations. It's just another smart product innovation from Accuride.

MORE ACCESS

- ▶ .38" wide
- ▶ 1.62" high
- ▶ 2" of over travel for
access to entire unit
- ▶ Lock-out feature holds chassis
stable while servicing

MORE FLEXIBILITY

- ▶ 100 lb. load rating
- ▶ Lever disconnect provides
easy chassis removal & reinsertion
- ▶ Adapts to a wide range of
chassis sizes
- ▶ Even lengths: 12 to 30 inches

CALL 562-903-0263
OR VISIT WWW.ACCURIDE.COM
FOR YOUR SOLUTION.

Accuride®

The Leader In Precision Slide Solutions

This product is covered by U.S. patents issued and pending. ©2002 Accuride International Inc.

For Free Info Circle No. 524 or Enter No. 524 at www.nasatech.com/rs



Improvements in the Use of Water Washes in Testing for NVR

Effectiveness of washing and sensitivity of detection are increased.

John F. Kennedy Space Center, Florida

Some improvements have been made to enhance the role of water as a test solvent for determining the amount of hydrocarbon nonvolatile residue (NVR) present on an item of hardware that is required to be totally or nearly devoid of such residue. Water is now used as an NVR-testing solvent because (1) even high-molecular-weight hydrocarbon greases are at least slightly soluble in water, (2) water is safer and less expensive than are chlorofluorocarbon solvents [in particular, 1,1,2-trichloro-1,2,2-trifluoroethane (also known as CFC-113), which was used previously in testing for hydrocarbon NVR], and (3) CFC solvents are expensive and are now recognized as environmentally harmful.

The present improvements address two major aspects of the NVR-testing prob-

lem: (1) increasing the efficiency of removal of NVR from hardware by use of water and (2) increasing the sensitivity of measuring the concentration of NVR dissolved in the water. Prior to these improvements, it was known that when small parts are subjected to ultrasound in a water bath and NVR is present, the amount of NVR dispersed into the water is sufficient to enable measurement of the concentration of the dissolved NVR by the total-organic-carbon (TOC) method.

The present improvements extend the applicability of water-wash NVR testing to parts too large to fit in an ultrasonic bath. The efficiency of removal of NVR from a large part can be increased somewhat by use of steam or high-pressure spray of water, with or without a gas mixed in.

However, the technique found to be most efficient (and least dependent on the size of the part) is spraying water on the surface of the part from an ultrasonic nozzle.

The increase in the sensitivity of measurement is achieved by concentrating the NVR from the wash water before attempting the measurement. For this purpose, all of the wash water is made to flow through a bed of silica gel. During this flow, a significant portion of the dissolved NVR becomes adsorbed onto the silica gel particles. Then part or all of the silica gel is analyzed by the TOC method. Tests have shown that by use of both ultrasonic spraying of water and measurement of the TOC of silica gel through which the wash water has passed, it is possible to measure areal concentrations of NVR as

Versatile Data Acquisition

Size, configurability, and measurement speed make the stand-alone CR9000 and CR5000 ideal for remote, portable, and test-chamber applications. Both operate with or without AC power and computers and measure most


available sensors without external signal conditioning. Onboard instruction sets provide event-triggered output and mathematical functions for on-site data reduction. All systems are temperature tested to NIST traceable standards.

CR5000

- 16-bit A/D, up to 5 kHz sample rate
- 40 single-ended analog inputs (20 diff.); resolution to 0.67 μ V
- Excitations: 4 switched voltage, 4 current, and 2 continuous voltage
- 2 pulse counters
- 8 digital I/O ports


CR9000

- 16-bit A/D, up to 100 kHz sample rate
- Anti-aliasing filter module
- 9 slots for analog, filter, pulse, excitation, and digital I/O modules
- Up to 252 single-ended analog inputs (126 diff.); resolution to 1.6 μ V
- Fiber optic, parallel, and RS-232 interfaces



PC9000 is a full-featured software package that provides program generation and editing, data collection, and real-time and historical data display.

ViewDAQ real-time display software lets you create your own virtual instrument panels—allowing you to view your data any way you want.



Innovative Measurements Since 1974

Get the specs and test drive PC9000

→ www.campbellsci.com/specs.html
(435) 753-2342 • (435) 750-9540 fax



**CAMPBELL
SCIENTIFIC, INC.**

Sensors-Demeter

Components Group

Imaging Beyond Silicon CCDs **SWIR InGaAs Cameras from Sensors Unlimited**



Image at night



- **High Sensitivity:**
900 nm to 1700 nm
- **Pixel Resolutions**
320 x 240 & 640 x 480
- **User Programmable**
Exposure Times
- **Analog & Digital Outputs**




Image targeting
and training lasers



Over 10 years experience in high performance InGaAs focal plane array fabrication

www.sensorsdemeter.com



STAY ON THE CUTTING EDGE

Renew or get your own copy of *NASA Tech Briefs*. You can qualify at our website:
www.nasatech.com/subscribe or Fax this form to **856-786-0861**

Please print

Reader ID Number 000

Name

Title

Company

Address

City/St/Zip

Check one of the following:

- ☐ New Subscription
☐ Renewal
☐ Change of address

For Change of Address and/or
Renewal you must provide the
11-digit Reader ID Number from
your mailing label.

You can also
mail this form to:

NASA Tech Briefs
P.O. Box 10523
Riverton, NJ 08076-9023

1 Do you wish to receive (continue to receive) *NASA Tech Briefs*? ☐ Yes ☐ No
Please check preferred format:
a. ☐ Print Version of *NASA Tech Briefs* only
b. ☐ Digital (PDF) Version of *NASA Tech Briefs* only
c. ☐ BOTH the Print AND Digital (PDF) Versions of *NASA Tech Briefs**
Signature Date
Bus.Tel. No. Bus.Fax No.
e-mail
If you checked "c" above that you wish to receive BOTH the Print and Digital Versions of
NASA Tech Briefs, there is a small service fee of \$2.00 per month (\$24 annually).
☐ My check (for \$24) is enclosed ☐ Bill me
☐ Charge to my: ☐ American Express ☐ Discover Card ☐ Master Card ☐ Visa
Card # Exp. Date
Signature

2 Which of the following best describes
your industry or service? (check one)
E ☐ Electronics
S ☐ Computers
X ☐ Communications
O ☐ Automotive
T ☐ Transportation
M ☐ Materials/Chemicals
P ☐ Power/Energy
B ☐ Bio/Medical
J ☐ Consumer Product Manufacturing
Q ☐ Industrial Machinery & Equip.
A ☐ Aerospace
G ☐ Government
D ☐ Defense
R ☐ Research Lab
U ☐ University
Z ☐ Other (specify):

3 Your engineering responsibility is:
(check one)
A ☐ Manage Engineering Department
B ☐ Manage a Project Team
C ☐ Manage a Project
D ☐ Member of a Project Team
E ☐ Other
(specify)

4 Your job functions are:
(please check all that apply)
10 ☐ Design & Development Engineering
(inc. applied R&D)
12 ☐ Testing & Quality Control
13 ☐ Manufacturing & Production
14 ☐ Engineering Management
16 ☐ General & Corporate Management
17 ☐ Basic R&D
15 ☐ Other (specify)
Write in the number of your
principal job function

5 a. In which of the following categories do you
recommend, specify, or authorize the
purchase of products? (check all that apply)
01 ☐ Electronics
02 ☐ Photonics
03 ☐ Computers/Peripherals
04 ☐ Software
05 ☐ Mechanical Components
06 ☐ Materials
07 ☐ None of the above

5 b. Products you recommend, specify, or
authorize for purchase: (check all that apply)
32 ☐ ICs & semiconductors
33 ☐ Connectors/interconnections/
packaging/ enclosures
02 ☐ Board-level products
18 ☐ Sensors/transducers/detectors
16 ☐ Data acquisition
19 ☐ Test & measurement instruments
34 ☐ Power supplies & batteries
35 ☐ PCs & laptops
06 ☐ Workstations
36 ☐ EDA/CAE software
37 ☐ CAD/CAM software
17 ☐ Imaging/video/cameras
38 ☐ Lasers & laser systems
39 ☐ Optics/optical components
40 ☐ Fiber optics
41 ☐ Optical design software
20 ☐ Motion control/positioning equipment
30 ☐ Fluid power and fluid handling devices
31 ☐ Power transmission/motors & drives
42 ☐ Rapid prototyping and tooling
13 ☐ Metals
28 ☐ Plastics & ceramics
27 ☐ Composites
43 ☐ Coatings
80 ☐ None of the above

6 How many engineers and scientists work at
this address? (check one)
A ☐ 1 F ☐ 100-249
B ☐ 2-5 G ☐ 250-499
C ☐ 6-19 H ☐ 500-999
D ☐ 20-49 J ☐ over 1000
E ☐ 50-99

7 To which of the following publications do you
subscribe? (check all that apply)
01 ☐ Cadalyst
02 ☐ Cadence
03 ☐ Computer-Aided Engineering
05 ☐ Designfax
06 ☐ Design News
07 ☐ Desktop Engineering
08 ☐ EDN
09 ☐ Electronic Design
10 ☐ Machine Design
11 ☐ Mechanical Engineering
12 ☐ Product Design & Development
13 ☐ Sensors
14 ☐ Test & Measurement World
15 ☐ Laser Focus World
16 ☐ Photonics Spectra
17 ☐ None of the above

8 Would you like to receive a free e-mail newsletter
from *NASA Tech Briefs*?
☐ Yes ☐ No
Your e-mail address
You may receive renewal reminders via e-mail.
Do you want to receive other business-to-business
third party e-mail offers from *NASA Tech Briefs*?
☐ Yes ☐ No



low as 0.05 mg/ft^2 ($\approx 0.5 \text{ mg/m}^2$) on the surfaces of parts under test.

This work was done by Christian Clausen III of the University of Central Florida for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Materials category. KSC-12129

Using Polyimide Tape To Mask Against Reactive-Ion Etching

This technique is cheap, simple, and effective.

NASA's Jet Propulsion Laboratory, Pasadena, California


Polyimide tape (Kapton™ or equivalent) has been found to be effective as a material for masking selected areas of a semiconductor wafer that is about to be processed in a reactive-ion etching (RIE) apparatus. The conventional etch-resistant masking materials for protecting selected areas against etching are photoresists and oxides. These materials are patterned into masks by standard photolithographic techniques. The use of polyimide tape is an inexpensive option that provides additional flexibility for increasing the protection of some areas and for implementing last-minute design changes without having to incur the high cost of making optical masks for photolithography.

The tape is cut to fit the areas that are to be protected against etching, then secured to the wafer by use of its own adhesive backing (see figure). The tape is smoothed down to remove pockets of

air that would otherwise become trapped between the wafer and the adhesive. The tape is thin enough ($\approx 50 \mu\text{m}$) that it can easily be made to conform to previously patterned changes in surface height. When the RIE process is finished, the tape is simply pulled off.

In experiments, polyimide tape proved effective in preventing RIE of masked areas. Specimens of tape that were exposed to RIE and vacuum for as long as 3 hours exhibited no measurable change in thickness, no loss of adhesion, no changes in color, and no melting or other surface changes.

This work was done by Stephen Vargo of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Materials category. NPO-20598



Pieces of Polyimide Tape are applied to areas designated to be protected (or additionally protected) against RIE. During the RIE process, the ions are incident along the perpendicular to the plane of this drawing.

World's Fastest CompactPCI Digitizers

CompactPCI Digitizers



Product of the Month

CompuScope 14100C

14 Bit, 100 MS/s
CompactPCI Digitizer



- ➔ 14 Bit, 100 MS/s A/D Sampling
- ➔ 50 MS/s Simultaneous Sampling on two Channels
- ➔ 50 MHz Bandwidth
- ➔ 63 dB Signal to Noise Ratio
- ➔ Multi-Card Systems, up to 4 Channels at 100 MS/s or 8 Channels at 50 MS/s
- ➔ Software Development Kits for C/C++, MATLAB and LabVIEW

GAGE
A Tektronix Technology Company

1-800-567-GAGE ext:3405
www.gage-applied.com/ad/nasa602.htm

Outside the U.S. contact: Gage Applied, Inc.
Tel: +1-514-633-7447 Fax: +1-514-633-0770
e-mail: prodinfo@gage-applied.com

For Free Info Circle No. 516 or
Enter No. 516 at www.nasatech.com/rs



Hexfoil Rotary Flexures

These devices would afford high accuracy of centration.

NASA's Jet Propulsion Laboratory, Pasadena, California


Hexfoil rotary flexures have been proposed as pivots suitable for use in precise optical instruments. In the application that inspired the hexfoil concept, there is a requirement for a limited-rotation mirror gimbal that would maintain, with unprecedented accuracy, coincidence among the axes of rotation and a fiducial mark on the mirror, over the entire range of rotation. Theoretically, a hexfoil rotary flexure could satisfy this requirement.

A hexfoil rotary flexure would offer the following advantages over a nominally equivalent commercial rotary flexure:

- A hexfoil rotary flexure would maintain a static center of rotation; in other words, it would be subject to no more than negligible drift of the center of rotation.

- The ratio between lateral stiffness and rotational stiffness (this ratio is regarded as a figure of merit for a flexural pivot) would be much greater. Thus, a hexfoil would approximate an ideal pivot more closely.
- An optimized hexfoil rotary flexure could withstand a lateral load greater than that for any similarly sized commercial flexural pivot.
- A hexfoil rotary pivot would be made from a single piece of material. The monolithic nature of this device would ensure the highest reliability.

The hexfoil rotary flexure is related to the device described in "Trefoil Rotary Flexure" (NPO-20228) *NASA Tech Briefs*, Vol. 22, No. 8 (August 1998), page 68. In comparison with a trefoil pivot, a hexfoil pivot would have twice the angular range,



A Hexfoil Rotary Flexure would feature a favorable load-bearing configuration and a high degree of symmetry, such that the application of torque about the cylindrical axis would result in exceptionally pure rotation, even in the presence of axial and lateral loads.



MicroStrain[®]

Micro Sensors. Big Ideas.[™]

micro displacement transducers

Displacement sensors from an award winning company.

MicroStrain's range of displacement sensing devices are used by America's largest automakers and by innovative start-ups.

At MicroStrain, we help find solutions for the most difficult sensing challenges. Our patented packaging and compensation techniques perform in the harshest environments.

Every device is carefully tested prior to shipment, and calibration data is included with each order.

Please visit us at www.microstrain.com

- temperature compensation to 200° c
- microminiature
- non-contact
- submersible



Visit us online at www.microstrain.com to see our line of micro displacement transducers.

Q. Why is full featured FEA so expensive?

linear statics 3D dynamic rotation, pan and zoom mass properties
extensive error checking multi-level undo/redo
tetrahedral & hexahedral mesher
at flow into heat boundary elements
subspace iterative eigenvalue solver NASTRAN Output 2 or PATRAN 2.5 neutral file interface
mass, and damper inertia relief velocities nonlinear static
temperature dependent materials damping supported in all dynamic solution
and nonlinear direct transient response analysis linear and nonlinear buckling modal summation
gap contact with friction light source shading and transparency custom packaging
anisotropic initial slack or tension
re models over 3 million D.O.F....
ar, customizable reports robust shell and solid elements
resses surface-to-surface contact composite failure
direct matrix import & export (DMIG)

A. It Isn't...

stress dependent PCGLSS Solver
forces, and contact stresses
complete program control gap and slide line di
sparse direct and iterative (PCGLSS) solvers
orthotropic quad-dominant automatic surface me
linear functional forms
quadrilateral and triangular plates
parametric design
port DXF and IGES files
ABS
dynamic solutions perfectly
composite laminate materials s
von mises
powerful easy to use proven. precise

NE/NASTRAN
finite element analysis

all the features without the price

www.NENASTRAN.com/TB/proven ~ 1.877.NENASTRAN

while sacrificing some lateral stiffness and load capability. A hexfoil pivot could be designed as a drop-in replacement for a standard Lucas (or equivalent) pivot, inasmuch as it has the same type of interface.

A hexfoil pivot (see figure) would include two coaxial hollow circular cylinders that would constitute a rotor and stator, respectively. From each cylinder, three flexural elements in the form of thin plates spaced at equal circumferential intervals would extend radially inward, terminating at approximately the axis of rotation. More precisely, the plates attached to each cylinder would be parallelograms

with bases equal to the length of the cylinder, radial heights approximately equal to the inner radius of the cylinder, and an axial slant distance of approximately half the length of the cylinder. Thus, in effect, the three flexural elements from each cylinder would terminate in a line segment of length equal to that of the cylinder, coincident with axis of rotation, displaced axially from the cylinder by half the length of the cylinder.

To complete the characterization, it should be mentioned that the on-axis flexure termination for each cylinder would be displaced axially toward the

other cylinder, such that the flexure terminations for both cylinders would coincide. Furthermore, the flexural elements for the two cylinders would be "clocked" relative to each other such that each flexure from one cylinder would be coplanar (when not deflected) with one from the other cylinder. Hence, in essence, there would be three contiguous flexures connecting the two cylinders.

The advantages of this configuration are the following:

- The termination of the flexural elements would be brought as close as possible to the axis of rotation, thereby maximizing the rotational flexibility while maintaining lateral stiffness.
- Load paths through the device would be aligned such that all translational loads would be carried as tension or compression in the flexural elements (the stiffest and highest-load-bearing arrangement possible), while a torque applied about the axis of rotation would be reacted by simple bending (configuration of greatest compliance and least stress).

This work was done by Donald Moore and Robert Calvet of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Mechanics category. NPO-21154

THE ONLY WAY TO SEAL IT SHUT IS TO PNEUMA-SEAL IT

Pneuma-Seal® inflatable gaskets are pressurized with air to fill the uneven gaps between surfaces. When deflated, they quickly retract preventing interference when opening and closing a door or cover. Pneuma-Seal is an effective barrier against pressure differentials, and seals out water, dust, gas, chemicals, noise and other contaminants. Typical applications include:

- Processing Equipment: chemical, food, textile, pharmaceuticals, dryers, ovens and where rapid sealing and unsealing are required.
- Semiconductor Fabrication
- Pollution Control
- Laboratory Facilities
- Transportation
- Construction

Pneuma-Seal is particularly suitable in:

- Large enclosures where it is uneconomical to machine the entire sealing surface.
- Uneven fabrications where traditional compression gaskets or latches are ineffective.
- Horizontal or vertical sliding doors or covers that tend to drag on and abrade conventional seals.
- Hinged doors where flush thresholds are required.

For complete details on profiles, configurations, and applications, visit our website at: **WWW.PRESRAY.COM**



PNEUMA-SEAL®
manufactured by
PRESRAY

Presray Corporation
159 Charles Colman Blvd. • Pawling, NY 12564 USA
(845) 855-1220 • Fax: (845) 855-1139
West Coast: (949) 475-9842 • e-mail: info@presray.com

✶ Flight Research on Supersonic Laminar Flow

Flow over a suitably designed airfoil can remain largely laminar, even at supersonic speed.

Dryden Flight Research Center, Edwards, California

Some airfoil designs have been shown by theory and small-scale tests to be capable of passively maintaining laminar flow at supersonic speeds. More recently, flight tests have proven that these designs can maintain large runs of laminar flow at higher Reynolds numbers in harsh flight environments. The flight tests were conducted for the purposes of observing laminar flow at speeds up to mach 2.0 and determining the conditions under which laminar flow breaks down.

Flight tests were performed on an F-15B airplane equipped with a laminar-flow test article — essentially, a small

half wing mounted vertically (see figure). The airplane was also equipped with an infrared camera for observing the test article flow. In effect, the camera measures the local surface temperature of the test article, which temperature varies with the state of the boundary-layer flow: The portion of the surface covered by a turbulent boundary layer is warmer than that covered by a laminar boundary layer — a consequence of its higher wall recovery temperature as well as greater convection of the turbulent layer with the free-stream flow. Hence, in the infrared image, the surface in the turbulent-flow region appears brighter than that in the laminar-flow region.

The test article was fabricated from aluminum with an insulating layer covering all but the first 3 to 4 in. (about 7.5 to 10 cm) in from the leading and trailing edges. A splitter plate was installed at the root of the test article to minimize the effect of disturbances from the bottom of the airplane on the flow about the test article and to better simulate a full-span wing.

Laminar flow was observed up to full chord on the outer third of the span of the test article and up to approximately 80 percent of chord over the inner two-thirds of the span. The laminar flow was found to be capable of penetrating weak shock waves, but was typically terminated by strong shock waves. The strongest shock wave incident on the test surface appeared to emanate from the camera pod, which was located on an armament rail of the airplane.


For future flights, the test article will be instrumented with surface-pressure gauges and thermocouples to obtain more detailed data. Also, the video data-recording system will be updated to enable it to record the full 12-bit digital images from the camera. A contemplated subsequent program would use a larger test article that would permit assessment of effects of greater Reynolds numbers.

This work was done by Daniel W. Banks of Dryden Flight Research Center and Richard R. Tracy and James D. Chase of Reno Aeronautical Corporation, a subsidiary of Directed Technologies, Inc. Further information can be obtained from Daniel Banks [telephone no. (661) 276-2921 or e-mail dan.banks@dfrc.nasa.gov].

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

*Richard R. Tracy, Ph.D., President
Reno Aeronautical Corporation
3000 Old Ranch Rd.
Carson City, NV 89704-9542
Tel. No.: 775-883-8410
E-mail: tracy@renoaero.com*


Refer to DRC-00-22, volume and number of this NASA Tech Briefs issue, and the page number.



Predicted Transition Pattern on Test Article (Cross-Hatched Area Denotes Transition)



Article Mounted on F-15B Aircraft



Infrared Image of Test Article

The Boundary of the Transition from laminar to turbulent flow is visible in an infrared image of the test article taken during supersonic flight.


Any Way You Measure 3CCD Performance The Choice Is Panasonic.



Only Panasonic offers 3CCD

cameras in three different chip configurations - 1/2", 1/3" and 1/4" -- to provide the best solution for your specific application. Panasonic 3CCD cameras also feature compatible CCU's that allow you to easily switch camera heads. And all three units accommodate long cable runs of up to 100 feet without the need for signal amplifiers. You'll also find Panasonic 3CCD cameras feature an advanced pixel correction circuit that virtually eliminates image dropouts.

It's Panasonic engineering at its best --- any way you measure it.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic
Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.

Technologies & Technology Needs


Sponsored by **yet2.com**

Connecting Technology Needs with Technology Solutions

Looking for technology solutions created by the world's leading technology providers?

Afterburning Ericsson Cycle Engine Low-Cost Fuel Cell Alternative

The new Afterburning Ericsson Cycle (AEC) engine features a unique, patented, integrated combustion/engine process. Key to its success is its newly developed, patent-pending recuperator – a heat exchanger that recovers over 90% of the exhaust heat for higher thermodynamic efficiency and unmatched engine performance exceeding any conventional combustion engine or available fuel cell alternatives. This remarkable engine has virtually no burner efficiency loss because there's no external burner; it provides complete, continuous




combustion, obtaining nearly the full heating value of the fuel. And, unlike fuel cells, it can run on any available fuel, including gasoline, methane, and propane.

The AEC engine does not require costly pollution controls and is easy and inexpensive to build, requiring nothing more than a modestly equipped machine shop capable of rebuilding an automobile engine. Its simple construction enables even a small manufacturer to produce engines for tomorrow's power market.

Get the complete report on this technology at:
<http://www.yet2.com/nasatech/205> or call (617) 557-3837

New Low-Cost, Single-Substrate Flat-Panel Display

To improve plasma flat-panel technology and create a more efficient, lower-cost display for a wide range of applications, this innovative concept uses a single substrate instead of the conventional two, precisely-spaced substrates. This single-substrate solution utilizes one set of conductors mounted or silk-screened to a transparent substrate with a second, beam-like conductor grid mounted orthogonally over the first, uniformly separated by spacing posts incorporated into the grid. This unique spacing method, called a microbridge or air bridge, eliminates the need for a two-sided enclosure and partial vacuum, substantially reducing manufacturing costs. No need for thick, expensive glass substrates, reinforced display designs, and costly alignment processes. As a result, conventional, large displays typically costing around ten thousand dollars might be produced in volume for around a thousand dollars.



Get the complete report on this technology at:
<http://www.yet2.com/nasatech/206> or call (617) 557-3837

These are just two of our complete showcase of technologies. For more information on these and other new licensable inventions, visit www.yet2.com

Can you solve these technology needs?

Looking for an Airflow Measurement Tool to Overcome the Observer Effect

This company needs a way to measure airflow through the ducts and plenums of both commercial and residential ovens without disrupting that airflow. The actual measurement apparatus must be small, and should interface with a PC for data logging and recording. The solution also should provide a way to visualize the airflows.

Get the complete report on this technology need at:
<http://www.yet2.com/nasatech/207> or call (617) 557-3837

Need Audible Strain or Stress Indicator Between Two Contact Surfaces

A sound—a click, squeak, pop, or something else—indicates when this sought-for material or coating is under a predetermined shear or compressive stress. The material itself may be configurable or it may be applied to another material to produce the effect. The sound should be audible by humans in a standard industrial environment.

Get the complete report on this technology need at:
<http://www.yet2.com/nasatech/208> or call (617) 557-3837


If you would like to anonymously list your own urgent technology need and let yet2.com help you identify an existing solution, visit www.yet2.com

Improved Flange Design for Cryogenic Vacuum O-Ring Seals

Spring-loaded joints could be made less bulky.

NASA's Jet Propulsion Laboratory, Pasadena, California

A compact spring-loading design has been proposed to increase the reliability of seals in the joints of vacuum cryogenic systems. Heretofore, such joints have been, variously, compact or reliable, but not both, for the following reasons: In all such joints, sealing is effected by compression of soft metal (typically, indium or alloys of indium) O rings between flanges. Over time, the soft O-ring metal flows, with consequent reduction of preload, sometimes leading to loss of seal. To ensure reliable seals, it is necessary to spring-load the flanges to maintain compression of the O rings. However, spring-loaded joints of traditional design are not compact.



The Outer Portion of One of the Flanges would be cut to form leaf springs, which would be used for spring loading of the O ring.

The proposed compact spring-loading design is related to a prior noncompact design in which (1) one of the flanges of a joint is cut so that it acts somewhat like a leaf spring and (2) the bolt-circle diameter of the flange is made considerably greater than the major diameter of the O ring so that the flange can bend elastically and its deflection is spread out over the annulus between the O ring and the bolt circle. In the proposed design, leaf springs with a thickness less than that of the flange would be formed in the bolt-circle region by cutting a combination of meridional (radial-axial) and annular slots in the flange, as shown in the figure. This design would afford the elasticity needed for spring loading, without need to make the bolt circle much larger than the O ring.

This work was done by Bob Bamford, Talso Chui, and Warren Holmes of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com/tsp under the Mechanics category. NPO-21006

The Smallest Color Cameras In The World Are Backed By The Biggest Name In The Industry.



Panasonic color microcameras are big on performance and small in size. In fact, Panasonic offers a color super microcamera with a detachable camera head that measures only 6.7mm in diameter — the smallest in the world. It's ideal for use in various non-intrusive devices where space is limited. When color reproduction is the issue, Panasonic offers a 900,000 pixel CCD color microcamera. And for general applications, Panasonic's DSP color microcamera offers a versatile range of features. Plus, they're all supported by the biggest name in the industry — Panasonic.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.



Making Hydrogen by Electrolysis of Methanol


The cost is about half that of making hydrogen by electrolysis of water.

NASA's Jet Propulsion Laboratory, Pasadena, California

Scientists at NASA's Jet Propulsion Laboratory are developing apparatuses for electrolysis of methanol to produce pure hydrogen for use at industrial sites, in scientific laboratories, and in fuel cells. The state-of-the-art onsite hydrogen generators now in use are based on electrolysis of water to produce hydrogen, with oxygen as a byproduct that has no commercial value in this context. The developmental methanol electrolyzers consume less than half the electrical energy of water electrolyzers in producing a given amount of hydrogen. Even when the cost of methanol is included, the cost of producing hydrogen by electrolysis of methanol is still only about half that of producing hydrogen by electrolysis of water.

Figure 1 schematically illustrates a methanol-electrolysis apparatus. The heart of the apparatus is an electrolysis cell that contains a unitary membrane-electrode structure. Typically, this structure comprises a solid electrolyte in the form of a proton-conducting polymeric membrane, with a catalytic anode (e.g., containing a Pt/Ru catalyst) deposited on one side and a catalytic cathode (e.g., containing Pt or Pd as the catalyst) deposited on the other side — as described, for example, in "Improved Fabrication of Electrodes for Methanol Fuel Cells" (NPO-19941), NASA Tech Briefs, Vol. 23, No. 4 (April 1999), page 38.

An aqueous solution of methanol is circulated past the anode, where methanol and water undergo the reaction



The hydrogen ions pass through the membrane to the cathode, where they are reduced to hydrogen molecules in the reaction






Figure 1. Methanol is electrolyzed to hydrogen (the main product) and carbon dioxide (the byproduct). The carbon dioxide is vented, while the hydrogen is purified with a molecular sieve to remove traces of water and methanol before use.

Thus, the net reaction in the cell is



with carbon dioxide liberated on the anode side and hydrogen liberated on the cathode side. Because the membrane is not totally impermeable by water and methanol, traces of these substances pass through along with the protons. However, the water and methanol can easily be removed from the hydrogen stream by use of a molecular sieve, as is routinely done to remove traces of water and oxygen from hydrogen streams produced in water electrolyzers.

If the solid-electrolyte membrane in the cell is made of Nafion™ (or equiv-

alent) perfluorosulfonic acid-based proton-conducting polymer, then the cell can be operated in the temperature range from 5 to 120 °C. The concentration of methanol in the aqueous solution can range from 0.1 to 8 molar. The membrane is the electrolyte, and it is not necessary to acidify the solution to make it electrically conductive.

The theoretical operating potential of the cell is 0.02 V, though in practice, a useful amount of electrolysis is not achieved until the potential is

raised to 0.3 V. In contrast, the potential needed to electrolyze water is more than 1.4 V, even in the most efficient electrolyzers. As shown in Figure 2, the potential needed to obtain a given current density in electrolysis of methanol is more than 1 V below the potential needed to obtain the same current density in electrolysis of water. The electrical power consumed in electrolysis is reduced proportionately.

This work was done by Sekharipuram Narayanan, William Chun, Barbara Jeffries-Nakamura, and Thomas I. Valdez of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Property group
JPL

Mail Stop 202-233
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-19948, volume and number of this NASA Tech Briefs issue, and the page number.




Figure 2. Less Voltage is needed to electrolyze methanol than to electrolyze water at the same current density, as indicated by these plots of data from an experiment with a prototype methanol electrolyzer and a commercial water electrolyzer.

Aircraft-Mounted Cloud-Water-Content Probe

This relatively simple instrument contains no heater or pump.

NASA's Jet Propulsion Laboratory, Pasadena, California

An aircraft-mounted instrument for high-resolution, *in situ* measurement of the abundances of liquid water and ice in clouds is undergoing development. This instrument is intended to overcome the disadvantages of instruments developed previously for the same purpose. The disadvantages include various combinations of complexity, dependence on heaters and/or pumps, insensitivity to ice crystals, or dependence on droplet/crystal size. The present instrument is relatively simple, does not include a heater or a pump, and is expected (when fully developed) to be sensitive to both water droplets and ice crystals of any size.

In principle, the fully developed version of the instrument would contain (1) a first air-sampling probe based a total-temperature probe, (2) a second air-sampling probe that would reject water droplets and ice crystals, and (3) two fast-reading electronic hygrometers — one for each probe. A simplified prototype of the instrument has been built from a modified commercial total-temperature probe and a surface-acoustic-wave hygrometer (see figure).

By virtue of its total-temperature feature, the first air-sampling probe would bring the incident airflow to rest (except for a slow internal sampling flow), thus raising the temperature of the sam-



AIR-SAMPLING PROBE (FRONT VIEW)



AIR-SAMPLING PROBE (REAR VIEW)



SURFACE-ACOUSTIC-WAVE HYGROMETER

The Air-Sampling Probe feeds an aerodynamically heated sample stream to the surface-acoustic-wave hygrometer.

When Your Image Is On the Line Count On Panasonic.



Panasonic machine vision cameras deliver the highest levels of reliability to help assure your systems stay up and running. In addition, Panasonic offers industrial cameras for virtually every machine vision application. With features like progressive scanning for high-speed image capture that rivals expensive line scan cameras. And affordable 1/2" and 1/3" CCD cameras with versatile features and functions ideal for numerous manufacturing applications. When your image is on the line, Panasonic Industrial Cameras provide the reliability you want.



888-880-VISION (888-880-8474)
www.panasonic.com/mv

Panasonic

Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.

Thermal-Ribbon RTD's fast response surface sensing



Thin, flexible resistance temperature detectors • Wire wound or thin-film • Pt, Cu, Ni, Ni-Fe curves • 0.1 second time response • Rugged laminated construction
• -200 to 220°C range • Many sizes & styles in stock

Stable, accurate, dependable measurement • Install with self-stick backing, tapes, or cements • Avionics
• Process lines • Medical devices • Aircraft windows
• Stator windings • Thermal processing equipment

MINCO

Minco Products, Inc.

7300 Commerce Lane / Minneapolis, MN 55432-3177 U.S.A.
Tel: (763) 571-3121 / Fax: (763) 571-0927 / www.minco.com

For Free Info Circle No. 538 or
Enter No. 538 at www.nasatech.com/rs

Free Sample of NASA Tech Briefs' New PDF Edition: www.qmags.com/ntb

Join thousands of readers who already are enjoying the benefits of the new digital version!

⇒ Search/archive issues on your desktop

⇒ Link seamlessly from articles/ads to Web resources

⇒ Get earlier delivery, and special technology supplements

⇒ Save paper and storage space



Convert or add PDF to your subscription at:
www.nasatech.com/subscribe

Physical Sciences

pled air. This aerodynamic heating would cause entrained water droplets and ice crystals to evaporate. The sample stream containing the water vapor generated by aerodynamic heating would be routed to the associated first hygrometer, which would thus be made to measure the total water content (vapor, liquid, and ice) of the ambient air.

The sample stream from the second probe would be routed to the associated second hygrometer, but, unlike the sample stream from the first probe, this stream would not contain the vapor from the water droplets and ice crystals; that is, its vapor content would consist solely of the ambient-air vapor. Then one could subtract the vapor reading of the second hygrometer from the vapor+liquid+ice reading of the first hygrometer to determine the liquid+ice content.

Of course, the cloud-water-content determinations made by use of the instrument depend largely on the assumption that all of the droplets evaporate and all of the ice crystals sublimate in the first probe as a result of aerodynamic heating (and, possibly, of impact upon the probe wall). It is planned to assess the validity of this assumption in tests in a wet wind tunnel.

This work was done by Flavio Noca and Michael Hoenk of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Physical Sciences category. NPO-20767

Miniature NMR Spectrometers Without Magnets

These spectrometers would be used to characterize ferromagnetic minerals.

NASA's Jet Propulsion Laboratory, Pasadena, California

Miniature, lightweight nuclear-magnetic-resonance (NMR) spectrometers suitable for characterizing ferromagnetic minerals in the field are undergoing development. In previously developed miniature NMR spectrometers, more than half the weight is contributed by permanent magnets. The present developmental miniature NMR spectrometers can be made much lighter because they do not contain permanent magnets: Unlike other NMR spectrometers, they are designed to operate without applied magnetic fields; instead, they exploit the natural magnetic fields of the mineral phases to be studied.

Figure 1 shows a prototype instrument of this type designed to exploit the natural magnetic fields in minerals that contain iron. These fields give rise to nuclear magnetic resonance




Figure 1. This Miniature NMR Spectrometer has a mass of only 65 g (this includes the battery) and consumes a power of only 0.2 W.




Figure 2. These NMR Spectra of specimens of magnetite and hematite were obtained by use of the instrument shown in Figure 1.

of the isotope ^{57}Fe at frequencies in the approximate range of 60 to 74 MHz. Resonances occur at specific frequencies associated with mineral phases of interest. For example, magnetite (Fe_3O_4) exhibits a resonance at 63.8 MHz for $^{57}\text{Fe}^{3+}$ ions in octahedral sites (coordination with oxygen atoms) and another resonance at 67.6 for $^{57}\text{Fe}^{3+}$ at tetrahedral sites.

This instrument includes a marginal oscillator, the frequency of which is determined mainly by tuning capacitors, two varactors, and the NMR sample coil, in which a mineral specimen is placed. During operation, the frequency is swept slowly by use of one varactor, and is modulated at a rate of 110 Hz by use of the other varactor. The instrument also includes a digital-to-analog and an analog-to-digital converter and a microprocessor that communicates with an external laptop computer, generates frequency-sweep and modulation signals, samples the output from the oscillator, and performs synchronous detection.

The instrument is connected with the computer via a telephone (RS232) cable. Such parameters as the scan range, scan rate, number of averages, and time constant can be set through the computer keyboard. Spectral data can be displayed on the computer screen. The software in the computer includes routines for processing data to estimate concentrations of mineral phases of interest.

The performance of the instrument was demonstrated in NMR measurement experiments on two mineral specimens: one that contained magnetite in chlorite schist mixed with magnetically inert particles and one made of hematite ($\alpha\text{-Fe}_2\text{O}_3$). The spectra obtained from these specimens (see Figure 2) show the expected magnetite resonances and a hematite resonance at about 70.8 MHz.

This work was done by Soon Sam Kim, Narayan Mysoor, and Christopher Ulmer of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasa.gov/tsp under the Physical Sciences category. NPO-20106

Panasonic

Search

Machine Vision ☒

Medical Vision ☒

3CCD Cameras ☒

Recorders ☐

Monitors ☐

Engineering Support ☐

Contact Us ☐

For every detail...

www.panasonic.com/mv

Panasonic Industrial Cameras

BEYOND IMAGE... ENGINEERING, RELIABILITY, SUPPORT.



Books & Reports

VERSATILE UNISLIDE®

ASSEMBLIES FOR:

- ALIGNMENT
- FIXTURES
- GAUGING
- TESTING
- PROTOTYPES
- WORK HOLDING
- METROLOGY
- INDEXING
- XY TABLES

FAST DELIVERY
OF 747 MODELS
IN MANY
LENGTHS

FREE Catalog
CALL

800 642-6446


www.velmex.com
sales@velmex.com
Tel: 585 657-6151

VELMEX, INC.
Made in Bloomfield, NY

For Free Info Circle No. 539 or
Enter No. 539 at www.nasatech.com/rs

DATA LOGGING SOLUTIONS FROM ACR SYSTEMS

An ISO 9001 Registered Company



Temperature, Relative Humidity,
Pressure, Pulse, Process Signal,
Electric Current and more...



ACR Systems Inc.
Phone 1-800-663-7845 (Toll-Free in North America)
Or: 604-591-1128; Fax: 604-591-2252
Email: enquiry@acrsystems.com

The Industry Leader Since 1985 & The Best Warranty in the Business
www.acrsystems.com

For Free Info Circle No. 541 or
Enter No. 541 at www.nasatech.com/rs

FLEXIBLE BLADDERS



NASA Qualified

- BLADDER TANKS & AIR CELLS
- DIAPHRAGMS & ACTUATORS
- BELLOWS & FUEL CELLS
- STRESS TEST BLADDERS
- CUSTOM INFLATABLES
- PNEUMATIC / HYDRAULIC PRESSES

ATL 800-526-5330

AERO TEC LABORATORIES INC.
RAMSEY, NJ 07446-1251 USA
TEL: 201.825.1400 • FAX: 201.825.1962
e-Mail aerotec@cybernex.net
www.atlinc.com

For Free Info Circle No. 454 or
Visit www.nasatech.com/454

MEMS Design Optimization With FEA

This report examines design considerations in one of the most promising new areas of engineering – Micro Electro Mechanical Systems (MEMS). Designing and optimizing MEMS devices involves unique challenges, including analyzing the interdependent physical phenomena to which MEMS devices are sensitive and working with small-scale geometry. A discussion of the necessary steps to model a MEMS micro-heater for an automotive gas sensor array that can withstand high temperatures is presented in this article.

This work was a collaborative effort between Walied Moussa, Ph.D., of the University of Alberta in Edmonton, Alberta, Canada; and ALGOR, Inc., Pittsburgh, PA. To obtain a copy of the report, "MEMS Design Optimization with FEA," visit <http://optimizemems.algor.com>.

Further Developments Regarding Noise-Reducing Slots in QWIPs

A report presents additional information on the devices described in "Noise-Reducing Slots in Quantum-Well Infrared Photodetectors" (NPO-20518), *NASA Tech Briefs*, Vol. 25, No. 6 (June 2001), page 6a. To recapitulate: it was proposed that incorporation of suitably dimensioned crossed slots into quantum-well infrared photodetectors (QWIPs) equipped with two-dimensional surface grating light couplers would reduce dark currents and increase detectivities. Going slightly beyond that proposal, the report proposes optionally filling the slots with low-index-of-refraction dielectric material. Going beyond the previous discussion, the report notes that finite-difference solution of the Helmholtz equations for electromagnetic coupling into a slotted QWIP leads to the conclusions that (1) the slotted QWIP acts as an array of leaky waveguides or weakly coupled cavity resonators; (2) coupling can be maximized by choosing the width, spacing, and index of refraction of the slots to obtain resonance at the desired wavelength of operation; and (3) the coupling in such a case is stronger and more broad-band, relative to the coupling into a non-slotted surface-grating QWIP.

This work was done by Daniel Wilson, Sarath Gunapala, Sumith Bandara, and John

K. Liu of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Slotted Quantum Well Infrared Photodetector for Reduced Dark Current and Enhanced Optical Coupling," access the Technical Support Package (TSP) **free on-line at** www.nasatech.com/tsp under the Electronic Components and Systems category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Property group

JPL

Mail Stop 202-233

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

Refer to NPO-20586, volume and number of this NASA Tech Briefs issue, and the page number.

Time-Parallel Algorithms for Solving PDEs

A report presents additional details about a class of massively parallel algorithms for finite-difference numerical solution of time-dependent partial differential equations (PDEs). Some aspects of these algorithms were described in two previous articles in *NASA Tech Briefs*; namely, "Massively Parallel Computation of Electromagnetic Fields" (NPO-19453), Vol. 26, No. 5 (May 2002), page 72 and "Time-Parallel Solutions of Linear PDEs on a Supercomputer" (NPO-19385), Vol. 23, No. 12 (December 1999), page 24. These algorithms are fully parallelized in time as well as in space: this is achieved via a set of transformations based on eigenvalue/eigenvector decompositions of matrices obtained in discretizing the PDEs. Among other things, the report discusses efficient techniques for computing these decompositions for PDEs in which the spatial part involves Laplace's or Poisson's equation in two-dimensional Cartesian or polar coordinates.

This work was done by Amir Fijany, Jacob Barhen, and Nikzad Toomarian of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Time Parallel Algorithms for Solution of Time-Dependent Partial Differential Equations (PDEs)," access the Technical Support Package (TSP) **free on-line at** www.nasatech.com/tsp under the Information Sciences category. NPO-19433

Motion CONTROL Tech Briefs

Specifying Fiber Alignment System Performance: Coupling Loss Offers An Alternative to Motion Capability

One of the most difficult assembly tasks ever introduced into commercial manufacturing is the sub-micron alignment and attachment of a fiber-optic to a laser diode or other optical waveguide. Consequently, many questions arise about how to specify and ultimately verify the performance of the positioning system(s) that will guide these microscopic elements successfully into alignment. Proper alignment is critical to assuring the long-term performance of fiber-optic components.

Precision motion performance is usually discussed in terms of "resolution," but in fact there are multiple performance attributes that must be addressed in order to be consistently successful in fiber-optic device alignment applications. This article defines key terms for motion systems, discusses the importance of each with respect to this very demanding process, and offers a method for specifying motion systems in terms of coupling loss rather than motion capability.

Fundamental Motion Terminology

There are four important figures of merit for motion stages. They are resolution, minimal incremental motion (MIM), repeatability, and stability.

Resolution is used for Encoder Feedback Resolution (EFR) and is the smallest increment for determining the position of a stage. EFR describes only position reading and is not the same as the Minimum Incremental Motion.

Minimum Incremental Motion (MIM) is the smallest motion a positioning device is capable of reliably moving. MIM describes actual motion and is influenced by several factors like encoder resolution, stage, and controller closed loop quality.

Repeatability is the ability of a motion system to reliably achieve a commanded position over many attempts. There are two types of repeatability, uni-directional (UDR) and bi-directional (BDR). BDR is more stringent, and for fiber-optic align-

ment applications requires closed-loop positioning control with direct drive and on-axis encoder feedback. As it turns out, BDR and MIM are linked which allows us to use the approximation: $BDR = \pm MIM$

Stability is the ability to maintain a constant position over a specified period of time.

Of these four parameters, MIM (and so BDR) is the most significant when defining a motion system to achieve maximum fiber coupling. Because MIM relates to the ability of the motion system to take smaller steps while searching for the optimal location, a stage with a smaller MIM will theoretically find the highest coupling point. In practice however, most fiber-optic devices have coupling maxima that are of much greater width than the MIM of the alignment system. This means that decreasing MIM beyond a certain point will no longer have a measurable effect on the overall alignment efficiency.

The importance of BDR is necessitated by the device attachment application, which requires the alignment system to (repeatedly) return a fiber to the position of maximum coupling during the attachment process.

Stability is also essential because after alignment the remaining steps, such as attachment, require the coupling efficiency to be held constant over the period of time needed for completion. Although resolution contributes to MIM, it is not a critical parameter in fiber-optic device alignment applications. If a stage cannot move in very small steps (MIM), even very high-resolution readings of position become irrelevant.

Stage specifications such as MIM, stability and resolution are typically given per stage axis as if the stage was used by itself. Since fiber alignment systems are composed of many stages stacked together, the motion system must be spec-



Motion systems for fiber-optic device alignment & attachment, such as the Newport AutoAlign™-MDX, are being specified in terms of coupling loss (dB).

ified rather than a single stage axis. Furthermore, the true MIM, stability, and resolution at the tool point (where the fiber meets the device) are much different than at the stage encoder. In order to establish the exact MIM at the tool point, sophisticated experimental setups are needed, normally using non-contact measurements. Although interferometric measurements would be the most precise, it's relatively difficult to implement for the typical user. A simpler alternative is to use the power coupling efficiency of two single-mode fibers.

A Simpler Alternative

Achieving the maximum coupling point during alignment is a function of the previously outlined parameters, the alignment algorithm and its ability to search out and seek the maximum point, and other factors including environmental characteristics. So rather than specifying a motion system in terms of MIM, resolution, and other motion related criteria, specifications should be defined in terms of power coupling efficiency.

All specifications should be easily measurable by both the customer and the vendor. They should also relate to the performance characteristics of the system in a way that is understood to the user. Lastly, part of the specification should address overall system performance rather than the performance of its individual parts. This is particularly important since alignment systems are complex systems consisting of motion stages, vibration isolation, optical power measurements, and alignment algorithms. The following method for specifying alignment systems addresses these criteria.

The experimental setup to verify these specifications is quite simple and consists of two single-mode fibers. Light passes through one fiber into the other. The alignment system will

align these two fibers so that there is maximum light coupling. The test conditions are as follows:

System Setup: Two single-mode fibers are separated by a specified distance z in the optical axis. One fiber is on a stationary stage. The other is on the alignment system to be tested.

Load on the System: The load on the system is W .

Temperature Range: The system will operate within a temperature range K and achieve the above specifications, except for stability (S) specification, which has its own specified range.

Number of Measurements: The range and standard deviation of each specification is measured using at least 50 observations.

The Specifications

Motion Repeatability is defined by R_σ (dB). It is determined by achieving alignment, recording the motion coordinates and the coupling power, and then commanding the system to return to the same coordinates and record the power for at least 50 more repetitions. R_σ is the standard deviation of these measurements. This measurement is a system level measurement that takes into account all the system parameters.

Maximum Coupling Efficiency is defined by two parameters. The average coupling-loss C (dB). This specification is a measure of how good the coupling is, and is determined by achieving alignment, recording coupling efficiency, then moving all axes (except Z) away from the aligned position, and then aligning again and recording power.

Alignment Repeatability is defined by the coupling loss standard deviation C_σ (dB) measured as described above. C and C_σ are also system level performance measurements that take into account all the system parameters including the alignment algorithm.

Alignment Stability is defined by the drift, S (dB), in coupling loss recorded over a period of t minutes after alignment has been achieved, while the temperature fluctuation is limited to a range $K(s)$. When determining this specification, the alignment system is kept idle.

Alignment Time is defined by the average time, T in seconds, required by the alignment system to reach maximum coupling efficiency from observation of first light.

Fiber-to-fiber alignment does not cover all applications. Since single-mode fibers are standard, it provides a universal apparatus to test alignment systems. The user may have other applications where they are aligning lasers to fibers or waveguides to fibers, but those applications are dependent on the device in question and do not provide a universal means for system specification.

How will MIM effect the coupling efficiency specifications? If two fibers are in perfect alignment, movement in the X or Y -axes will result in lower coupling between them. Based on theoretical models, a 50nm movement in X or Y will only result in <0.001 dB additional loss. This difference cannot usually be measured but is calculated from a theoretical model. In general, 50nm MIM is sufficient for most alignment applications.

As standards emerge in the fiber-optic industry for performance of components, similar set of standards are needed for the performance of automation systems, particularly alignment systems. Both the user and the vendor can easily measure the suggested performance criteria. It can also be used as acceptance level tests or used to compare the performance of different systems.

The authors can be contacted by email at Guy Bowvree (Applications Manager, Motion Systems), gbowvree@newport.com; Frank Vodhanel (Product Manager, Fiber Alignment Systems), Fvodhanel@newport.com; and Sohrab Zarrabian (Sr. Director of Product Management), szarrabian@newport.com, or call (949) 862-3400.

For more information on Newport Corporation, visit www.newport.com.



- Patented "taper mount" overcomes run-out errors
- ± 1 arc second accuracy
- Outside diameters from 52mm to 413mm
- Small cross-section, large internal diameter
- Resolutions down to 0.01 arc seconds
- Up to 129.6 million counts per revolution
- Zero backlash

Renishaw Inc. 5277 Trillium Boulevard, Hoffman Estates, IL 60192
T 847 286 9953 F 847 286 9974 E usa@renishaw.com
www.renishaw.com

For Free Info Circle No. 654 or
Enter No. 654 at www.nasatech.com/rs



NEW, Harmonic Planetary® High Precision Planetary Gearhead

Exclusively from HD Systems, the Harmonic Planetary® HPG Series provides the motion control and design engineer with a planetary gearhead that reduces backlash to less than 1 arc-min. This level of backlash is maintained for the life of the gear.

This design is made possible by developing a ring gear that can flex in the radial direction, while maintaining high torsional stiffness. The result is a planetary gearhead that provides consistently low backlash, high efficiency, and high output speeds.


This planetary gearhead is available in 3 frame sizes from 60mm to 120mm. Rated torque ranges from 53 in-lb to 956 in-lb. Peak torque ranges from 496 in-lb to 5753 in-lb. Gear Ratios 5:1 to 45:1. Flange or shaft output available.

HD Systems, Inc.

(800)231-HDSI (631)231-6630

For Free Info Circle No. 657 or

Enter No. 657 at www.nasatech.com/rs



NEW, Hollow Shaft Actuators

The FHA Series of actuators features a through-bore up to 45mm in diameter and provides high torque and exceptional positioning accuracy. This performance is achieved in a compact design using a patented "S" tooth harmonic drive gear coupled to a DC brushless pancake motor with integral electronic commutation and a high resolution encoder. Rated torque up to 1730 in-lb and positional accuracy better than 1 arc-minute can be achieved. The FHA Series is available in five frame sizes, ranging from 128 to 300mm in diameter, and 116 to 248mm in length.

HD Systems, Inc.

(800)231-HDSI (631)231-6630

For Free Info Circle No. 658 or

Enter No. 658 at www.nasatech.com/rs

NEW, Harmonic Drive Gearhead, Zero Backlash

The CSF-2UH series high torque gearheads use HD Systems' patented "S" tooth that delivers more than twice the torque, twice the life, and twice the torsional stiffness when compared to conventional Harmonic Drive Gearing. Positional Accuracy is better than 1 arc-min. The CSF-2UH series is available in 10 frame sizes with rated torque ranging from 48 in-lb to 8400 in-lb and peak torque ranging from 310 in-lb to 42,000 in-lb. Gear Ratios 50:1 to 160:1.

The CSF series uses a rigid cross roller bearing to support its output flange. This combination allows the gearhead to be extremely compact while providing high axial, radial, and moment load capacities. Easily interfaced with a servo motor, these zero backlash, high accuracy gear systems are ideal for indexing tables, robots, and factory automation equipment. Flange or shaft output available.

HD Systems, Inc. (800)231-HDSI (631)231-6630

For Free Info Circle No. 656 or Enter No. 656 at www.nasatech.com/rs



ULTRA FLAT

HARMONIC DRIVE GEARING

- Zero Backlash
- 1 Arc-Min Accuracy
- Gear Ratios to 160:1



New CSD Series

Call for Technical Brochure

800.231.HDSI

631.231.6630

or visit www.HDSI.net



Conventional
Harmonic Drive Gearing



New CSD Series
Ultra Flat Design

World Leader in Ultra-Precision Motion

89 Cabot Court. Hauppauge, NY 11788 T: 631.231.6630 F: 631.231.6803 800.231.HDSI www.HDSI.net

For Free Info Circle No. 659 or Enter No. 659 at www.nasatech.com/rs

See us at SEMICON West (San Francisco), Booth# 3106

Algorithm Computes Kinematics of a Rover on Rocky Terrain

This algorithm is efficient enough for use in a real-time simulation.

NASA's Jet Propulsion Laboratory, Pasadena, California


The Rover Analysis Modeling and Simulation (ROAMS) algorithm is to solve the kinematics of a wheeled mobile robot (rover) traversing on a rocky terrain. The rover is constructed using a "rocker-bogey-differential" type suspension and steering system as shown in the figure. By exploring the mechanical symmetry and the wheeled-

terrain contact characteristics on a rough terrain profile, we developed a novel algorithm to carry out the rover's configuration, including the vehicle's wheels, steering and suspension linkages, and the position and orientation of the chassis. Because of its efficient and reliable numerical results, the ROAMS algorithm is well suited for the

real-time simulation test bed, e.g., a simulation software system, of the mobile robotic vehicles in the planetary surface exploration missions. Currently, it is used to support the development of simulation and operation tools for the Mars Exploration Rover (MER) in the Mars '03 mission.

One of the most important properties of the algorithm is the robust computational result, which yields a fast prediction of the rover's position and orientation in an uncertain environment. The ROAMS algorithm treats the underlying mathematical model as an inverse-kinematics problem, and carries out the solutions using the computational techniques for constrained optimization. In this framework, the objective functions comprise three conditions: (1) rover's internal differential mechanisms, (2) wheel-terrain contact, and (3) rover's driving motion. The resultant nonlinear equations can be derived, and their solution can be computed by a straightforward application of numerical methods. However, the standard approaches to this nonlinear system of equations suffer from the instability and inefficiency in the numerical solutions due to the rough terrain profile, which is often modeled as a piecewise smooth digital elevation map (DEM). Moreover, the modeling of the physical limits of the linkages (e.g., the bumper-stops) can be problematic to the solution, as well as the case that all wheels may not be in contact with the ground at all times. All these modeling and numerical difficulties are resolved in the novel algorithm that achieves the real-time simulation of the rover traversal on a rocky terrain.

In this algorithm, we implemented a Newton-type iterative method that handles the non-smooth wheel-terrain contact equations using global searching and relaxation techniques. The solution also takes account for the bump-stopper devices, which have been modeled as the joint limits at the corresponding linkages, and maintains a fast convergent rate. Regular Newton-type iteration requires the smoothness of the equations to ensure a fast convergence. This prerequisite of a robust convergence is violated since the roughness of the terrain has been embedded in the contact equations. When the rocker or bogey linkages reach their limits, an abruptness of the iteration can induce



GO FASTER. GO FURTHER. GO HEAVIER.

The new DriTran® Screw Drive System gives engineers the freedom to design machinery without the critical speed and length concerns associated with conventional screw drive systems.

Imagine being able to move a 10,000 lb. load 30 feet in 10 seconds with a 2.75" diameter screw delivering 6" of travel per revolution. This new system handles dynamic loads up to 30,000 lbs. and standoffs allow joining multiple sections up to 40 feet.

Cast epoxy-threads inside the nut make it all happen. The best part—the low friction, extended wear nut is easy to service, and it can be changed out in minutes instead of days.


To find out more,

Call us today at 231-946-6270 or
visit www.trantekdrivesystems.com

TRANTEK

DRIVE SYSTEMS INCORPORATED

2470 N. AERO PARK COURT TRAVERSE CITY, MICHIGAN 49686



Rocky-7, a small robotic vehicle, is designed to traverse rocky terrain. The algorithm described in the text solves the inverse kinematic problem of the rover/terrain system during a computational simulation of such a traversal.

unpredictable solution of the configuration. To overcome these numerical difficulties, we applied a weight factor to the residual of each contact equation. During the iterations, the weight factor for a given wheel can be made to approach zero to relax the contact condition. Whenever the wheel leaves the ground, its corresponding weight factor is set to zero for a total relaxation of this wheel-terrain contact. The re-scaling of the weight factors is coupled with the global search algorithm, which can detect the joint limits (associated with each of the wheel-terrain contacts) for locking the joints, and can sample small perturbations around the contacting locations to determine the occurrence of a separation of the wheel and the ground.

The step-selection strategy used in the global search is a backtracking line search algorithm that monitors the progress of the iteration. For a smooth terrain profile, the iterative solution generated by the Newton method converges very rapidly to a local minimum of the

nonlinear equations. However, the rate of convergence can be tremendously decreased when a non-smooth terrain profile appears. Special cares have to be taken to maintain robust and efficient solution in the case of non-smooth terrain profile. Although the problem in hand is ill-posed (i.e., it is well-known that the Newton method cannot treat non-smooth equations), we developed a heuristic solution to ease the computational difficulty in the iterations. In

practice, the wheel-terrain contact is treated as a non-penetrative type, which is not a realistic portrait of the nature of the wheel-terrain interaction. Therefore, a search direction to the wheel-terrain contact may not be in-line with the normal direction of the terrain (at the contact location), instead, it could be anywhere along the perimeter of the wheel. The heuristic solution leads to modeling the wheel-terrain contact equation as the distance constraint between the wheel center and the terrain profile. As shown in all the preliminary testing cases, the modification of contact equations yields a much-improved convergence in non-smooth terrain profiles, and allows the modified Newton iteration to overcome many local irregularities.

This work was done by Jeng Yen of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com/tsp under the Mechanics category. NPO-20997

Software for Simultaneous Control of Three Magnetic Bearings

John H. Glenn Research Center, Cleveland, Ohio


Five-Axis, Three-Magnetic-Bearing Control Code (FATMaCC) is a C++-language computer program for controlling a magnetic thrust bearing in one degree of freedom and two magnetic radial bearings, each in two degrees of freedom. These bearings levitate a vertical-axis rotor for experiments on the effects of vibrations on turbomachinery. When executed on a 1-GHz processor, FATMaCC can control the bearing/rotor motions in either a decentralized or a centralized (modal-control) manner at a loop time of 56 μ s. Through keyboard

entries, the user can modify such bearing parameters as stiffness, damping, and bias. A module in the program generates signals that can be superimposed on the radial-bearing x- and y-axis control signals to generate forces that excite rotor vibrations. There is an option to modulate the radial bearing control signals with cosine and sine functions, to make the radial excitation force vector rotate about the nominal central bearing axis. There is also an option to excite rotor rigid-body modes; depending on the polarities of the excitation signals ap-

Better Mousetraps No Maintenance




Production couplings



Custom couplings



U-joints



Machined springs



901 W. McCoy Lane, P.O. Box 1069
Santa Maria, CA 93456-1069
tel 805-928-3851 fax 805-928-2369
www.Heli-Cal.com

ADVERTISEMENTS

Precision Linear Motion Assembly




PRECISION LINEAR MOTION

"Rolling ring" linear actuator with integrated linear scale. Resolution up to 0.0004 inches (0.01 mm). Offset quadrature output signal to the controller derives both linear position and rotational direction (travel direction).

Assembly built to customer specifications; arrives ready to install in production machinery and connect to drive motor. Virtually zero backlash. Amacoil, Inc.; Tel: (800) 252-2645; Fax: (610) 485-2357; e-mail: amacoil@amacoil.com; <http://www.amacoil.com>.

Amacoil, Inc.

For Free Info Circle No. 615 or
Enter No. 615 at www.nasatech.com/rs



MICRO-DRIVES

Is an international group of micromotor and gearbox manufacturers dedicated to providing quality products and services with timely delivery at a reasonable price.

For over 40 years we have supplied OEMs with fractional horsepower motors and gearmotors for pumps, ventilation equipment, security and access control, printing machinery, motorized window treatments and gaming equipment, medical equipment and instruments and almost any other miniature actuator applications you can imagine.

- Product sizes 12 to 80 mm
- Power ratings .5 to 25 watts
- Torque range up to 347.2 oz-in
- Visit our website for pricing

www.micro-drives.com



COMPANY PROFILE

Micro Mo Electronics is an OEM supplier of fractional horsepower DC motors, precision gearheads, tachometers, encoders, brakes, and complete servo systems. Gearmotors from 1.9 mm in diameter. Power outputs to 1,000 watts. Over 1,000 matching gearhead types are available in ratios up to 1,000,000:1. Custom motion systems and special modifications. ISO 9001 certified. Micro Mo Electronics, Inc., 14881 Evergreen Ave., Clearwater, FL 33762-3008; Phone (800) 807-9166 (US or Canada) or (727) 572-0131; fax (727) 573-5918; web site: <http://www.micromo.com>; e-mail: info@micromo.com.

Micro Mo Electronics

For Free Info Circle No. 651 or
Visit www.nasatech.com/651



MVP®2001 MOTION CONTROL SYSTEMS

The MVP® provides motion, velocity, position, and torque control with an integrated PWM or linear amplifier in one 2" X 4" X 3.7" extruded metal case. It provides DeviceNet™ compliant, RS-232, or RS-485 multidrop control of brush and/or brushless DC motors. Up to 64 axes can be networked. Under US\$600 in single piece quantities. Micro Mo Electronics, Inc., 14881 Evergreen Ave., Clearwater, FL 33762-3008; Phone: (800) 807-9166 (US or Canada) or (727) 572-0131; fax: (727) 573-5918; web site: <http://www.micromo.com>; e-mail: info@micromo.com.

Micro Mo Electronics

For Free Info Circle No. 652 or
Visit www.nasatech.com/652

plied to the radial bearings, either the bounce or the tilt mode is excited.

This program was written by Carlos R. Morrison of Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Software category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17293.

Crowned Races for Crossed Roller Bearings

Scuffing would be reduced.

NASA's Jet Propulsion Laboratory, Pasadena, California

Crowned races have been proposed for crossed roller bearings. Crowning of the races is expected to reduce scuffing of the cylindrical rollers. Crowning of the races is expected to be especially beneficial in bearings made of polymers (instead of metals) to reduce weight.


The crossed-roller bearing design is the roller equivalent of the x-type ball bearing design. In a crossed-roller bearing, the races are conical surfaces at angles of 45° to the axis of rotation. The advantages and disadvantages of the ball and crossed-roller designs are complementary: In comparison with ball bearings, roller bearings can withstand greater loads. On the other hand, roller bearings are more susceptible to scuffing, which is caused by a kinematic mismatch between tangential roller speeds at the inner and outer diameters of the races.

In a crossed-roller bearing with crowned races (see figure), the contact area, and thus the amount of scuffing, would be reduced (relative to that of con-

ical races) to a value near that of ball bearings. The crown radius is a free design parameter that can be chosen, along with other parameters, in consideration of the bearing material(s) and the loads that must be borne in a given application.

One might ask why it would be preferable to crown the races instead of crowning the rollers. The reason is a practical one: Unlike in the case of steel bearing balls, it is difficult to fabricate polymeric bearing balls or polymeric crowned rollers with sufficient precision to ensure sharing of loads as needed for long bearing life. On the other hand, cylindrical crowned rollers of sufficient precision can be fabricated easily by centerless grinding in conventional machines.

This work was done by Donald Bickler of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com/tsp under the Mechanics category. NPO-30203




Crowned Races, in contradistinction to conical races, would function with less scuffing in roller/race contact areas.

New on the MARKET

Digital Oscilloscopes

The TDS1000 and TDS2000 series digital storage oscilloscopes from Tektronix, Beaverton, OR, feature a Fast Fourier Transform (FFT) function to analyze, characterize, and troubleshoot circuits, and a color LCD display. The TDS2000 family is available in 2- and 4-channel versions, delivering up to 200 MHz bandwidth and 2 GS/s maximum sample rate. The TDS1000 are 2-channel instruments with a 1 GS/s maximum sample rate and bandwidth up to 100 MHz. **For Free Info Circle No. 700 or Visit www.nasatech.com/tektronix**



Waveform Digitizer Cards

Gage Applied, Montreal, Canada, has released CompuScope waveform digitizer cards for the CompactPCI bus that offer sample rates for 8-bit, 14-bit, and 16-bit sampling resolution. The CompuScope 85Gc features 5 GS/s sampling and 500-MHz bandwidth on two simultaneous channels. The CompuScope 1610C features 16-bit vertical resolution at a 10 MS/s sampling rate for two simultaneous channels. **For Free Info Circle No. 701 or Visit www.nasatech.com/gage**

Rugged Notebook Computer

Dolch Computer Systems, Fremont, CA, offers the NotePAC™ industrial notebook computer featuring an integrated full-color inkjet printer protected by an all-metal enclosure. The printer assembly is attached to the NotePAC via a machined interface plate and high tensile screws to form a single, portable unit. The printer is battery powered and is suitable for emergency services, the military, public utilities, and other field services. **For Free Info Circle No. 702 or Visit www.nasatech.com/dolch**



Sensor/Transducer System

Transducer Techniques, Temecula, CA, has combined its SWS socket wrench torque sensor and its PHM-100 handheld transducer indicator into one system, providing measurements of bolt or nut wrenching torques in either direction. The PHM-100 has a peak hold feature that captures at less than one millisecond and operates on a 9-volt battery for 60 hours. The SWS is a reaction-type torque sensor offered in six ranges from 10 to 1000 ft. lbs. full scale. **For Free Info Circle No. 703 or Visit www.nasatech.com/tt**

Motion and Stress Simulation

MSC.visualNastran 4D 2002 from MSC.Software, Santa Ana, CA, is a Windows-based software that sets 3D assemblies into motion, animating the resulting stresses. It supports most CAD systems through integration with Autodesk Inventor™ and Mechanical Desktop®, Pro/ENGINEER®, SolidWorks®, and Solid Edge®, and standard file formats. Features include analysis of rigid body dynamics, vibration, deflection, buckling, steady state heat transfer, redundant constraint relief, and photo-realistic rendering. **For Free Info Circle No. 704 or Visit www.nasatech.com/msc**



Globe Motors™
EXPERTS IN MOTION CONTROL



Optimum Precision ... Optimum Performance

Globe Motors has the precision motion control solution for your automotive application. Our standard and custom motors meet high-performance needs, tight tolerances, and stringent specifications.

QS9000
CERTIFIED

**For Free Info Circle No. 450 or
Visit www.nasatech.com/450**

HIGH STRENGTH ADHESIVE RESISTS VIBRATION, IMPACT AND SHOCK

MASTER BOND SUPREME 30 POLYMER SYSTEM

Fast cure at ambient temperatures ■ High physical strength properties ■ Excellent adhesion to metallic and non-metallic substrates ■ High T-peel strength ■ Superior durability and chemical resistance ■ Wide service temperature range ■ Convenient packaging

154 Hobart St.,
Hackensack, NJ 07601
TEL: 201-343-8983
FAX: 201-343-2132
main@masterbond.com
www.MasterBond.com

Master Bond Inc.
Adhesives, Sealants & Coatings

**For Free Info Circle No. 542 or
Enter No. 542 at www.nasatech.com/rs**

emotion

WWW.GLOBE-MOTORS.COM

937-228-3171
Fax 937-229-8531

Quality


COMBINED WITH PERFORMANCE

RAE's **GIL200 Gearbox**. A perfect fit for RAE's DC motors M4000 and M6000. Rugged and heavy duty with speeds up to 400 RPM and ratings at 300 in-lbs. Perfect for long lasting performance.



RAE Corporation

4615 W. Prime Parkway • McHenry, IL 60050-7937 USA
Tel 815-385-3500 • Fax 815-363-1641 • www.raemotors.com



New LITERATURE

Pressure and Flow Instruments

The **CONTROL CAT™ New Horizons®** in Pressure, Flow & Everything Else handbook from OMEGA Engineering, Stamford, CT, features information on conductivity and dissolved oxygen meters, controllers and transmitters, and handheld instruments for pH, temperature, pressure, and airflow. The handbook also features load cells, flow meters, signal conditioners and switches, and industrial pressure transducers and transmitters. **For Free Info Circle No. 706 or Visit www.nasatech.com/omega**




Quality

TOUGH, DEPENDABLE and VERSATILE

RAE's **M4000 DC Motor**. Extremely durable. High output torque. Rating to 1/4 HP and speeds to 3500 RPM. The M4000 motor series offers a broad range of performance potential and is perfect for various motor sizes and stack lengths.

RAE Corporation

4615 W. Prime Parkway
McHenry, IL 60050-7937 USA
Tel 815-385-3500 • Fax 815-363-1641
www.raemotors.com



O-Ring Seals

Parker Hannifin Seal Group, Irvine, CA, has released a catalog describing product forms and applications for its o-ring seals. Applications include automotive systems, chemical processing equipment, medical devices, aerospace vehicles, and ultra-high-purity semiconductor processing. Also included are the compound mixing and tooling operations used to manufacture the seals. **For Free Info Circle No. 707 or Visit www.nasatech.com/parker**

Data Acquisition Systems

The **DAQ Designer™ 2002 CD** from National Instruments, Austin, TX, helps users select software and hardware products for their custom data acquisition systems. Users answer questions about their application details, and the configuration advisor recommends the best software and hardware for applications in acoustic/vibration, inspection and placement, data logging and low-frequency sourcing, signal acquisition and generation, control and simulation, and data management. **For Free Info Circle No. 708 or Visit www.nasatech.com/ni**



Paperless Recorders

Monarch Instrument, Amherst, NH, offers a brochure highlighting its **Data-Chart®** paperless recorders that accept up to 12 direct universal inputs including thermocouples, RTDs, DC voltage, current, and dry contact. Information is displayed on LCD displays and recorded to 3.5" disk, 100 MB Zip disk, or PCMCIA cards. **For Free Info Circle No. 709 or Visit www.nasatech.com/monarch**



Plastic Fasteners and Components

A 368-page catalog of plastic fasteners and components is available from Craftech Industries, Hudson, NY. The catalog includes ANSI and DIN standard machine screws, cap screws, nuts, washers, spacers, hinges, handles, u-bolts, eye bolts, wire handling hardware, tube and hose fittings, caps and plugs, and panel fasteners. More than 80 materials are available. **For Free Info Circle No. 710 or Visit www.nasatech.com/craftech**



ASME International

In Business Problems? In-Company Solutions

Identify your training needs and save time, while cutting costs with ASME In-Company Programs!

- ASME has the engineering courses and industry experts that enable your company to stay ahead in today's competitive marketplace.
- We will work closely with you to ensure that objectives are met and examples are incorporated specific to your company's needs.

Call or e-mail to find out more information about ASME In-Company Programs today!

ASME International

Tel: 212-591-7752

Web: www.asme.org/pro_dev

Email: rubine@asme.org

For Free Info Circle No. 544 or Enter No. 544 at www.nasatech.com/rs

FREE INFORMATION REQUEST FORM

For quickest service:

Fax this form to (413) 637-4343

Use the online reader service center at www.nasatech.com/rs

Or mail your completed form to
NASA Tech Briefs,
PO Box 5077, Pittsfield, MA 01203-9109.

Name: _____

Company: _____

Address: _____

City/St/Zip: _____

Phone: _____

Fax: _____

e-mail: _____

Please tell us below how *NASA Tech Briefs* has helped you solve a problem or been applied to your business/product line.

Do you currently receive *NASA Tech Briefs*? ☐ Yes ☐ No

If no, would you like to receive *NASA Tech Briefs*? ☐ Yes ☐ No

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410
411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430
431	432	433	434	435	436	437	438	439	440
441	442	443	444	445	446	447	448	449	450
451	452	453	454	455	456	457	458	459	460
461	462	463	464	465	466	467	468	469	470
471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490
491	492	493	494	495	496	497	498	499	500
501	502	503	504	505	506	507	508	509	510
511	512	513	514	515	516	517	518	519	520
521	522	523	524	525	526	527	528	529	530
531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550
551	552	553	554	555	556	557	558	559	560
561	562	563	564	565	566	567	568	569	570
571	572	573	574	575	576	577	578	579	580
581	582	583	584	585	586	587	588	589	590
591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610
611	612	613	614	615	616	617	618	619	620
621	622	623	624	625	626	627	628	629	630
631	632	633	634	635	636	637	638	639	640
641	642	643	644	645	646	647	648	649	650
651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670
671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690
691	692	693	694	695	696	697	698	699	700
701	702	703	704	705	706	707	708	709	710
711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730
731	732	733	734	735	736	737	738	739	740
741	742	743	744	745	746	747	748	749	750
751	752	753	754	755	756	757	758	759	760
761	762	763	764	765	766	767	768	769	770
771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790
791	792	793	794	795	796	797	798	799	800
801	802	803	804	805	806	807	808	809	810
811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830
831	832	833	834	835	836	837	838	839	840

ARE YOU AN INSIDER?

Subscribe today to receive the INSIDER, a FREE e-mail newsletter from *NASA Tech Briefs*. The INSIDER features exclusive previews of upcoming articles...late-breaking NASA and industry news...hot products and design ideas...links to online resources...and much more.

☐ I want to be an INSIDER. Send my newsletter to the following e-mail address:

Name _____

Company _____

I also want to receive special-focus e-newsletters on the following technology topics: (check all that apply)

- | | |
|----------------------------------|--|
| <input type="checkbox"/> CAD/CAE | <input type="checkbox"/> Fiber Optics/Communications |
| <input type="checkbox"/> Lasers | <input type="checkbox"/> Test & Measurement |
| <input type="checkbox"/> Optics | <input type="checkbox"/> Imaging/Cameras |
| <input type="checkbox"/> Sensors | |

**For fastest service, sign up online
 at www.nasatech.com/insider**



MINIATURE METAL BELLOWS

Servometer® miniature metal bellows for flexible seals, volume compensation, pressure responsive devices, EMI shields, vibration dampeners, etc. A 12-page Design

Manual contains detailed formulas for designing miniature nickel bellows plus parts which lend themselves to electroforming. Servometer® Precision Manufacturing Group, LLC, 501 Little Falls Rd., Cedar Grove, NJ 07009-1291; Tel: 973-785-4630; Fax: 973-785-0756; www.servometer.com

Servometer®
Precision Manufacturing Group, LLC

For Free Info Circle No. 676 or
Enter No. 676 at www.nasatech.com/rs



AWARD WINNING FLUID FLOW SOFTWARE

Design Flow Solutions (DF) DesignNet provides complete hydraulic analysis of piping networks for both gases and liquids. Network branches can consist of any combination of pipe, fittings, and valves, with virtually no limit on components. DesignNet solves networks using the Darcy-Weisbach and Bernoulli's for liquids and the differential form of Bernoulli's theorem together with numerical integration techniques for gases. Considers sonic flow and the heat transfer limitations for gases. New training manual is now available. ABZ, Inc.; Tel: 800-747-7401; Fax: 703-631-5282; www.abzinc.com

ABZ, Incorporated

For Free Info Circle No. 680 or
Visit www.nasatech.com/680



SMALL LINEAR TRANSDUCERS - 50,000,000 CYCLES MIN.

Model 5903 * For animatronics, robotics, positioning, linear actuators, ind./aircraft concls. SPECS: Output Smoothness: .05% * Std. Res: 1K Ω , 5K Ω , 10K Ω , 20K Ω . Dimens: Only .312 (8mm) OD, Length 1/2" to 4" * Stroke: Approx. 1" longer than body length * Std. Linearity: 1%, custom avail. * Al. housings, SS shafts. Incl. 3-30 ga. Lead wires. JDK Controls, 424 Crown Pt. Cir., Grass Valley, CA 95945; Tel: 800-880-7730; www.jdkcontrols.com

JDK Controls

For Free Info Circle No. 682 or
Enter No. 682 at www.nasatech.com/rs



ELECTRONIC COMPONENTS DISTRIBUTOR

Mouser Electronics catalog provides product & pricing data for over 130,000 components from 200+ leading suppliers. Our catalog is updated every 90 days and our Internet is updated daily. Our web site offers secure online ordering, data sheets, search capabilities, and much more. Mouser Electronics, Inc., A TTI Inc. Company; Tel: 800-346-6873 or 817-804-3888; Fax: 817-804-3899; e-mail: catalog@mouser.com; www.mouser.com

Mouser Electronics, Inc.

For Free Info Circle No. 686 or
Enter No. 686 at www.nasatech.com/rs



OPTICAL COMPONENTS

Argyle International, an American corporation, supplies optical components of all types including prisms, lenses, light-pipes, windows, beamsplitters. Custom manufactured to your specifications at our factory in China, quantities range from prototype to OEM and quality is always excellent. Materials used range from all glasses to fused silica, silicon, sapphire, and others. Call, fax, e-mail with your requirements. Argyle International Inc., 254 Wall St., Princeton, NJ 08540; Tel: 609-924-9484; Fax: 609-924-2679; www.argleo.com

Argyle International Inc.

For Free Info Circle No. 618 or
Visit www.nasatech.com/618



IEC CORPORATION INTRODUCES FIBER OPTIC SLIP RING LINE

IEC has a catalog of their standard line, but pride themselves in stating that they only sell about 10% standard. Meaning that 90% of their business lies in modified and custom designs. The fiber optic rotary joint, or FORJ, is offered from 1 to 7 channels, single or multi-mode. The standard options available on the electrical component are: 2-60 rings, current to 90 amps, voltage to 6000V, signal to 250 MHz. IEC Corporation, 3100 Longhorn Blvd., Austin, TX 78758; Tel: 512-836-0547; Fax: 512-834-1082; e-mail: info@ieccorporation.com; www.ieccorporation.com

IEC Corporation

For Free Info Circle No. 677 or
Enter No. 677 at www.nasatech.com/rs



POROUS CERAMIC VACUUM CHUCK

PhotoMachining offers a porous ceramic vacuum chuck for use with thin films and other flat samples. Pore sizes under 25 microns assure uniform suction and holding power for even the smallest parts. PhotoMachining also provides contract laser-manufacturing services, and designs and builds custom laser-based manufacturing equipment. PhotoMachining, Inc., 4 Industrial Dr., Unit 40, Pelham, NH 03076; Tel: 603-882-9944; Fax: 603-886-8844; rschaeffer@photomachining.com; www.photomachining.com

PhotoMachining, Inc.

For Free Info Circle No. 683 or
Enter No. 683 at www.nasatech.com/rs



TILT SENSOR

Kavlico's tilt sensor has a molded housing and cable assembly providing excellent humidity resistance for outdoor installations. Rugged design is ideal for high vibration situations such as road construction equipment, agricultural vehicles, cranes & booms, scissor lifts, truck rollover, and more. Quick response time 0.5 to 3 seconds, operates on 5 Vdc and provides a .5 to 4.5 Vdc output. Features EMI, RFI, ESD, and reverse polarity protection. Kavlico Corp.; Tel: 805-523-2000; www.kavlico.com

Kavlico Corporation

For Free Info Circle No. 687 or
Enter No. 687 at www.nasatech.com/rs




FMEA SOFTWARE

Failure Modes and Effects Analysis using FMEA-Pro™ 5 empowers automotive, consumer, electronic, aerospace, defense and general manufacturing industries to improve the quality, reliability and safety of their products. This fully customizable software helps companies comply with QS 9000, ISO 9000, SAE J1739, MIL-STD-1629, ISO/TS 16949 and other regulations. FMEA-Pro™ 5 contains extensive libraries and data protection features. The report generation tools support a variety of file formats, including HTML and PDF. Download a free trial: www.fmeasoftware.com.

Dyadem International Ltd.

For Free Info Circle No. 678 or
Visit www.nasatech.com/678



PRESSURE INDICATING SENSOR FILMS

Pressurex force indicating sensor films enable you to quickly, accurately and inexpensively measure pressure distribution and magnitude between any two contacting surfaces. Ideal QC and R&D applications include evaluation of bolted joints and gasketed surfaces, lamination presses, nip impressions, heat seals, composite material tests and machine calibration. FREE samples. Sensor Products Inc. USA; Tel: 973-884-1755; Fax: 973-884-1699; e-mail: sales@sensorprod.com; www.sensorprod.com

Sensor Products Inc. USA

For Free Info Circle No. 681 or
Enter No. 681 at www.nasatech.com/rs



SELF-COMPENSATED LIQUID LEVELS

Patented Model 187 Self-Compensated Liquid Level Instrument uses capacitance-based technology to address errors in level measurements due to changing liquid/gas compositions, pressures, temperatures and densities inside a vessel. The instrument continuously monitors a gas and liquid reference sensor, as well as a linear sensor that spans the vessel height. American Magnetics, Inc.; Tel: 865-482-1056; e-mail: sales@americanmagnetics.com; www.americanmagnetics.com

American Magnetics, Inc.

For Free Info Circle No. 684 or
Enter No. 684 at www.nasatech.com/rs



ADAPTABLE WORKSTATION SYSTEMS

Arlink's new 32-page Order and Information Guide is packed with products and planning tools helping you create the perfect solution for any application. The guide contains many new items and an easy to use matrix simplifying configuring and accessorizing workstations. Choose a variety of workstation products including modular/cantilever, mobile, height adjustable, and traditional workbenches. Special sections feature workflow management solutions, static control accessories, computing support, ergonomic issues, and more. Arlink; www.arlink.com

Arlink

For Free Info Circle No. 669 or
Visit www.nasatech.com/669



STOCK AND CUSTOM COIL SPRINGS

Over 6,000,000 springs in stock including Mil Spec, Metric and English units.

- A full line of compression, extension and torsion springs.
- Every shipment inspected, certified and traceable — no seconds or recycled rejects.
- Free stock spring catalog, free custom spring designs and quotations.

Use response card, call 800-633-7734, or go to www.msdspring.com.

MSDivisions (MSDSpring)

For Free Info Circle No. 666 or Visit www.nasatech.com/666



ELECTRONIC CATALOG

Free software is now available that allows engineers to search through thousands of standard spiral retaining rings and space saving wave springs. Utilize interactive design wizards to create custom rings and springs, and input assembly parameters to calculate thrust capacity, maximum rpm and stress. Smalley Steel Ring Company, 555 Oakwood Road, Lake Zurich, IL 60047; Tel: 847-719-5900; Fax: 847-719-5999; e-mail: info@smalley.com; www.smalley.com

Smalley Steel Ring Company

For Free Info Circle No. 688 or Enter No. 688 at www.nasatech.com/rs



PEM TD SELF-CLINCHING CABLE TIE-MOUNT HARDWARE

Literature describes the new PEM Type TD™ cable-mount fastener that clinches permanently in metal sheets from .040" to .125" (1mm-3.2mm) in thickness. It provides a secure, clean, accurate attachment point for enclosure-mounted cables and wires. The TD™ mounting hardware is compact, minimizes EMI/RFI, and reduces total installed costs. PEM Fastening Systems - a PennEngineering company; Tel: 800-237-4736; Fax: 215-766-0143; www.pemnet.com

PEM Fastening Systems - A PennEngineering Company

For Free Info Circle No. 689 or Enter No. 689 at www.nasatech.com/rs



LINEAR ACTUATORS

Ideal for robotics, pick-and-place, packaging, medical equipment, clean room, testing, processing, and positioning, the "DigitHS" (High Speed) linear actuators are available in stroke lengths to 8 in. Offering speeds to 14 in/sec, force to 190 lbs, repeatability to 1.5 microns. Totally enclosed, these actuators are available in a variety of drive screw combinations. Ultra Motion; Tel: 631-298-9179; Fax: 831-298-6593.

Ultra Motion

For Free Info Circle No. 667 or Visit www.nasatech.com/667



DIGITAL DELAY/PULSE GENERATOR

DEI's PDG-2510 is a precision digital delay and pulse generator providing two output channels with independent delay and pulse width adjustable from 0 to 99.9 seconds with 25 nanoseconds resolution. With a standard RS-232 interface, it is well suited for laser timing, automated testing and precision pulse applications. See our web site for data sheets and additional product information. Directed Energy; Tel: 970-493-1901; Fax: 970-493-1903; e-mail: deiinfo@directedenergy.com; www.directedenergy.com

Directed Energy, Inc. (DEI)

For Free Info Circle No. 660 or Visit www.nasatech.com/660



SUBSCRIBE TO NATIONAL INSTRUMENTS NEWSLETTERS

Packed full of product information, industry news, and customer application successes, NI gives you valuable technical information for creating your measurement and automation solution based on industry-standard technology. For your FREE Instrumentation Newsletter, NI News, or eSupport News subscription, go to ni.com/info and enter nag740. National Instruments; Tel: 512-683-0100; Toll-free: 800-452-6914; Fax: 512-683-9300; e-mail: info@ni.com.

National Instruments

For Free Info Circle No. 670 or Visit www.nasatech.com/670



OGP WEB SITE

Optical Gaging Products, Inc. (OGP) is a leading manufacturer of dimensional measurement systems. Its website, www.ogpnet.com, has more than 100 pages of information about all the company's products, including the latest multi-sensor technologies and software. Optical Gaging Products, Inc., 850 Hudson Avenue, Rochester, NY 14621; Tel: 585-544-0400; Toll-free: 800-647-4243; www.ogpnet.com

Optical Gaging Products, Inc.

For Free Info Circle No. 668 or Visit www.nasatech.com/668



OEM MANUFACTURING

PolyScience offers contract manufacturing, including OEM and turnkey projects. PolyScience's vertical integrated facility is available for cost-effective design, engineering, and manufacture of a wide variety of products. Core areas of expertise are in electronics, refrigeration, sheet metal, powder coating and assembly. From initial concept to final production, PolyScience can produce complete electromechanical systems and sub-assemblies, including temperature control equipment. PolyScience; Tel: 847-647-0611; Toll-free: 800-229-7569; Fax: 847-647-1155; e-mail: catalogs@polyscience.com; www.polyscience.com

PolyScience

For Free Info Circle No. 671 or Visit www.nasatech.com/671



CUSTOM CERAMIC COMPONENTS


Part shapes to solve functional problems for environments where plastics and metals will not work.

- Withstands Extremely High Temperatures

- Threaded Components
 - Exacting Tolerances
 - Stock Hex-Head Alumina Nuts & Bolts
 - Resists Corrosion and Abrasion
 - Simple to Complex Shapes
 - Affordable Tooling
- Ceramco, Inc., Center Conway, NH; Tel: 603-447-2090; Fax: 603-447-3906; e-mail: info@ceramcoceramics.com; www.ceramcoceramics.com

Ceramco, Inc.

For Free Info Circle No. 685 or Visit www.nasatech.com/685



SURFACE PROFILING TOOL

Triptar's surface profiling tool, SurfaceScope™, renders 3D images of surfaces. It is combined with a standard OEM microscope to extract height information throughout the field of view. Acquisition is extremely fast. Resolution is limited only by the microscope and the electronic camera used to capture the images. Triptar Lens Company, Inc.; www.triptar.com/surfacescope.htm.

Triptar Lens Company, Inc.

For Free Info Circle No. 672 or Visit www.nasatech.com/672



"AUTO-SLIDES" MOTOR READY LINEAR BALL OR CROSSED ROLLER STAGES

With a flexible zero backlash coupling, straight line accuracy of up to 0.0001" per inch of travel and repeatability of 0.0001", the new slides offer precision linear motion at prices starting at \$844. Auto-Slides provide a 3/8" diameter 0.10" lead screw with anti-backlash nut and contain a Nema 23 mount for motor installation. They are available with special configurations and a variety of leads and pitches. Tusk Direct; Tel: 800-447-2042 or 203-790-4611; www.tuskdirect.com.

Tusk Direct

For Free Info Circle No. 690 or Enter No. 690 at www.nasatech.com/rs



PRECISION-ENGINEERED RINGS

USA Tolerance Rings manufactures and distributes a precision-engineered ring that uses the natural elasticity of metals to securely hold parts and transmit torque.

- Allows limitless pre-alignment of parts for precise timing
 - Not only transmits torque but works as a safety clutch to prevent damage to expensive components
 - Holds secure over extreme temperatures and compensates for differing rates of material expansion
 - Helps eliminate vibration, reducing noise and wear on brushes in electric motors
- USA Tolerance Rings; Toll-free: 877-865-7464; www.usatolerancerings.com

USA Tolerance Rings

For Free Info Circle No. 673 or Visit www.nasatech.com/673

Advertisers Index

For free product literature from these advertisers, enter their reader service numbers at www.nasatech.com/rs

Advertisers listed in bold-face type have banner ads on the NASA Tech Briefs Web site — www.nasatech.com

Company	Reader Service Number	Page	Company	Reader Service Number	Page
ABZ	680.....	76	Micro Mo Electronics	651, 652.....	72
Accuride	524.....	51	Microsoft Business Tools Div	504.....	4-5
ACR Systems Inc.	541.....	66	MicroStrain	508.....	56
Aero Tec	454.....	66	Minco Products, Inc.	538.....	64
Algor, Inc.	513	7	Mouser Electronics, Inc.	686.....	76
Amacoil Inc.	615.....	72	MSC Software	511	16-17
American Magnetics, Inc.	684.....	76	MSDivisions.....	666.....	77
Ansoft Corporation	566.....	45	National Instruments Corporation	670	COV II, 44, 77, 1a
Argyle International Inc.	618.....	76	Noran Engineering, Inc.	537.....	57
Arlink.....	669.....	76	Omega Engineering, Inc.	500, 501.....	1
ASME International	544.....	74	Optical Gaging Products Inc.	668.....	77
Autodesk	509.....	19	Panasonic Vision Systems Group	59, 61, 63, 65	65
BSI/Broadax Systems.....	506.....	8	PEM Fastening Systems-A PennEngineering Company.....	689.....	77
Campbell Scientific	535.....	52	PhotoMachining, Inc.	683.....	76
Ceramco Inc.	685.....	77	Polyscience	671.....	77
Compaq Computer Corporation	518.....	11	Presray Corporation.....	549.....	58
Comsol Inc.	25-26		Prior Scientific, Inc.	428.....	12a
Dewetron.....	520.....	33	PTC	531.....	46-47
Digi-Key Corporation.....	503.....	3	RAE Corporation	543.....	74
Directed Energy, Inc.	660.....	77	Renishaw Inc.	654.....	68
Dolch Computer Systems	517.....	23	Research Systems	525	36
Duma Optronics Ltd.....	402.....	11a	Sensor Products Inc.	681.....	76
Dyadem International	678.....	76	Sensors Unlimited	547.....	53
EDS Unigraphics	507.....	9	Servometer	676.....	76
Electrocube.....	529.....	50	Smalley Steel Ring Company	688.....	77
Emhart, a Black & Decker Company	411, 534.....	20-21	SolidWorks	515.....	12-13
Epix	445.....	14a	Spectra-Physics Lasers	404.....	7a
Fluke Electronics	532.....	40	Stanford Research Systems	528.....	39
Gage Applied, Inc.	516.....	55	StellarNet Inc.	498.....	8a
Globe Motors	450.....	73	StockerYale Canada, Inc.	401.....	6a
HD Systems, Inc.....	656-659.....	69	Synrad, Inc.	502.....	2
Helical Products Company	653.....	71	TEAC America	505.....	35
IBM.....	28		Thermo Laser Science.....	484.....	3a
IEC Corporation.....	677.....	76	Thomson Industries, Inc.	545.....	COV III
IEEE.....	512.....	15	TranTek Drive Systems Inc.	655.....	70
Innovative Integration	527.....	38	Triptar Lens Co.	672.....	77
Instron Corporation.....	530.....	10	Tusk Direct	690.....	77
Integrated Engineering Software	546.....	COV IV	Ultra Motion.....	667.....	77
IOtech.....	40 A-B		USA Tolerance Rings.....	673.....	77
JDK Controls.....	682.....	76	Velmex.....	539.....	66
Kaman Sensors	533.....	22	VX Corporation	526.....	37
Kavlico	687.....	76	yet2.com	585, 489	24, 60, 8a, 9a
Keithley Instruments	523	43	ZC & R.....	469.....	5a
Master Bond Inc.	542	73	Zaber	403.....	14a
The MathWorks, Inc.	522.....	49			

Ride-along enclosed in versions 1, 2, 3, 4, 13; Standard Mail enclosed in versions 5, 6, 7, 8, 14

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright ©2002 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S. and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years. Single copies \$5.00. Foreign subscriptions one-year U.S. Funds \$195.00. Remit by check, draft,

postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to NASA Tech Briefs, PO Box 10523, Riverton, NJ 08076-9023.

The Thomson Linear Motion and Control Library:

Access the Complete World of Linear Motion & Control Technology



LINEAR BEARINGS

60 CASE™ SHAFTING

SYSTEMS, SLIDES & STAGES

MOTION CONTROL

LINEAR GUIDES

GEARHEADS

BALL SCREWS


ACTUATORS

MOTORS

POLYMER BEARINGS

PRECISION BALLS

FEEDBACK DEVICES



For a free CD:

CALL: 1-800-554-8466 • FAX: 1-516-944-1045

INTERNET: www.thomsonindustries.com

E-MAIL: litrequest@thomsonmail.com

- Every Catalog
 - Every CAD File
 - Every Application Tool
- in one easy-to-use CD!

THOMSON
First in Linear Motion and Control Technology


©2002 Thomson Industries, Inc. Printed in the U.S.A. KP 5-9-02 200205-07.qxd



LOOKING FOR A FASTER WAY TO ROCKET THROUGH THE PRODUCT-TO-MARKET CYCLE?


ACCELERATE WITH IES

Whether you're designing electric motors, MEMS devices, magnetic sensors, ion guns, high voltage equipment or power electronics systems, Integrated's innovative electromagnetic simulation software will get you from concept-to-market faster and beats conventional method EM simulation software...hands down.



HOW?


- An intuitive graphical user interface designed specifically with the engineer in mind



- The industry's most powerful geometric modeler with built-in parametrics for design optimization
- Fully optimized solvers for unequaled speed and performance
- Exact modeling of geometry and superior modeling of regions exterior to device for the most accurate field results
- Advanced, direct plug-in interoperability with leading CAD software
- Unmatched technical support

Rely on IES's software to accurately model your most complex electromagnetic device or system and predict force, torque, field components, capacitance, inductance, space charge, eddy currents, power system performance and more...

Dream a design, plug it in, optimize it and speed it to market like never before.



For a test flight of any of IES's simulation tools, contact Integrated Engineering Software at 204-632-5636, e-mail us at info@integratedsoft.com or visit www.integratedsoft.com



**INTEGRATED
ENGINEERING SOFTWARE**

Setting the Standard...Again

